


**MITSUBISHI
ELECTRIC
INVERTER**

**CC2
INSTRUCTION MANUAL**

Converter Unit

FR-CC2-H315K to H630K



INTRODUCTION	1
INSTALLATION AND WIRING	2
PRECAUTIONS FOR USE OF THE CONVERTER UNIT	3
BASIC OPERATION	4
PARAMETER	5
PROTECTIVE FUNCTIONS	6
PRECAUTIONS FOR MAINTENANCE AND INSPECTION	7
SPECIFICATIONS	8

Thank you for choosing this Mitsubishi converter unit.

This Instruction Manual provides handling information and precautions for use of the FR-CC2 series.

Incorrect handling might cause an unexpected fault. Before using this converter unit, always read this Instruction Manual carefully to use this product correctly.

Safety instructions

Do not attempt to install, operate, maintain or inspect the product until you have read through this Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, qualified personnel means a person who meets all the conditions below.

- A person who possesses a certification in regard with electric appliance handling, or person took a proper engineering training.


Such training may be available at your local Mitsubishi office. Contact your local sales office for schedules and locations.

- A person who can access operating manuals for the protective devices (e.g. light curtain) connected to the safety control system. A person who has read and familiarized himself/herself with the manuals.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Warning Incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Caution Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

Even items that are marked with the  icon

may lead to a potentially critical situation, depending on the circumstances. Both instruction levels must be followed because these are important to personal safety.

Electric Shock Prevention



Warning

- While the converter power is ON, do not open the front cover or the wiring cover. Do not run the converter with the front cover or the wiring cover removed. Otherwise you may access the exposed high voltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. Accidentally touching the charged converter circuits will result in electric shock.
- Before wiring or inspection, LED indication of the operation panel must be switched OFF. Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- A neutral-point earthed (grounded) power supply for converter unit in compliance with EN standard must be used.
- Any person who is involved in wiring or inspection of this equipment shall be fully competent to do the work.
- The converter unit must be installed before wiring. Otherwise you may get an electric shock or be injured.
- Setting dial and key operations must be performed with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.
- Do not change the cooling fan while power is ON. It is dangerous to change the cooling fan while power is ON.
- Do not touch the printed circuit board or handle the cables with wet hands. Otherwise you may get an electric shock.

Fire Prevention



Caution

- The converter unit must be installed on a nonflammable wall without holes (so that nobody touches the converter unit heatsink on the rear side, etc.). Mounting it to or near flammable material may cause a fire.
- If the converter unit has become faulty, the converter power must be switched OFF. A continuous flow of large current may cause a fire.
- Be sure to perform daily and periodic inspections as specified in the Instruction Manual. If a product is used without any inspection, a burst, breakage, or a fire may occur.

Injury Prevention



Caution

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise a burst, damage, etc. may occur.
- The cables must be connected to the correct terminals. Otherwise a burst, damage, etc. may occur.
- The polarity (+ and -) must be correct. Otherwise a burst, damage, etc. may occur.
- While power is ON or for some time after power OFF, do not touch the converter unit as it will be extremely hot. Touching these devices may cause a burn.

Additional instructions

The following instructions must be also followed. If the product is handled incorrectly, it may cause unexpected fault, an injury, or an electric shock.



Caution

Transportation and mounting

- Any person who is opening a package using a sharp object, such as a knife and cutter, must wear gloves to prevent injuries caused by the edge of the sharp object.
- The product must be transported in correct method that corresponds to the weight. Failure to do so may lead to injuries.
- Do not stand or rest heavy objects on the product.
- Do not stack the boxes containing converters higher than the number recommended.
- When carrying the converter, do not hold it by the front cover or setting dial; it may fall off or fail.
- During installation, caution must be taken not to drop the converter unit as doing so may cause injuries.
- The product must be installed on the surface that withstands the weight of the converter unit.
- Do not install the product on a hot surface.
- The mounting orientation of the converter unit must be correct.
- The converter unit must be installed on a strong surface securely with screws so that it will not drop.
- Do not install or operate the converter unit if it is damaged or has parts missing.
- Foreign conductive objects must be prevented from entering the converter unit. That includes screws and metal fragments or other flammable substance such as oil.
- As the converter unit is a precision instrument, do not drop or subject it to impact.
- The surrounding air temperature for the FR-CC2-H315K to H560K must be between -10°C and +50°C (non-freezing). The surrounding air temperature for the FR-CC2-H630K must be between -10°C and +40°C (non-freezing). Otherwise the converter unit may be damaged.
- The ambient humidity must be 95%RH or less (non-condensing). Otherwise the converter unit may be damaged. (For the details, refer to [page 17.](#))

Caution

Transportation and mounting

- The storage temperature (applicable for a short time, e.g. during transit) must be between -20 and +65°C. Otherwise the converter unit may be damaged.
- The converter unit must be used indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.) Otherwise the converter unit may be damaged.
- The converter unit must be used at an altitude of 2500 m or less above sea level, with 2.9 m/s² or less vibration at 10 to 55 Hz (directions of X, Y, Z axes). Otherwise the converter unit may be damaged. (For the details, refer to [page 17](#).)
- If halogen-based materials (fluorine, chlorine, bromine, iodine, etc.) infiltrate into a Mitsubishi product, the product will be damaged. Halogen-based materials are often included in fumigant, which is used to sterilize or disinfect wooden packages. When packaging, prevent residual fumigant components from being infiltrated into Mitsubishi products, or use an alternative sterilization or disinfection method (heat disinfection, etc.) for packaging. Sterilization or disinfection of wooden package should also be performed before packing a product.

Test run

- Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions.

Warning

Usage

- Everyone must stay away from the equipment when the retry function is set as it will restart suddenly after a trip.
- Since pressing a STOP/RESET key of the operation panel may not stop output depending on the function setting status, separate circuit and switch that make an emergency stop (power OFF, mechanical brake operation for emergency stop, etc.) must be provided.
- OFF status of the start signal must be confirmed before resetting an inverter fault. Resetting an converter unit fault with the start signal ON restarts the motor suddenly.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

Caution

Usage

- Do not use a magnetic contactor on the input side for frequent starting/stopping of the inverter. Otherwise the life of the inverter and the converter unit decreases.
- The effect of electromagnetic interference must be reduced by using a noise filter or by other means. Otherwise nearby electronic equipment may be affected.
- Appropriate measures must be taken to suppress harmonics. Otherwise power supply harmonics from the inverter or the converter unit may heat/damage the power factor correction capacitor and generator.
- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations. because all parameters return to their initial values.
- Before running a converter unit which had been stored for a long period, inspection and test operation must be performed.
- Static electricity in your body must be discharged before you touch the product.

Emergency stop

- A safety backup such as an emergency brake must be provided to prevent hazardous conditions to the machine and equipment in case of converter unit failure.
- When the breaker on the converter unit's input side trips, check for the wiring fault (short circuit), damage to internal parts of the converter unit, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.
- When a protective function is activated, take an appropriate corrective action, then reset the converter unit (inverter), and resume the operation.

Maintenance, inspection and parts replacement

- Do not carry out a megger (insulation resistance) test on the control circuit of the inverter. It will cause a failure.

Disposal

- The converter must be treated as industrial waste.

General instruction

- Many of the diagrams and drawings in the Instruction Manual show the product without a cover or partially open for explanation. Never operate the product in this manner. The cover must be always reinstalled and the instruction in the Instruction Manual must be followed when operating the product.

CONTENTS

1	INTRODUCTION	7
1.1	Product checking	8
1.2	Component names	9
1.3	About the related manuals	10
2	INSTALLATION AND WIRING	11
2.1	Peripheral devices	12
2.1.1	Converter unit and peripheral devices	12
2.1.2	Peripheral devices	14
2.2	Removal and reinstallation of the front cover	15
2.3	Installation of the converter unit and enclosure design	17
2.3.1	Converter unit installation environment	17
2.3.2	Cooling system types for converter unit enclosure	20
2.3.3	Installation of the converter unit	21
2.3.4	Protruding the heatsink	23
2.4	Terminal connection diagrams	25
2.5	Main circuit terminals	28
2.5.1	Details on the main circuit terminals	28
2.5.2	Terminal layout of the main circuit terminals, wiring of the power supply and the inverter	28
2.5.3	Applicable cables	30
2.5.4	Earthing (grounding) precautions	31
2.6	Control circuit	32
2.6.1	Details on the control circuit terminals	32
2.6.2	Control logic (sink/source) change	34
2.6.3	Wiring of control circuit	36
2.6.4	Wiring precautions	38
2.6.5	When using separate power supplies for the control circuit and the main circuit	39
2.6.6	When supplying 24 V external power to the control circuit	40
2.7	Communication connectors and terminals	42
2.7.1	PU connector	42
2.7.2	RS-485 terminal block	43
3	PRECAUTIONS FOR USE OF THE CONVERTER UNIT	45
3.1	Electro-magnetic interference (EMI) and leakage currents	46
3.1.1	Leakage currents and countermeasures	46
3.1.2	Countermeasures against EMI generated by the inverter or the converter unit	48
3.1.3	Built-in EMC filter	51
3.2	Power supply harmonics	52
3.2.1	Power supply harmonics	52

3.2.2	Harmonic Suppression Guidelines	53
3.3	Installation of a reactor	55
3.4	Power-OFF and magnetic contactor (MC)	56
3.5	Checklist before starting operation	58

4 BASIC OPERATION **59**

4.1	Operation panel (FR-DU08)	60
4.1.1	Components of the operation panel (FR-DU08).....	60
4.1.2	Basic operation of the operation panel.....	61
4.1.3	Correspondences between digital and actual characters.....	62
4.1.4	Changing the parameter setting value	63
4.2	Monitoring the converter unit status	64
4.2.1	Monitoring of converter output voltage and input current	64
4.2.2	First monitored item.....	64

5 PARAMETER **65**

5.1	Parameter list	66
5.1.1	Parameter list (by parameter number)	66
5.1.2	Parameter display by function group.....	69
5.1.3	Parameter list (by function group)	70
5.2	(E) Environment setting parameters	72
5.2.1	Real time clock function	73
5.2.2	Reset selection / disconnected PU detection / reset limit.....	75
5.2.3	Buzzer control	76
5.2.4	Display-off mode	76
5.2.5	Setting dial key lock operation selection	76
5.2.6	Parameter write selection	77
5.2.7	Password function.....	78
5.2.8	Free parameter.....	80
5.2.9	Converter unit parts life display	80
5.2.10	Maintenance timer alarm	82
5.3	(H) Protective function parameter	83
5.3.1	Varying the activation level of the undervoltage protective function.....	83
5.3.2	Initiating a protective function.....	83
5.3.3	Input phase loss protection selection	84
5.3.4	Retry function	84
5.4	(M) Monitor display and monitor output signal	86
5.4.1	Monitor display selection using operation panel or via communication.....	86
5.4.2	Output terminal function selection	90
5.4.3	Detection of control circuit temperature.....	93
5.5	(T) Multi-function input terminal parameters	94
5.5.1	Input terminal function selection.....	94
5.5.2	Operation selection for the external thermal relay input (Pr.876).....	95

5.6	(A) Application parameters	96
5.6.1	Self power management.....	96
5.6.2	Automatic restart after instantaneous power failure selection	98
5.6.3	Power failure time deceleration-to-stop function.....	99
5.7	(N) Operation via communication and its settings	100
5.7.1	Wiring and configuration of PU connector	100
5.7.2	Wiring and configuration of RS-485 terminals	102
5.7.3	Initial setting of operation via communication	105
5.7.4	Initial settings and specifications of RS-485 communication	106
5.7.5	Mitsubishi inverter protocol (computer link communication)	108
5.7.6	Modbus-RTU communication specification	119
5.8	Parameter clear / all parameter clear	132
5.9	Copying and verifying parameters	133
5.9.1	Parameter copy	133
5.9.2	Parameter verification.....	135
5.10	Checking parameters changed from their initial values (Initial value change list)	136

6 PROTECTIVE FUNCTIONS 137

6.1	Converter unit fault and alarm indications	138
6.2	Reset method for the protective functions	138
6.3	Check and clear of the faults history	139
6.4	Faults history and the list of fault displays	141
6.5	Causes and corrective actions	142
6.6	Check first when you have trouble	148
6.6.1	Converter unit does not operate properly	148
6.6.2	The power lamp is OFF	148
6.6.3	The charge lamp is OFF	148
6.6.4	Operation panel (FR-DU08) display is not operating.....	148
6.6.5	Inverter cannot be operated.....	149
6.6.6	Unable to write parameter setting	149
6.6.7	Breaker trips	149
6.6.8	Converter unit generates abnormal noise.....	149

7 PRECAUTIONS FOR MAINTENANCE AND INSPECTION 151

7.1	Inspection item	152
7.1.1	Daily inspection.....	152
7.1.2	Periodic inspection.....	152
7.1.3	Daily and periodic inspection	153
7.1.4	Checking the converter module	155
7.1.5	Cleaning.....	155
7.1.6	Replacement of parts.....	156
7.1.7	Converter unit replacement	158

7.2	Measurement of main circuit voltages, currents and powers	159
7.2.1	Measurement of powers	160
7.2.2	Measurement of voltages and use of PT	160
7.2.3	Measurement of currents	161
7.2.4	Use of CT and transducer	161
7.2.5	Example of measuring converter unit input power factor	161
7.2.6	Measurement of converter output voltage (across terminals P and N)	161
7.2.7	Insulation resistance test using megger	162
7.2.8	Pressure test	162

8 SPECIFICATIONS **163**

8.1	Converter unit rating	164
8.2	Common specifications	164
8.3	Outline dimension drawings	165
8.3.1	Converter unit outline dimension drawings	165

APPENDIX **167**

Appendix1	Instruction code list.....	168
Appendix2	Instructions for compliance with the EU Directives	170
Appendix3	Instructions for UL and cUL	172

1 INTRODUCTION

This chapter contains the descriptions that must be read before using this product.

Always read the instructions before using the equipment.

1.1	Product checking.....	8
1.2	Component names.....	9
1.3	About the related manuals.....	10

<Abbreviations>

DU.....	Operation panel (FR-DU08)
PU.....	Operation panel (FR-DU08)
Converter unit	Converter unit FR-CC2 series
FR-CC2.....	Converter unit FR-CC2 series
Pr.	Parameter number (Number assigned to function)

<Trademarks>

- Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States and other countries.
- Other company and product names herein are the trademarks and registered trademarks of their respective owners.

<Notes on descriptions in this Instruction Manual>

- Connection diagrams in this Instruction Manual suppose that the control logic of the input terminal is the sink logic, unless otherwise specified. (For the control logic, refer to [page 34.](#))

Harmonic Suppression Guidelines

All the models of the inverters used by specific consumers are covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". (For the details, refer to [page 53.](#))

1.1 Product checking

Unpack the product and check the capacity plate on the front cover and the rating plate on the side to ensure that the model agrees with the order and the product is intact.


● Converter unit model

Symbol	Voltage class
H	400V class

Symbol	Description
315K to 630K	Rated converter unit capacity (kW)

FR-CC2-H 315K -60

Symbol	Circuit board coating (conforming to IEC60721-3-3 3C2/3S2)	Plated conductor
-60	With	Not used
-06	With	With




Rating plate

Converter unit model Input rating Output rating SERIAL Manufactured year and month	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;"> MITSUBISHI ELECTRIC </td> <td style="text-align: right; vertical-align: middle;"> INVERTER </td> <td style="text-align: right; vertical-align: middle;"> <div style="border: 1px solid black; border-radius: 5px; padding: 2px; display: inline-block;">PASSED</div> </td> </tr> <tr> <td colspan="3"> MODEL FR-CC2-H315K-60 </td> </tr> <tr> <td colspan="3"> INPUT : XXXXX </td> </tr> <tr> <td colspan="3"> OUTPUT : XXXXX </td> </tr> <tr> <td colspan="3"> SERIAL : XXXXXXXXXX DATE : XXXX-XX </td> </tr> </table>	MITSUBISHI ELECTRIC	INVERTER	<div style="border: 1px solid black; border-radius: 5px; padding: 2px; display: inline-block;">PASSED</div>	MODEL FR-CC2-H315K-60			INPUT : XXXXX			OUTPUT : XXXXX			SERIAL : XXXXXXXXXX DATE : XXXX-XX		
MITSUBISHI ELECTRIC	INVERTER	<div style="border: 1px solid black; border-radius: 5px; padding: 2px; display: inline-block;">PASSED</div>														
MODEL FR-CC2-H315K-60																
INPUT : XXXXX																
OUTPUT : XXXXX																
SERIAL : XXXXXXXXXX DATE : XXXX-XX																

● How to read the SERIAL number

Rating plate example




The SERIAL consists of one symbol, two characters indicating the production year and month, and six characters indicating the control number.

The last digit of the production year is indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), or Z (December.)

1.2 Component names

Component names are shown below.



Symbol	Name	Description	Refer to page
(a)	PU connector	Connects the operation panel (FR-DU08). This connector also enables the RS-485 communication.	42
(b)	For manufacturer setting. Do not use.		-
(c)	RS-485 terminals	Enables RS-485 and Modbus-RTU communication.	43
(d)	For manufacturer setting. Do not use.		-
(e)	Control circuit terminal block	Connects cables for the control circuit.	32
(f)	EMC filter ON/OFF connector	Turns ON/OFF the EMC filter.	51
(g)		Turns ON/OFF the EMC filter. (Provided only for the FR-CC2-H400K or higher)	
(h)	Main circuit conductor	Connects cables for the main circuit.	28
(i)	Charge lamp	Stays ON while the power is supplied to the main circuit.	28
(j)	Alarm lamp	Turns ON when the protective function of the converter is activated.	28
(k)	Power lamp	Stays ON while the power is supplied to the control circuit (R1/L11, S1/L21).	28
(l)	Front cover (upper side)	Remove this cover for the installation of the product, RS-485 terminal wiring, etc.	15
(m)	Front cover (lower side)	Remove this cover for wiring.	15
(n)	Cooling fan	Cools the converter.	157
(o)	Accessory cover	Covers the operation panel (FR-DU08) installation area	15

1.3 About the related manuals

The manuals related to FR-CC2 are shown below.

Manual name	Manual number
FR-A802 Instruction Manual (Hardware)	IB-0600534ENG
FR-A800 Instruction Manual (Detailed)	IB-0600503ENG
FR-F802 Instruction Manual (Hardware)	IB-0600550ENG
FR-F800 Instruction Manual (Detailed)	IB-0600547ENG

2 **INSTALLATION AND WIRING**


This chapter explains the "installation" and the "wiring" of this product.

Always read the instructions before using the equipment.

2.1	Peripheral devices	12
2.2	Removal and reinstallation of the front cover.....	15
2.3	Installation of the converter unit and enclosure design	17
2.4	Terminal connection diagrams	25
2.5	Main circuit terminals	28
2.6	Control circuit	32
2.7	Communication connectors and terminals	42

2.1 Peripheral devices

2.1.1 Converter unit and peripheral devices



 **NOTE**

- To prevent an electric shock, always earth (ground) the converter unit, the inverter, and the motor.
- Do not install a power factor correction capacitor or surge suppressor or capacitor type filter on the inverter's output side. Doing so will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices is connected, immediately remove it. When installing a molded case circuit breaker on the output side of the inverter, contact the manufacturer of the molded case circuit breaker.
- Electromagnetic wave interference
The input/output (main circuit) of the inverter or the converter unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter or the converter unit. In this case, activating the EMC filter may minimize interference. (Refer to [page 51](#).)
- For details of options and peripheral devices, refer to the respective Instruction Manual.
- A PM motor cannot be driven by the commercial power supply.
- A PM motor is a motor with permanent magnets embedded inside. High voltage is generated at the motor terminals while the motor is running even after the inverter power is turned OFF. Before closing the contactor at the output side, make sure that the inverter power is ON and the motor is stopped.

Symbol	Name	Overview	Refer to page
(a)	Inverter (FR-A800/FR-F800)	The life of the inverter and the converter unit is influenced by the surrounding air temperature. The surrounding air temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure.	17 25 51
(b)	Converter unit (FR-CC2)	Incorrect wiring may lead to damage of the inverter and the converter unit. The control signal lines must be kept fully away from the main circuit lines to protect them from noise. The built-in EMC filter of the converter unit can reduce the noise.	
(c)	Three-phase AC power supply	Must be within the permissible power supply specifications of the converter unit.	164
(d)	Molded case circuit breaker (MCCB), earth leakage circuit breaker (ELB), or fuse	Must be selected carefully since an inrush current flows in the converter unit at power ON.	14
(e)	Magnetic contactor (MC)	Install this to ensure safety. Do not use this to start and stop the inverter. Doing so will shorten the life of the inverter and the converter unit.	56
(f)	AC reactor (FR-HAL)	Install this to suppress harmonics and to improve the power factor. An AC reactor (FR-HAL) (option) is required when installing the inverter near a large power supply system (1000 kVA or more). The inverter or the converter unit may be damaged if you do not use a reactor. Select a reactor according to the applicable motor capacity.	55
(g)	Noise filter	Suppresses the noise radiated from the power supply side of the converter unit.	48
(h)	Brake unit (FR-BU2)	Allows the inverter to provide the optimal regenerative braking capability. Install these options as required.	—
(i)	Resistor unit (MT-BR5)		
(j)	Noise filter	Install this to reduce the electromagnetic noise generated from the inverter or the converter unit. The noise filter is effective in the range from about 0.5 MHz to 5 MHz.	48
(k)	Induction motor	Connect a squirrel-cage induction motor.	—
(l)	Contactor Example) No-fuse switch (DSN type)	Connect this for an application where a PM motor is driven by the load even while the inverter power is OFF. Do not open or close the contactor while the inverter is running (outputting).	—
(m)	PM motor	Drives a PM motor. A PM motor cannot be driven by the commercial power supply.	—

2.1.2 Peripheral devices

◆Compatible inverters

The table below shows the inverter models compatible with the FR-CC2 converter units.

- FR-A800 series

Motor capacity (kW) *1	Converter unit FR-CC2-[]	Inverter											
		SLD (superlight duty)		LD (light duty)		ND (normal duty, initial value)		HD (heavy duty)					
		Model FR-A842-[]	Rated current (A)	Model FR-A842-[]	Rated current (A)	Model FR-A842-[]	Rated current (A)	Model FR-A842-[]	Rated current (A)				
280	H315K	—	—	—	—	—	—	—	—	—	—	—	—
315	H315K	—	—	—	—	—	—	315K	07700	610	—	—	—
355	H355K	—	—	—	—	—	—	—	—	—	—	—	—
355	H355K	—	—	—	—	—	—	315K	07700	683	—	—	—
400	H400K	315K	07700	770	—	—	—	355K	08660	683	—	—	—
400	H400K	315K	07700	770	315K	07700	683	400K	09620	770	—	—	—
450	H450K	355K	08660	866	355K	08660	770	400K	09620	866	—	—	—
450	H450K	355K	08660	866	400K	09620	866	450K	10940	866	—	—	—
500	H500K	400K	09620	962	400K	09620	866	500K	12120	962	—	—	—
500	H500K	400K	09620	962	450K	10940	962	500K	12120	962	—	—	—

- FR-F800 series

Motor capacity (kW) *1	Converter unit FR-CC2-[]	Inverter					
		SLD (superlight duty)		LD (light duty)			
		Model FR-F842-[]	Rated current (A)	Model FR-F842-[]	Rated current (A)		
355	H355K	—	—	—	—	—	—
400	H400K	355K	07700	770	—	—	—
450	H450K	400K	08660	866	—	—	—
500	H500K	450K	09620	962	—	—	—
560	H560K	500K	10940	1094	—	—	—
630	H630K	560K	12120	1212	—	—	—

*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.

◆Selecting the breaker/magnetic contactor

Check the model of the inverter and the converter unit you purchased. Appropriate peripheral devices must be selected according to the capacity.

Refer to the table below to prepare appropriate peripheral devices.

- 400 V class

Motor output (kW)*1	Applicable converter model	Molded case circuit breaker (MCCB)*2 or earth leakage circuit breaker (ELB) (NF, NV type)	Input-side magnetic contactor*3
315	FR-CC2-H315K	700A	S-N600
355	FR-CC2-H355K	800A	S-N600
400	FR-CC2-H400K	900A	S-N800
450	FR-CC2-H450K	1000A	1000A rated product
500	FR-CC2-H500K	1200A	1000A rated product
560	FR-CC2-H560K	1500A	1200A rated product
630	FR-CC2-H630K	2000A	1400A rated product

*1 Assumes the use of a Mitsubishi 4-pole standard motor with the power supply voltage of 400 VAC 50 Hz.


*2 Select an MCCB according to the power supply capacity.

Install one MCCB per converter.

For the use in the United States or Canada, provide the appropriate UL and cUL listed fuse that is suitable for branch circuit protection. (Refer to [page 172](#).)

*3 The magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stops during motor driving, the electrical durability is 25 times.

If using an MC for emergency stop during driving the motor, select an MC regarding the converter unit input side current as JEM1038-AC-3 class rated current. When providing an MC to use the commercial power supply during general-purpose motor operation, select an MC regarding the rated motor current as JEM1038-AC-3 class rated current.





NOTE

- When the converter unit capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the converter unit model, and select cables and reactors according to the motor output.
- When the breaker on the converter unit's input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter or the converter unit, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.

2.2 Removal and reinstallation of the front cover

◆ Removal of the accessory cover and installation of the operation panel (FR-DU08)


- Loosen the two fixing screws on the accessory cover. (These screws cannot be removed.)
- Push the upper edge of the accessory cover and pull the accessory cover to remove.




- To install the inverter operation panel (FR-DU08), align its connector on the back with the PU connector of the inverter, and insert the operation panel. After confirming that the operation panel is fit securely, tighten the screws. (Tightening torque: 0.40 to 0.45 N•m)

◆ Removal of the front cover (lower side)

(a)




(b)




- Remove the mounting screws to remove the front cover (lower side).
- With the front cover (lower side) removed, wiring of the main circuit terminals can be performed.

◆ Removal of the front cover (upper side)



- (a) With the front cover (lower side) removed, loosen the mounting screws on the front cover (upper side). (These screws cannot be removed.)
- (b) While holding the areas around the installation hooks on the sides of the front cover (upper side), pull out the front cover (upper side) using its upper side as a support.
- (c) With the front cover (upper side) removed, wiring of the control circuit or the RS-485 terminals can be performed.

◆ Reinstallation of the front cover



- (a) Insert the upper hooks of the front cover (upper side) into the sockets of the converter unit.
Insert the upper hooks of the front cover (upper side) into the sockets of the converter unit.
- (b) Tighten the mounting screw at the lower part of the front cover (upper side).
- (c) Fasten the front cover (lower side) with the mounting screws.

NOTE

• Fully make sure that the front cover is installed securely. Always tighten the mounting screws of the front cover.

2.3 Installation of the converter unit and enclosure design

When designing or manufacturing an enclosure to contain the converter unit, determine the structure, size, and device layout of the enclosure by fully considering the conditions such as heat generation of the contained devices and the operating environment. A converter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the converter unit in the ambient environment that completely satisfies the equipment specifications.

2.3.1 Converter unit installation environment

The following table lists the standard specifications of the converter unit installation environment. Using the converter unit in an environment that does not satisfy the conditions deteriorates the performance, shortens the life, and causes a failure. Refer to the following points, and take adequate measures.

◆ Standard environmental specifications of the converter unit

Item	Description
Surrounding air temperature	FR-CC2-H315K to H560K: -10 to +50°C (non-freezing) FR-CC2-H630K: -10 to +40°C (non-freezing)
Surrounding air humidity	With circuit board coating (conforming to IEC60721-3-3 3C2/3S2): 95% RH or less (non-condensing) Without circuit board coating: 90% RH or less (non-condensing)
Storage temperature	-20 to +65°C*1
Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)
Altitude	Maximum 1,000 m above sea level*2
Vibration	2.9 m/s ² or less at 10 to 55 Hz (directions of X, Y, Z axes)

*1 Temperature applicable for a short time, e.g. in transit.

*2 For the installation in an altitude above 1000 m (up to 2500 m), derate the rated current 3% per 500 m.

◆ Temperature

The permissible surrounding air temperature of the converter unit is between -10°C and +50°C (-10°C to +40°C for the FR-CC2-H630K). Always operate the converter unit within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures to keep the surrounding air temperature of the converter unit within the specified range.

(a) Measures against high temperature

- Use a forced ventilation system or similar cooling system. (Refer to [page 20](#).)
- Install the enclosure in an air-conditioned electric chamber.
- Block direct sunlight.
- Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
- Ventilate the area around the enclosure well.

(b) Measures against low temperature

- Provide a space heater in the enclosure.
- Do not power OFF the converter unit.

(c) Sudden temperature changes

- Select an installation place where temperature does not change suddenly.
- Avoid installing the inverter near the air outlet of an air conditioner.
- If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

◆ Humidity

Operate the converter unit within the ambient air humidity of usually 45 to 90% (up to 95% with circuit board coating). Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may cause a spatial electrical breakdown. The insulation distance defined in JEM1103 "Control Equipment Insulator" is humidity of 45 to 85%.

(a) Measures against high humidity

- Make the enclosure enclosed, and provide it with a hygroscopic agent.
- Provide dry air into the enclosure from outside.
- Provide a space heater in the enclosure.

(b) Measures against low humidity

Air with proper humidity can be blown into the enclosure from outside. Also when installing or inspecting the unit, discharge your body (static electricity) beforehand, and keep your body away from the parts and patterns.

(c) Measures against condensation

Condensation may occur if frequent operation stops change the in-enclosure temperature suddenly or if the outside air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- Take the measures against high humidity in (a).
- Do not power OFF the converter unit.

◆ Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contacts, reduced insulation and cooling effect due to the moisture-absorbed accumulated dust and dirt, and in-enclosure temperature rise due to a clogged filter. In an atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time. Since oil mist will cause similar conditions, it is necessary to take adequate measures.

Countermeasure

- Place the inverter in a totally enclosed enclosure.
Take measures if the in-enclosure temperature rises. (Refer to [page 20](#).)
- Purge air.
Pump clean air from outside to make the in-enclosure air pressure higher than the outside air pressure.

◆ Corrosive gas, salt damage

If the converter unit is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the above-mentioned measures.

◆ Explosive, flammable gases

As the converter unit is non-explosion proof, it must be contained in an explosion-proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

◆ High altitude

Use the converter unit at an altitude of within 1000 m. For use at an altitude above 1000 m (up to 2500 m), derate the rated current 3% per 500 m.

If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

◆Vibration, impact

The vibration resistance of the converter unit is up to 2.9m/s^2 at 10 to 55 Hz frequency and 1 mm amplitude for the directions of X, Y, Z axes. Applying vibration and impacts for a long time may loosen the structures and cause poor contacts of connectors, even if those vibration and impacts are within the specified values.

Especially when impacts are applied repeatedly, caution must be taken because such impacts may break the installation feet.

Countermeasure






- Provide the enclosure with rubber vibration isolators.
- Strengthen the structure to prevent the enclosure from resonance.
- Install the enclosure away from the sources of the vibration.

2.3.2 Cooling system types for converter unit enclosure

From the enclosure that contains the converter unit, the heat of the converter unit and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-enclosure temperature lower than the permissible temperatures of the in-enclosure equipment including the converter unit.


The cooling systems are classified as follows in terms of the cooling calculation method.

- (a) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- (b) Cooling by heatsink (aluminum fin, etc.)
- (c) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- (d) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

Cooling system		Enclosure structure	Comment
Natural cooling	Natural ventilation (enclosed, open type)		This system is low in cost and generally used, but the enclosure size increases as the converter unit capacity increases. This system is for relatively small capacities.
	Natural ventilation (totally enclosed type)		Being a totally enclosed type, this system is the most appropriate for hostile environment having dust, dirt, oil mist, etc. The enclosure size increases depending on the converter unit capacity.
Forced cooling	Heatsink cooling		This system has restrictions on the heatsink mounting position and area. This system is for relatively small capacities.
	Forced ventilation		This system is for general indoor installation. This is appropriate for enclosure downsizing and cost reduction, and often used.
	Heat pipe		This is a totally enclosed for enclosure downsizing.


2.3.3 Installation of the converter unit

◆ Installation of the converter unit



Fix six positions.

- Install the converter unit on a strong surface securely with screws.
- Leave enough clearances and take cooling measures.
- Avoid places where the converter unit is subjected to direct sunlight, high temperature and high humidity.
- Install the converter unit on a nonflammable wall surface.
- When encasing multiple converter units in an enclosure, install them in parallel as a cooling measure.
- For heat dissipation and maintenance, keep clearance between the converter unit and the other devices or enclosure surface. The clearance below the converter unit is required as a wiring space, and the clearance above the converter unit is required as a heat dissipation space.



*1 For replacing the cooling fan, 30 cm (11.81 inches) or more of space is necessary in front of the converter unit. Refer to [page 157](#) for fan replacement.

◆ Installation orientation of the converter unit

Install the converter unit on a wall as specified. Do not mount it horizontally or in any other way.


◆ Above the converter unit

Heat is blown up from inside the converter unit by the small fan built in the unit. Any equipment placed above the converter unit should be heat resistant.

◆ Encasing multiple inverters and converter units

When multiple inverters and converter units are placed in the same enclosure, generally arrange them horizontally as shown in the figure on the right. Do not place multiple converter units or the converter unit and the inverter vertically. The exhaust air temperature of the converter unit may be increased.


When mounting multiple inverters and converter units, fully take caution not to make the surrounding air temperature of the inverter and the converter unit higher than the permissible value by providing ventilation and increasing the enclosure size.



Arrangement of multiple inverters and converter units

◆ Arrangement of the ventilation fan and the converter unit

Heat generated in the converter unit is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the converter unit to cool air.)



Arrangement of the ventilation fan and the converter unit


2.3.4 Protruding the heatsink

When encasing an converter unit to an enclosure, the heat generated in the enclosure can be greatly reduced by protruding the heatsink of the converter unit.

When installing the converter unit in a compact enclosure, etc., this installation method is recommended.


◆ Panel cutting

Cut the panel of the enclosure according to the converter unit capacity.




◆ Shift and removal of a rear side installation frame

One installation frame is attached to each of the upper and lower parts of the converter unit. Remove the rear side installation frame on the top and bottom sides of the converter unit as shown on the right.



◆ Installation of the converter unit

Push the converter unit heatsink portion outside the enclosure and fix the enclosure and converter unit with upper and lower installation frame.




NOTE

- Having a cooling fan, the cooling section which comes out of the enclosure cannot be used in the environment of water drops, oil, mist, dust, etc.
- Be careful not to drop screws, dust etc. into the converter unit and cooling fan section.

2.4 Terminal connection diagrams

◆When the sink logic is selected



*1 When using separate power supply for the control circuit, remove the jumpers from R1/L11 and S1/L21.

*2 The function of these terminals can be changed with the input terminal assignment (Pr.178, Pr.187, Pr.189).

*3 The function of these terminals can be changed with the output terminal assignment (Pr.195).

*4 The function of these terminals can be changed with the output terminal assignment (Pr.190 to Pr.194).

*5 The connector is for manufacturer setting. Do not use.

*6 Plug-in options cannot be used.

*7 For manufacturer setting. Do not use.


*8 For the FR-CC2-H400K or higher, two EMC filter ON/OFF connectors are provided.

*9 To use RDA signal of the converter unit, select the NC contact input specification for the input logic of MRS signal or X10 signal of the inverter. To use RDB signal of the converter unit, select the NO contact input specification for the input logic of MRS signal or X10 signal of the inverter. (For changing the input logic, refer to the Instruction Manual of the inverter.)

NOTE

- To prevent a malfunction due to noise, keep the signal cables 10 cm or more away from the power cables. Also, separate the main circuit cables at the input side from the main circuit cables at the output side.
- After wiring, wire offcuts must not be left in the inverter or the converter unit. Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter and the converter unit clean. When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter or the converter unit.

◆ When the source logic is selected



- *1 When using separate power supply for the control circuit, remove the jumpers from R1/L11 and S1/L21.
- *2 The function of these terminals can be changed with the input terminal assignment (Pr.178, Pr.187, Pr.189).
- *3 The sink logic is initially set. The control logic can be changed with the jumper connector position.
- *4 The function of these terminals can be changed with the output terminal assignment (Pr.195).
- *5 The function of these terminals can be changed with the output terminal assignment (Pr.190 to Pr.194).
- *6 The connector is for manufacturer setting. Do not use.
- *7 Plug-in options cannot be used.
- *8 For manufacturer setting. Do not use.
- *9 For the FR-CC2-H400K or higher, two EMC filter ON/OFF connectors are provided.
- *10 To use RDA signal of the converter unit, select the NC contact input specification for the input logic of MRS signal or X10 signal of the inverter. To use RDB signal of the converter unit, select the NO contact input specification for the input logic of MRS signal or X10 signal of the inverter. (For changing the input logic, refer to the Instruction Manual of the inverter.)

NOTE


- To prevent a malfunction due to noise, keep the signal cables 10 cm or more away from the power cables. Also, separate the main circuit cables at the input side from the main circuit cables at the output side.
- After wiring, wire offcuts must not be left in the inverter or the converter unit. Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter and the converter unit clean. When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter or the converter unit.

◆ Connection and wiring length between the converter unit and the inverter

- Perform wiring so that the commands sent from the converter unit are transmitted to the inverter without fail. Incorrect connection may damage the converter unit and the inverter.
- For the wiring length, refer to the table below.

Total wiring length	Across the terminals P and P and the terminals N and N	50 m or lower
	Other signal cables	30 m or lower


- For the cable gauge of the cable across the main circuit terminals P/+ and N/- (P and P, N and N), refer to [page 30](#).




- *1 Do not install an MCCB across the terminals P/+ and N/- (across terminals P and P/+ or across N and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
- *2 For the terminal used for the X10 signal input, set "10" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the function.
- *3 To use RDA signal of the converter unit, select the NC contact input specification for the input logic of MRS signal or X10 signal of the inverter. To use RDB signal of the converter unit, select the NO contact input specification for the input logic of MRS signal or X10 signal of the inverter. (For changing the input logic, refer to the Instruction Manual of the inverter.)
- *4 For the terminal used for the X11 signal input, set "11" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the function. For RS-485 or any other communication where the start command is only transmitted once, use the X11 signal to save the operation mode at the time of an instantaneous power failure.
- *5 Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE of the converter unit and the terminal SD (sink logic) of the inverter. Not connecting these terminals may damage the converter unit.

2.5 Main circuit terminals

2.5.1 Details on the main circuit terminals


Terminal symbol	Terminal name	Terminal function description	Refer to page
R/L1, S/L2, T/L3	AC power input	Connect these terminals to the commercial power supply.	—
R1/L11, S1/L21	Power supply for the control circuit	Connected to the AC power supply terminals R/L1 and S/L2. To retain the fault display and fault output, remove the jumpers across terminals R/L1 and R1/L11 and across S/L2 and S1/L21 and supply external power to these terminals. The power capacity necessary when separate power is supplied from R1/L11 and S1/L21 is 80 VA.	39
P/+, N/-	Inverter connection	Connect to terminals P/+ and N/- of the inverter.	25
	Earth (ground)	For earthing (grounding) the converter unit chassis. This must be earthed (grounded).	31

2.5.2 Terminal layout of the main circuit terminals, wiring of the power supply and the inverter




NOTE

- Make sure the power cables are connected to the R/L1, S/L2, and T/L3. (Phase need not be matched.)
- When wiring the main circuit conductor, tighten a nut from the right side of the conductor.
When wiring two wires, place wires on both sides of the conductor. (Refer to the drawing below.)
For wiring, use bolts (nuts) provided with the converter unit.




- When wiring cables to the main circuit conductor (R/L1, S/L2, T/L3) of the converter unit, use the bolts (nuts) for main circuit wiring, which are provided on the front side of the conductor.

FR-CC2-H315K, H355K



Connect the cables here.

FR-CC2-H400K to H630K



Connect the cables here.

2.5.3 Applicable cables

Select a recommended cable size to ensure that the voltage drop will be 2% or less.

The following table indicates a selection example for the wiring length of 20 m (440 V input power supply, 150% overload current rating for 1 minute).

Converter model FR-CC2-□	Terminal screw Size*4	Tightening Torque N•m	Crimping terminal	Cable gauge					
				HIV cables, etc. (mm ²)*1			AWG/ MCM *2	PVC cables, etc. (mm ²)*3	
				R/L1, S/L2, T/L3	R/L1, S/L2, T/L3	P/+, N/-	Earthing (grounding) cable	R/L1, S/L2, T/L3	R/L1, S/L2, T/L3
H315K	M12 (M10)	46	150-12	2×150	2×150	100	2×300	2×150	150
H355K	M12 (M10)	46	C2-200	2×200	2×200	100	2×350	2×185	2×95
H400K	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95
H450K	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120
H500K	M12 (M10)	46	C2-200	3×200	3×200	2×100	2×500	2×240	2×120
H560K	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×350	3×185	2×150
H630K	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×400	3×185	2×150

- *1 The recommended cable size is that of the cable (LMFC (heat resistant flexible cross-linked polyethylene insulated cable), etc.) with continuous maximum permissible temperature of 90°C or higher. It assumes a surrounding air temperature of 50°C or lower and in-enclosure wiring.
- *2 The recommended cable size is that of the cable (THHN cable) with continuous maximum permissible temperature of 90°C. It assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring.
(Selection example for use mainly in the United States.)
- *3 The cable size is that of the cable (XLPE cable) with continuous maximum permissible temperature of 90°C. It assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring.
(Selection example for use mainly in Europe.)
- *4 The terminal screw size indicates the size of a terminal screw for R/L1, S/L2, T/L3, P/+, N/-, and a screw for earthing (grounding).
Screw size for earthing (grounding) is indicated in parentheses.

The line voltage drop can be calculated by the following formula:

$$\text{Line voltage drop [V]} = \frac{\sqrt{3} \times \text{wire resistance [m}\Omega\text{/m]} \times \text{wiring distance [m]} \times \text{current [A]}}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

NOTE

- Tighten the terminal screw to the specified torque.
A screw that has been tightened too loosely can cause a short circuit or malfunction.
A screw that has been tightened too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimping terminals with insulation sleeves to wire the power supply and motor.

2.5.4 Earthing (grounding) precautions

- Always earth (ground) the converter unit.

◆ Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flows into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operators from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

◆ Earthing (grounding) methods and earthing (grounding) work

As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-influenced malfunction prevention type. Therefore, these two types should be clearly distinguished, and the following work must be done to prevent the leakage current having the converter unit's high frequency components from entering the malfunction prevention type earthing (grounding):

- Whenever possible, use the independent earthing (grounding) for the converter unit.

If independent earthing (grounding) (I) is not available, use (II) common earthing (grounding) in the figure below where the converter unit is connected with the other equipment at an earthing (grounding) point. Do not use the other equipment's earthing (grounding) cable to earth (ground) the converter unit as shown in (III).




A leakage current containing many high frequency components flows into the earthing (grounding) cables of the converter unit. Because of this, the converter unit must be earthed (grounded) separately from EMI-sensitive devices.

In a high building, it may be effective to use the EMI prevention type earthing (grounding) connecting to an iron structure frame, and electric shock prevention type earthing (grounding) with the independent earthing (grounding) together.

- Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards).

A neutral-point earthed (grounded) power supply in compliance with EN standard must be used.

- use the thickest possible earthing (grounding) cable. The earthing (grounding) cable should be the size indicated in the table on [page 30](#).
- The earthing (grounding) point should be as close as possible to the converter unit, and the earth (ground) wire length should be as short as possible.
- Run the earthing (grounding) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.



To be compliant with the EU Directive (Low Voltage Directive), refer to [page 170](#).

2.6 Control circuit

2.6.1 Details on the control circuit terminals

The input signal function of the terminals in can be selected by setting **Pr.178, Pr.187, Pr.189 to Pr.195** (I/O terminal function selection). (Refer to [page 90, 94.](#))

◆ Input signal

Type	Terminal Symbol	Terminal name	Terminal function description	Rate Specification
Contact input	RES	Reset	Use this signal to reset a fault output provided when a protective function is activated. Turn ON the RES signal for 0.1 s or longer, then turn it OFF. In the initial setting, reset is always enabled. By setting Pr.75 , reset can be set enabled only at fault occurrence of the converter unit. The inverter recovers about 1 s after the reset is released.	Input resistance 4.7 kΩ Voltage when contacts are open: 21 to 27 VDC When contacts are short-circuited: 4 to 6 mADC
	OH	External thermal relay input	The external thermal relay input (OH) signal is used when using an external thermal relay or a thermal protector built into the motor to protect the motor from overheating. When the thermal relay is activated, the inverter trips by the external thermal relay operation (E.OHT).	
	RDI	Contact input	No function is assigned in the initial setting. The function can be assigned by setting Pr.178 .	
	SD	Contact input common (sink)	Common terminal for contact input terminal (sink logic).	_____
		External transistor common (source)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the source logic to avoid malfunction by undesirable current.	
		24 VDC power supply common	Common terminal for the 24 VDC power supply (terminal PC, terminal +24) Isolated from terminals 5 and SE.	
	PC	External transistor common (sink)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the source logic to avoid malfunction by undesirable current.	Power supply voltage range 19.2 to 28.8 VDC Permissible load current 100 mA
		Contact input common (source)	Common terminal for contact input terminal (source logic).	
		24 VDC power supply common	Can be used as a 24 VDC 0.1 A power supply.	
	External power supply input	+24	24 V external power supply input	For connecting a 24 V external power supply. If a 24 V external power supply is connected, power is supplied to the control circuit while the main power circuit is OFF.

◆ Output signal

Type	Terminal Symbol	Terminal name	Terminal function description	Rate Specification
Relay	A1, B1, C1	Relay output 1 (fault output)	1 changeover contact output that indicates that the protective function of the converter unit has been activated and the outputs are stopped. Fault: discontinuity across B and C (continuity across A and C), Normal: continuity across Band C (discontinuity across A and C)	Contact capacity 230 VAC 0.3 A (power factor = 0.4) 30 VDC 0.3 A
	88R, 88S	For manufacturer setting. Do not use.		
Open collector	RDA	Inverter operation enable (NO contact)	Switched to LOW when the converter unit operation is ready. Assign the signal to the terminal MRS (X10) of the inverter. The inverter can be started when the RDA status is LOW.	Permissible load 24 VDC (maximum 27 VDC) 0.1 A (The voltage drop is 2.8 V at maximum while the signal is ON.) LOW is when the open collector output transistor is ON (conducted). HIGH is when the transistor is OFF (not conducted).
	RDB	Inverter operation enable (NC contact)	Switched to LOW when a converter unit fault occurs or the converter is reset. The inverter can be started when the RDB status is HIGH.	
	RSO	Inverter reset	Switched to LOW when the converter is reset (RES-ON). Assign the signal to the terminal RES of the inverter. The inverter is reset when it is connected with the RSO status LOW.	
	IPF	Instantaneous power failure	Switched to LOW when an instantaneous power failure is detected.	
	FAN	Cooling fan fault	Switched to LOW when a cooling fan fault occurs.	
	SE	Open collector output common	Common terminal for terminals RDA, RDB, RSO, IPF, FAN	

◆ Communication

Type	Terminal symbol	Terminal name	Terminal function description	
RS-485	—	PU connector	With the PU connector, communication can be made through RS-485. (For connection on a 1:1 basis only) Conforming standard: EIA-485 (RS-485) Transmission format: Multidrop link Communication speed: 4800 to 115200 bps Wiring length: 500 m	
	RS-485 terminals	TXD+	Converter unit transmission terminal	The RS-485 terminals enable the communication by RS-485. Conforming standard: EIA-485 (RS-485) Transmission format: Multidrop link Communication speed: 300 to 115200 bps Overall length: 500 m
		TXD-	Converter unit transmission terminal	
		RXD+	Converter unit reception terminal	
		RXD-	Converter unit reception terminal	
	SG	Earthing (grounding)		

2

⚠ Caution

- Do not use the empty terminals (NC) of the control circuit. Doing so may lead to damage of the converter unit and the inverter.
- Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE of the converter unit and the terminal SD (terminal PC in the source logic) of the inverter. Not doing so may lead to damage of the converter unit.

2.6.2 Control logic (sink/source) change


Change the control logic of input signals as necessary.

To change the control logic, change the jumper connector position on the control circuit board.

Connect the jumper connector to the connector pin of the desired control logic.

The jumper connector is in the sink logic (SINK) when shipped from the factory.

(The output signals may be used in either the sink or source logic independently of the jumper connector position.)




NOTE

- Make sure that the jumper connector is installed correctly.
- Never change the control logic while power is ON.



◆ Sink logic and source logic

- In the sink logic, a signal switches ON when a current flows from the corresponding signal input terminal. Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
- In the source logic, a signal switches ON when a current flows into the corresponding signal input terminal. Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.

● Current flow concerning the input/output signal when sink logic is selected




● Current flow concerning the input/output signal when source logic is selected



- When using an external power supply for transistor output


Sink logic

Use the terminal PC as a common terminal, and perform wiring as shown below. (Do not connect the terminal SD of the converter unit with the terminal 0 V of the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the converter unit. Doing so may cause a malfunction in the converter unit due to undesirable currents.)




Source logic

Use the terminal SD as a common terminal, and perform wiring as shown below. (Do not connect the terminal PC of the converter unit with the terminal +24V of the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the converter unit. Doing so may cause a malfunction in the converter unit due to undesirable currents.)



2.6.3 Wiring of control circuit

◆Control circuit terminal layout



*1 For manufacturer setting. Do not use.

⚠ Caution

- Do not use the empty terminals (NC) of the control circuit. Doing so may lead to damage of the converter unit and the inverter.

◆Wiring method

- Power supply connection

For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Insert the blade terminal or the single wire into a socket of the terminal.

(1) Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.


Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.

Cable sheath stripping length



(2) Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve. Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.



- Blade terminals commercially available (as of February 2012)
Phoenix Contact Co., Ltd.

Cable gauge (mm ²)	Blade terminal model			Crimping tool name
	With insulation sleeve	Without insulation sleeve	For UL wire*1	
0.3	AI 0, 5-10WH	-	-	CRIMPFOX 6
0.5	AI 0, 5-10WH	-	AI 0, 5-10WH-GB	
0.75	AI 0, 75-10GY	A 0, 75-10	AI 0, 75-10GY-GB	
1	AI 1-10RD	A 1-10	AI 1-10RD/1000GB	
1.25, 1.5	AI 1, 5-10BK	A 1, 5-10	AI 1, 5-10BK/1000GB*2	
0.75 (for two wires)	AI-TWIN 2 × 0, 75-10GY	-	-	


*1 A blade terminal with an insulation sleeve compatible with the MTW wire which has a thick wire insulation.

*2 Applicable for the terminals A1, B1, C1, A2, B2, and C2 only.


NICHIFU Co.,Ltd.

Cable gauge (mm ²)	Blade terminal product number	Insulation product number	Crimping tool product number
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 69

(3) Insert the wires into a socket.



When using a single wire or stranded wires without a blade terminal, push the open/close button all the way down with a flathead screwdriver, and insert the wire.




NOTE

- When using stranded wires without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Never change the control logic while power is ON.

• Wire removal

Pull the wire while pushing the open/close button all the way down firmly with a flathead screwdriver.



NOTE

- Pulling out the wire forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (tip thickness: 0.4 mm/tip width: 2.5 mm).

If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.

Commercially available products (as of February 2012)

Name	Model	Manufacturer
Driver	SZF 0- 0,4 × 2,5	Phoenix Contact Co., Ltd.

- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.


2

◆ Common terminals of the control circuit (SD, PC, SE)

- Terminals SD (sink logic), PC (source logic), and SE are common terminals (0 V) for I/O signals. (All common terminals are isolated from each other.) Do not earth (ground) these terminals.
- In the sink logic, terminal SD is a common terminal for the contact input terminals (RES, OH, RDI). The open collector circuit is isolated from the internal control circuit by photocoupler.
- In the source logic, terminal PC is a common terminal for the contact input terminals (RES, OH, RDI). The open collector circuit is isolated from the internal control circuit by photocoupler.
- Terminal SE is a common terminal for the open collector output terminals (RDA, RDB, RSO, IPF, FAN). The contact input circuit is isolated from the internal control circuit by photocoupler.




◆ Signal inputs by contactless switches

The contact input terminals of the converter unit (RES, OH, RDI) can be controlled using a transistor instead of a contact switch as shown below.



2.6.4 Wiring precautions

- It is recommended to use a cable of 0.75 mm² for connection to the control circuit terminals.
 - The wiring length should be 30 m at the maximum.
 - Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.
 - To suppress EMI, use shielded or twisted cables for the control circuit terminals and run them away from the main and power circuits (including the 200 V relay sequence circuit). For the cables connected to the control circuit terminals, connect their shields to the common terminal of the connected control circuit terminal. When connecting an external power supply to the terminal PC, however, connect the shield of the power supply cable to the negative side of the external power supply. Do not directly earth (ground) the shield to the enclosure, etc.
 - Always apply a voltage to the fault output terminals (A1, B1, C1) via a relay coil, lamp, etc.
 - Separate the wiring of the control circuit away from the wiring of the main circuit.
- Make cuts in rubber bush of the converter unit side and lead the wires through.



2.6.5 When using separate power supplies for the control circuit and the main circuit



◆ Cable size for the control circuit power supply (terminals R1/L11 and S1/L21)

- Terminal screw size: M4
- Cable gauge: 0.75 mm² to 2 mm²
- Tightening torque: 1.5 N•m

◆ Connected to

When a fault occurs, opening of the electromagnetic contactor (MC) on the converter unit power supply side results in power loss in the control circuit, disabling the fault output signal retention. Terminals R1/L11 and S1/L21 are provided to hold a fault signal. In this case, connect the power supply terminals R1/L11 and S1/L21 of the control circuit to the input side of the MC. Do not connect the power cable to incorrect terminals. Doing so may damage the converter unit.


<Connection diagram>



- Remove the upper screws.
- Remove the lower screws.
- Pull the jumper toward you to remove.
- Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21).

NOTE

- When using separate power supplies, always remove the jumpers from terminals R1/L11 and S1/L21. The converter unit may be damaged if the jumpers are not removed.
- The voltage should be the same as that of the main control circuit when the control circuit power is supplied from other than the input side of the MC.
- The power capacity necessary when separate power is supplied from R1/L11 and S1/L21 is 80 VA.
- If the main circuit power is switched OFF (for 0.1 s or more) then ON again, the converter unit is reset and a fault output will not be held.



2.6.6 When supplying 24 V external power to the control circuit

Connect a 24 V external power supply across terminals +24 and SD. Connecting a 24 V external power supply enables I/O terminal ON/OFF operation, operation panel displays, control functions, and communication during communication operation even during power-OFF of converter unit's main circuit power supply. When the main circuit power supply is turned ON, the power supply changes from the 24 V external power supply to the main circuit power supply.

◆ Specification of the applied 24 V external power supply

Item	Rate Specification
Input voltage	23 to 25.5 VDC
Input current	1.4 A or lower

Commercially available products (as of October 2013)

Model	Manufacturer
S8JX-N05024C *1 Specifications: Capacity 50 W, output voltage 24 VDC, output current 2.1 A Installation method: Front installation with cover or S8VS-06024 *1 Specifications: Capacity 60 W, output voltage 24 VDC, output current 2.5 A Installation method: DIN rail installation *1 For the latest information about OMRON power supply, contact OMRON corporation.	OMRON Corporation

◆ Starting and stopping the 24 V external power supply operation


- Supplying 24 V external power while the main circuit power is OFF starts the 24 V external power supply operation. Likewise, turning OFF the main circuit power while supplying 24 V external power starts the 24 V external power supply operation.
- Turning ON the main circuit power stops the 24 V external power supply operation and enables the normal operation.

NOTE

- When the 24 V external power is supplied while the main circuit power supply is OFF, the converter unit operation is disabled.
- In the initial setting, when the main power supply is turned ON during the 24 V external power supply operation, a reset is performed in the converter unit, then the power supply changes to the main circuit power supply.

◆ Confirming the 24 V external power supply input

- During the 24 V external power supply operation, the ALARM lamp of the accessory cover flickers. When the operation panel (FR-DU08) is installed, "EV" flickers.



- During the 24 V external power supply operation, the 24 V external power supply operation signal (EV) is output. To use the EV signal, set "68 (positive logic) or 168 (negative logic)" in one of **Pr.190 to Pr.195 (output terminal function selection)** to assign function to an output terminal.

◆ Operation while the 24 V external power is supplied

- Faults history and parameters can be read and parameters can be written using the operation panel keys.
- During the 24 V external power supply operation, monitored items and signals related to inputs to main circuit power supply, such as input current, converter output voltage, and IPF signal, are invalid.
- The alarms, which have occurred when the main circuit power supply is ON, continue to be output after the power supply is changed to the 24 V external power supply. Perform the converter reset or turn OFF then ON the power to reset the faults.
- The retry function is invalid for all alarms during the 24 V external power supply.

NOTE


- Inrush current equal to or higher than the 24 V external power supply specification may flow at power-ON. Confirm that the power supply and other devices are not affected by the inrush current and the voltage drop caused by it. Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- When the wiring length between the external power supply and the converter unit is long, the voltage often drops. Select the appropriate wiring size and length to keep the voltage in the rated input voltage range.
- In a serial connection of several converter units, the current increases when it flows through the converter unit wiring near the power supply. The increase of the current causes voltage to drop further. Use the converter units after confirming that the input voltage of each converter unit is within the rated input voltage range. Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- "E.P24" may appear when the start-up time of the 24 V power supply is too long (less than 1.5 V/s) in the 24 V external power supply operation.
- "E.P24" may appear when the 24 V external power supply input voltage is low. Check the external power supply input.
- Do not touch the control circuit terminal block (circuit board) during the 24 V power supply operation (when conducted). Otherwise you may get an electric shock or burn.

2.7 Communication connectors and terminals

2.7.1 PU connector

◆ Installing the operation panel (FR-DU08) on the enclosure surface

- Having an operation panel (FR-DU08) on the enclosure surface is convenient. With a connection cable, you can install the operation panel to the enclosure surface, and connect it to the converter unit.
Use the option FR-CB2[], or connectors and cables available on the market.
(To install the operation panel (FR-DU08), the optional connector (FR-ADP) is required.)
Securely insert one end of the connection cable until the stoppers are fixed.



NOTE

- Refer to the following table when fabricating the cable on the user side. Keep the total cable length within 20 m.
- Commercially available products (as of February 2012)

Name	Model	Manufacturer
Communication cable	SGLPEV-T (Cat5e/300 m) 24AWG × 4P	Mitsubishi Cable Industries, Ltd.
RJ-45 connector	5-554720-3	Tyco Electronics

◆ Communication operation

- Using the PU connector enables communication operation from a personal computer, etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the converter unit or read and write parameters.
Communication can be performed with the Mitsubishi inverter protocol (computer link operation).
For the details, refer to [page 100](#).

2.7.2 RS-485 terminal block


◆ Communication operation

Conforming standard	EIA-485 (RS-485)
Transmission format	Multidrop link
Communication speed	115200 bps maximum
Overall length	500 m
Connection cable	Twisted pair cable (4 pairs)

The RS-485 terminals enables communication operation from a personal computer, etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the converter unit or read and write parameters.

Communication can be performed with the Mitsubishi inverter protocol (computer link operation) and Modbus-RTU protocol.

For the details, refer to [page 102](#).



NOTE

- To avoid malfunction, keep the RS-485 terminal wires away from the control circuit board.

MEMO

3

PRECAUTIONS FOR USE OF THE CONVERTER UNIT

This chapter explains the precautions for use of this product.
Always read the instructions before using the equipment.

3.1	Electro-magnetic interference (EMI) and leakage currents ..	46
3.2	Power supply harmonics	52
3.3	Installation of a reactor	55
3.4	Power-OFF and magnetic contactor (MC)	56
3.5	Checklist before starting operation	58

3.1 Electro-magnetic interference (EMI) and leakage currents

3.1.1 Leakage currents and countermeasures

Capacitances exist between the I/O cables or other cables of the inverter or the converter unit and earth, and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following countermeasures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

◆To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line or the converter unit's own line but also into the other lines through the earthing (grounding) cable, etc. These leakage currents may operate earth leakage circuit breakers and earth leakage relays unnecessarily.

●Countermeasures


- If the carrier frequency setting is high, decrease the **Pr.72 PWM frequency selection** setting. Note that motor noise increases. Selecting **Pr.240 Soft-PWM operation selection** makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).

●To-earth (ground) leakage currents

- Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
- Increasing the motor capacity increases the leakage current.

◆Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacitances between the output cables of the inverter or the converter unit may operate the external thermal relay unnecessarily.



●Countermeasures

- Use **Pr.9 Electronic thermal O/L relay**.
- If the carrier frequency setting is high, decrease the **Pr.72 PWM frequency selection** setting. Note that motor noise increases. Selecting **Pr.240 Soft-PWM operation selection** makes the sound inoffensive. To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

●Installation and selection of the molded case circuit breaker


Install a molded case circuit breaker (MCCB) on the power receiving side to protect the wiring at the input side of the inverter or the converter unit. Select an MCCB according to the inverter input side power factor, which depends on the power supply voltage, output frequency and load. Especially for a completely electromagnetic MCCB, a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.

◆ Selecting the rated sensitivity current for the earth leakage circuit breaker


When using an earth leakage circuit breaker with the circuit of the inverter or the converter unit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

- Breaker designed for harmonic and surge suppression
Rated sensitivity current
 $I_{\Delta n} \geq 10 \times (I_{g1} + I_{gn} + I_{gi} + I_{g2} + I_{gm})$
 - Standard breaker
Rated sensitivity current
 $I_{\Delta n} \geq 10 \times \{I_{g1} + I_{gn} + I_{gi} + 3 \times (I_{g2} + I_{gm})\}$
- I_{g1}, I_{g2} : Leakage currents in wire path during commercial power supply operation
 I_{gn} : Leakage current of inverter input side noise filter
 I_{gm} : Leakage current of motor during commercial power supply operation
 I_{gi} : Leakage current of inverter unit
 (When the converter unit is connected, add the leakage current of converter unit.)

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit




Leakage current example of three-phase induction motor during the commercial power supply operation



For "Δ" connection, the amount of leakage current is approx. 1/3 of the above value.

<Example>



• Selection example for the Δ connection of the 400 V class

Item	Breaker designed for harmonic and surge suppression	Standard breaker
Leakage current I_{g1} (mA)	$\frac{1}{3} \times 66 \times \frac{5 \text{ m}}{1000 \text{ m}} = 0.11$	
Leakage current I_{gn} (mA)	0 (without noise filter)	
Leakage current I_{gi} (mA)	1 (without EMC filter) For the leakage current of the inverter, refer to the following table.	
Leakage current I_{g2} (mA)	$\frac{1}{3} \times 66 \times \frac{60 \text{ m}}{1000 \text{ m}} = 1.32$	
Motor leakage current I_{gm} (mA)	0.36	
Total leakage current (mA)	2.79	6.15
Rated sensitivity current (mA) ($\geq I_g \times 10$)	30	100

• Inverter/converter unit leakage current

400 V class (input power condition: 440 V/60 Hz, power supply unbalance within 3%)

Inverter/ converter unit	FR-A800/FR-F800 (Standard model)		FR-A802/FR-F802 (Separated converter type)	Converter unit FR-CC2			
	ON	OFF		H315K, H355K		H400K to H630K	
EMC filter			-	ON	OFF	ON	OFF
Phase earthing (grounding)	35	2	2	35	2	70	2
Earthed-neutral system	2	1	1	2	1	2	1

(mA)

3

NOTE

- Install the earth leakage circuit breaker (ELB) on the input side of the converter unit.
- In the Δ connection earthed-neutral system, the sensitivity current is blunt against a ground fault at the output side of the inverter. Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is within the rating.
In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- The following models are standard breakers..... BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F earth leakage relay (except NV-ZHA), and NV with AA neutral wire open-phase protection.
The other models are designed for harmonic and surge suppression..... NV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, and NV-H.
- For the leakage current of a 75 kW or higher motor, contact the motor manufacturer.


3.1.2 Countermeasures against EMI generated by the inverter or the converter unit

Some electromagnetic noises enter the inverter or the converter unit to cause the inverter or the converter unit malfunction, and others are radiated by the inverter or the converter unit to cause the peripheral devices to malfunction. Though the inverter or the converter unit is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI countermeasures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- Basic techniques
 - Do not run the power cables (I/O cables) and signal cables of the inverter or the converter unit in parallel with each other and do not bundle them.
 - Use shielded twisted pair cables for the detector connecting and control signal cables and connect the sheathes of the shielded cables to terminal SD.
 - Ground (Earth) the inverter, converter unit, motor, etc. at one point.
- Techniques to reduce electromagnetic noises that enter and cause a malfunction of the inverter or the converter unit (EMI countermeasures)
When devices that generate many electromagnetic noises (which use magnetic contactors, electromagnetic brakes, many relays, for example) are installed near the inverter or the converter unit, and the inverter or the converter unit may malfunction due to electromagnetic noises, the following countermeasures must be taken:
 - Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
 - Install data line filters ([page 50](#)) to signal cables.
 - Ground (Earth) the shields of the detector connection and control signal cables with cable clamp metal.

- Techniques to reduce electromagnetic noises that are radiated by the inverter or the converter unit to cause the peripheral devices to malfunction (EMI countermeasures)

Noises generated from the inverter or the converter unit are largely classified into those radiated by the cables connected to the inverter or the converter unit and their main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit cables, and those transmitted through the power supply cables.



Noise propagation path	Countermeasure
(a) (b) (c)	<p>When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g. instruments, receivers and sensors, are contained in the enclosure that contains the inverter or the converter unit, or when their signal cables are run near the inverter or the converter unit, the devices may malfunction due to by air-propagated electromagnetic noises. The following countermeasures must be taken:</p> <ul style="list-style-type: none"> Install easily affected devices as far away as possible from the inverter or the converter unit. Run easily affected signal cables as far away as possible from the inverter or the converter unit, and their I/O cables. Do not run the signal cables and power cables (I/O cables of the inverter or the converter unit) in parallel with each other and do not bundle them. Set the EMC filter ON/OFF connector of the converter unit to the ON position. (Refer to page 51.) Inserting a line noise filter into the output suppresses the radiated noise from the cables. Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(d) (e) (f)	<p>When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises may be propagated to the signal cables to cause malfunction of the devices and the following countermeasures must be taken:</p> <ul style="list-style-type: none"> Install easily affected devices as far away as possible from the inverter or the converter unit. Run easily affected signal cables as far away as possible from the I/O cables of the inverter or the converter unit. Do not run the signal cables and power cables (I/O cables of the inverter or the converter unit) in parallel with each other and do not bundle them. Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(g)	<p>When the power supplies of the peripheral devices are connected to the power supply of the inverter or the converter unit in the same line, noises generated from the inverter or the converter unit may flow back through the power supply cables to cause malfunction of the devices and the following countermeasures must be taken:</p> <ul style="list-style-type: none"> Set the EMC filter ON/OFF connector of the converter unit to the ON position. (Refer to page 51.) Install the line noise filter to the power cables (output cables) of the inverter.
(h)	<p>When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter or the converter unit, leakage currents may flow through the earthing (grounding) cable of the inverter or the converter unit to cause the device to malfunction. In that case, disconnecting the earthing (grounding) cable from the device may stop the malfunction of the device.</p>

Electro-magnetic interference (EMI) and leakage currents


●Data line filter

Data line filter is effective as an EMI countermeasure. Provide a data line filter for the detector cable, etc.


<Example> Data line filter : ZCAT3035-1330 (by TDK)
 : ESD-SR-250 (by NEC TOKIN)
 Impedance (ZCAT3035-1330)

Impedance (Ω)	
10 to 100 MHz	100 to 500 MHz
80	150

The impedance values above are reference values, and not guaranteed values.



●EMI countermeasure example



NOTE

- For compliance with the EU EMC Directive, refer to [page 170](#).


3.1.3 Built-in EMC filter

The converter unit is equipped with a built-in EMC filter (capacitive filter).

The filter is effective in reducing air-propagated noise on the input side of the converter unit.

To enable the EMC filter, fit the EMC filter ON/OFF connector to the ON position. The filter is initially set to disabled (OFF). (For the FR-CC2-H400K or higher, two EMC filter ON/OFF connectors are provided. The both connectors are initially set to the "disabled" (OFF) position.)

To enable the EMC filter, fit the both EMC filter ON/OFF connectors to the ON position.)




<Switching ON/OFF the filter>

- Before removing a front cover, check to make sure that the indication of the inverter operation panel is OFF, wait for at least 10 minutes after the power supply has been switched OFF, and check that there is no residual voltage using a tester or the like.
- When disconnecting the connector, push the fixing tab and pull the connector straight without pulling the cable or forcibly pulling the connector with the tab fixed.

When installing the connector, also engage the fixing tab securely.

(If it is difficult to disconnect the connector, use a pair of needle-nose pliers, etc.)



NOTE

- Fit the connector to either ON or OFF position.
- Enabling (turning ON) the EMC filter increases leakage current. (Refer to [page 47.](#))

Warning

- While power is ON, do not open the front cover. Otherwise you may get an electric shock.

3.2 Power supply harmonics

3.2.1 Power supply harmonics

The inverter or the converter unit may generate power supply harmonics from its converter circuit to affect the power generator, power factor correction capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


- The differences between harmonics and noises

Item	Harmonics	Noise
Frequency	Normally 40th to 50th degrees or less (3 kHz or less).	High frequency (several 10 kHz to 1 GHz order).
Environment	To-electric channel, power impedance.	To-space, distance, wiring path,
Quantitative understanding	Theoretical calculation possible.	Random occurrence, quantitative grasping difficult.
Generated amount	Nearly proportional to the load capacity.	Changes with the current variation ratio. (Gets larger as switching speed increases.)
Affected equipment immunity	Specified by standards per equipment.	Different depending on maker's equipment specifications.
Countermeasure	Provide a reactor.	Increase distance.

- Countermeasures

The harmonic current generated from the inverter or the converter unit to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that this should be calculated in the conditions under the rated load at the maximum operating frequency.



*1 The converter unit (FR-CC2) is equipped with the DC reactor.

NOTE

- The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the input side of the inverter or the converter unit, or in the DC circuit.

3.2.2 Harmonic Suppression Guidelines

Harmonic currents flow from the inverter or the converter unit to a power receiving point via a power transformer. The Harmonic Suppression Guidelines was established to protect other consumers from these outgoing harmonic currents. The three-phase 200 V input specifications 3.7 kW or lower were previously covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" and other models were covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". However, the transistorized inverter has been excluded from the target products covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" in January 2004 and "the Harmonic Suppression Guideline for Household Appliances and General-purpose Products" was repealed on September 6, 2004.

All capacity and all models of general-purpose inverter used by specific consumers are now covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage" (hereinafter referred to as "the Specific Consumer Guidelines").


• "Specific Consumer Guidelines"

This guideline sets forth the maximum harmonic currents outgoing from a high-voltage or especially high-voltage receiving consumer who will install, add or renew harmonic generating equipment. If any of the maximum values is exceeded, this guideline requires that consumer to take certain suppression measures.

• Maximum values of outgoing harmonic currents per 1 kW contract power

Received power voltage	5th	7th	11th	13th	17th	19th	23rd	Over 23rd
6.6 kV	3.5	2.5	1.6	1.3	1.0	0.9	0.76	0.70
22 kV	1.8	1.3	0.82	0.69	0.53	0.47	0.39	0.36
33 kV	1.2	0.86	0.55	0.46	0.35	0.32	0.26	0.24

◆ Application of the specific consumer guidelines



• Conversion coefficient for the FR-A800 series

Classification	Circuit type		Conversion coefficient Ki
3	Three-phase bridge (Capacitor smoothing)	With reactor (DC side)*1	K33 = 1.8
		With reactors (AC, DC sides)*1	K34 = 1.4
5	Self-excitation three-phase bridge	When a high power factor converter is used	K5 = 0

• Equivalent capacity limits

Received power voltage	Reference capacity
6.6 kV	50 kVA
22/33 kV	300 kVA
66 kV or more	2000 kVA

3

Power supply harmonics

- Harmonic contents (values of the fundamental wave current is 100%)

Reactor	5th	7th	11th	13th	17th	19th	23rd	25th
Used (DC side)*1	30	13	8.4	5.0	4.7	3.2	3.0	2.2
Used (AC, DC sides)*1	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4

*1 The converter unit (FR-CC2) is equipped with the DC reactor on its DC side.

- Calculation of equivalent capacity P0 of harmonic generating equipment

"Equivalent capacity" is the capacity of a 6-pulse converter converted from the capacity of consumer's harmonic generating equipment and is calculated by the following equation: If the sum of equivalent capacities is higher than the limit (refer to [page 53](#)), harmonics must be calculated with the following procedure:

$$P_0 = \sum (K_i \times P_i) \text{ [kVA]}$$

K_i: Conversion coefficient (Refer to [page 53](#).)

P_i: Rated capacity of harmonic generating equipment*2 [kVA]

i: Number indicating the conversion circuit type

*2 Rated capacity: Determined by the capacity of the applied motor and found in the table below. The rated capacity used here is used to calculate the generated harmonic amount and is different from the power supply capacity required for actual inverter drive.

- Calculation of outgoing harmonic current

Outgoing harmonic current = fundamental wave current (value converted from received power voltage) × operation ratio × harmonic content

- Operation ratio: Operation ratio = actual load factor × operation time ratio during 30 minutes
- Harmonic content: Found in [page 54](#)

- Rated capacities and outgoing harmonic currents for inverter drive

Applicable motor (kW)	Rated current (A)	Fundamental wave current converted from 6.6 kV (mA)	Rated capacity (kVA)	Outgoing harmonic current converted from 6.6 kV (mA) (With a DC reactor, 100% operation ratio)							
	400 V			5th	7th	11th	13th	17th	19th	23rd	25th
75	123	7455	87.2	2237	969	626	373	350	239	224	164
90	147	8909	104	2673	1158	748	445	419	285	267	196
110	179	10848	127	3254	1410	911	542	510	347	325	239
132	216	13091	153	3927	1702	1100	655	615	419	393	288
160	258	15636	183	4691	2033	1313	782	735	500	469	344
220	355	21515	252	6455	2797	1807	1076	1011	688	645	473
250	403	24424	286	7327	3175	2052	1221	1148	782	733	537
280	450	27273	319	8182	3545	2291	1364	1282	873	818	600
315	506	30667	359	9200	3987	2576	1533	1441	981	920	675
355	571	34606	405	10382	4499	2907	1730	1627	1107	1038	761
400	643	38970	456	11691	5066	3274	1949	1832	1247	1169	857
450	723	43818	512	13146	5696	3681	2191	2060	1402	1315	964
500	804	48727	570	14618	6335	4093	2436	2290	1559	1462	1072
560	900	54545	638	16364	7091	4582	2727	2564	1746	1636	1200
630	1013	61394	718	18418	7981	5157	3070	2886	1965	1842	1351

- Determining if a countermeasure is required



A countermeasure for harmonics is required if the following condition is satisfied: outgoing harmonic current > maximum value per 1 kW contract power × contract power.

- Harmonic suppression techniques

No.	Item	Description
1	Reactor installation (FR-HAL)	With the DC reactor equipped on its DC side, the converter unit (FR-CC2) can suppress the outgoing harmonic current. Install an AC reactor (FR-HAL) on the AC side of the inverter to further suppress outgoing harmonic currents.
2	High power factor converter (FR-HC2)	This converter trims the current waveform to be a sine waveform by switching the rectifier circuit (converter module) with transistors. Doing so suppresses the generated harmonic amount significantly. Connect it to the DC area of an inverter. Use the high power factor converter (FR-HC2) with the accessories that come as standard.
3	Installation of power factor improving capacitor	When used with a reactor connected in series, the power factor improving correction capacitor can absorb harmonic currents.
4	Transformer multi-phase operation	Use two transformers with a phase angle difference of 30° as in λ - Δ and Δ - Δ combinations to provide an effect corresponding to 12 pulses, reducing low-degree harmonic currents.
5	Passive filter (AC filter)	A capacitor and a reactor are used together to reduce impedances at specific frequencies. Harmonic currents are expected to be absorbed greatly by using this technique.
6	Active filter (Active filter)	This filter detects the current in a circuit generating a harmonic current and generates a harmonic current equivalent to a difference between that current and a fundamental wave current to suppress the harmonic current at the detection point. Harmonic currents are expected to be absorbed greatly by using this technique.

3.3 Installation of a reactor

When the inverter is connected near a large-capacity power transformer (1000 kVA or more) or when a power factor correction capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an optional AC reactor (FR-HAL).



3.4 Power-OFF and magnetic contactor (MC)

◆ Converter unit input side magnetic contactor (MC)


On the converter unit input side, it is recommended to provide an MC for the following purposes:
(Refer to [page 14](#) for selection.)

- To disconnect the inverter from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.).
- To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure.
- To separate the inverter from the power supply to ensure safe maintenance and inspection work.

If using an MC for emergency stop during operation, select an MC regarding the converter unit input side current as JEM1038-AC-3 class rated current.

NOTE

- Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times), frequent starts and stops of the magnetic contactor must be avoided. Turn ON/OFF the inverter start controlling terminals (STF, STR) to run/stop the inverter.
- Inverter start/stop circuit example
As shown on the left, always use the start signal (ON or OFF of STF(STR) signal) to make a start or stop.



*1 When the power supply is 400 V class, install a stepdown transformer.
*2 Connect the power supply terminals R1/L11, S1/L21 of the control circuit to the input side of the MC to hold an alarm signal when the inverter's protective circuit is activated. At this time, remove jumpers across terminals R1/L11 and S1/L21. (Refer to [page 39](#) for removal of the jumper.)

◆ Handling of the magnetic contactor on the inverter's output side

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned ON while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided to switch to a commercial power supply, for example, it is recommended to use the commercial power supply-inverter switchover function **Pr.135 to Pr.139**. (The commercial power supply operation is not available with vector control dedicated motors nor with PM motors.)

◆ Handling of the manual contactor on the inverter's output side

A PM motor is a synchronous motor with high-performance magnets embedded inside. High-voltage is generated at the motor terminals while the motor is running even after the inverter power is turned OFF. In an application where the PM motor is driven by the load even after the inverter is powered OFF, a low-voltage manual contactor must be connected at the inverter's output side.

NOTE

- Before wiring or inspection for a PM motor, confirm that the PM motor is stopped. In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual contactor must be connected at the inverter's output side, and wiring and inspection must be performed while the contactor is open. Otherwise you may get an electric shock.
- Do not open or close the contactor while the inverter is running (outputting).

3.5 Checklist before starting operation

The FR-CC2 converter unit is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following points.

Checkpoint	Countermeasure	Refer to page	Check by user
Crimping terminals are insulated.	Use crimping terminals with insulation sleeves to wire the power supply and the inverter.	—	
No wire offcuts are left from the time of wiring.	Wire offcuts can cause an alarm, failure or malfunction. Always keep the converter unit clean. When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the converter unit.	—	
The main circuit cable gauge is correctly selected.	Use an appropriate cable gauge to suppress the voltage drop to 2% or less.	30	
The total wiring length is within the specified length.	Keep the total wiring length within the specified length. In long distance wiring, charging currents due to stray capacitance in the wiring may cause the equipment on the converter unit's output side to malfunction. Pay attention to the total wiring length.	30	
Countermeasures are taken against EMI.	The input/output (main circuit) of the converter unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the converter unit. In such case, activate the EMC filter (turn ON the EMC filter ON/OFF connector) to minimize interference.	51	
When performing an inspection or rewiring on the product that has been energized, the operator has waited long enough after shutting off the power supply.	For a short time after the power-OFF, a high voltage remains in the smoothing capacitor, and it is dangerous. Before performing an inspection or rewiring, wait 10 minutes or longer after the power supply turns OFF, then confirm that the voltage across the main circuit terminals P/+ and N/- of the converter unit is low enough using a tester, etc.	—	
The voltage applied to the converter unit I/O signal circuits is within the specifications.	Application of a voltage higher than the permissible voltage to the converter unit I/O signal circuits or opposite polarity may damage the I/O devices. Check the wiring beforehand.	32	
A magnetic contactor (MC) is installed on the converter unit's input side.	On the converter unit's input side, connect an MC for the following purposes: • To disconnect the converter unit from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.). • To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure. • To separate the converter unit from the power supply to ensure safe maintenance and inspection work. If using an MC for emergency stop during operation, select an MC regarding the converter unit input side current as JEM1038-AC-3 class rated current.	56	
The specifications and rating match the system requirements.	Make sure that the specifications and rating match the system requirements.	—	
The converter unit and the inverter are correctly connected.	• Make sure that the terminal P/+ of the converter unit and the terminal P/+ of the inverter, and the terminal N/- of the converter unit and the terminal N- of the inverter are correctly connected. Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter. Also, do not install an MCCB across the terminals P/+ and N/- (across terminals P and P/+ or across N and N/-). • Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE of the converter unit and the terminal SD (terminal PC for source logic) of the inverter. Not connecting these terminals may damage the converter unit.	27	

4 **BASIC OPERATION**


This chapter explains the "BASIC OPERATION" of this product.
Always read the instructions before using the equipment.














4.1	Operation panel (FR-DU08)	60
4.2	Monitoring the converter unit status	64

4.1 Operation panel (FR-DU08)

4.1.1 Components of the operation panel (FR-DU08)


To mount the operation panel (FR-DU08) on the enclosure surface, refer to [page 42](#).



No.	Component	Name	Description
(a)		—	Not used.
(b)		Operation panel status indicator	MON: ON to indicate the monitor mode. Quickly flickers twice intermittently while the protective function is activated. Slowly flickers in the display-off mode. PRM: ON to indicate the parameter setting mode.
(c)		—	Not used.
(d)		—	Not used.
(e)		Monitor (5-digit LED)	Shows the monitored status, parameter number, etc. (Using Pr.774 to Pr.776 , the monitored item can be changed.)
(f)		—	Not used.
(g)		—	Not used.
(h)		STOP/RESET key	Resets the converter unit when the protective function is activated.
(i)		Setting dial	Changes the parameter settings. Press the setting dial to perform the following operations: · To display a monitored item set in Pr.992 · To display a fault history number in the faults history mode
(j)		MODE key	Switches to different modes. Holding this key for 2 seconds locks the operation. The key lock is invalid when Pr.161="0" (initial setting). (Refer to page 77 .)
(k)		SET key	Enters each setting. If pressed during the operation, monitored item changes as the following: (Using Pr.774 to Pr.776 , the monitored item can be changed.) When the initial setting is set <div style="display: flex; align-items: center; gap: 10px;"> Converter output voltage → Input current → Electric thermal relay function load factor </div>
(l)		ESC key	Goes back to the previous display. Holding this key for a long time changes the mode back to the monitor mode.
(m)		—	Not used.

4.1.2 Basic operation of the operation panel

◆ Basic operation



*1 Monitored items can be changed. (Refer to [page 86](#).)

*2 For the details of faults history, refer to [page 142](#).

◆Parameter setting mode

In the parameter setting mode, converter unit functions (parameters) are set. The following table explains the indications in the parameter setting mode.

Operation panel indication	Function name	Description	Refer to page
P.	Parameter setting mode	Under this mode, the set value of the displayed parameter number is read or changed.	63
PrCLR	Parameter clear	Clears and resets parameter settings to the initial values. However, parameters such as terminal function selection parameters are not cleared. For the details of the uncleared parameters, refer to page 168 .	132
ALLCL	All parameter clear	Clears and resets parameter settings to the initial values. Terminal function selection parameters are also cleared. For the details of the uncleared parameters, refer to page 168 .	132
ErrCL	Faults history clear	Deletes the faults history.	139
PrCPY	Parameter copy	Copies the parameter settings saved in the converter unit to the operation panel. The parameters copied to the operation panel can be also copied to other converter units.	133
PrCHG	Initial value change list	Identifies the parameters that have been changed from their initial settings.	136
PrMd	Group parameter setting	Displays parameter numbers by function groups.	69










4.1.3 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

0	1	2	3	4	5	6	7	8	9	A	B(b)	C	c	D(d)
0	1	2	3	4	5	6	7	8	9	A	b	C	c	d
E(e)	F(f)	G(g)	H	h	I(i)	J(j)	K(k)	L(l)	M(m)	N	n	O	o	P(p)
E	F	G	H	h	I	J	K	L	M	N	n	O	o	P
Q(q)	R	r	S(s)	T(t)	U	u	V	v	W	w	X(x)	Y(y)	Z(z)	
Q	R	r	S	T	U	u	V	v	W	w	X	Y	Z	

4.1.4 Changing the parameter setting value

Changing example Change Pr.774 Operation panel monitor selection 1.

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press  to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number Turn  until P. 774 (Pr.774) appears. Press  to read the present set value. "9999" (initial value) appears.
4.	Changing the setting value Turn  to change the set value to "2". Press  to enter the setting. "2" and "P. 774" flicker alternately. <ul style="list-style-type: none"> ·Turn  to read another parameter. ·Press  to show the setting again. ·Press  twice to show the next parameter. ·Press  twice to return to the monitor display of the converter output voltage.

NOTE

- **Er-1** is displayed... Why?
 - **Er-1** appears... Write disable error
- For the details, refer to [page 142](#).

4.2 Monitoring the converter unit status

4.2.1 Monitoring of converter output voltage and input current

POINT

- Pressing in the monitor mode switches the monitored item to converter output voltage, input current, and then to electronic thermal relay function load factor.

		Operation
1.	Press <input type="button" value="MODE"/>	to monitor the converter output voltage. [V] appears.
2.	Press <input type="button" value="SET"/>	to monitor the input current. [A] appears.
3.	Press <input type="button" value="SET"/>	to monitor the electronic thermal relay function load factor.

NOTE

- Use Pr.774 to Pr.776 Operation panel monitor selection 1 to 3 to change the monitored items. (Refer to [page 86](#).)

4.2.2 First monitored item

The first monitored item to be displayed in the monitor mode is selectable.

To set a monitored item as the first monitored item, display a monitored item, and press for a while.

Set the input current as the first monitored item.

		Operation
1.	Select the monitor mode, and select the input current.	
2.	Press <input type="button" value="SET"/>	for a while (1 s). The input current is set as the first monitored item.
3.	When the monitor mode is selected next time, the input current is monitored first.	

NOTE

- Use Pr.774 Operation panel monitor selection 1 to change the monitored item. (Refer to [page 86](#).)

5 **PARAMETER**

**This chapter explains the function setting for use of this product.
Always read the instructions before using the equipment.**

5.1 Parameter list

5.1.1 Parameter list (by parameter number)

Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be performed from the operation panel.



- Refer to Appendix1 (page 168) for instruction codes for communication and availability of parameter clear, all clear, and parameter copy of each parameter.

Pr.	Pr. group	Name	Setting range	Minimum setting increments	Initial value	Refer to page	Customer setting
30	E300	Reset selection during power supply to main circuit	0, 100	1	0	96	
57	A702	Restart selection	0, 9999	1	9999	98	
65	H300	Retry selection	0 to 4	1	0	84	
67	H301	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0	84	
68	H302	Retry waiting time	0.1 to 600 s	0.1 s	1 s	84	
69	H303	Retry count display erase	0	1	0	84	
75	-	Reset selection/disconnected PU detection/reset limit	14 to 17, 114 to 117	1	14	75	
	E100	Reset selection	0, 1		0		
	E101	Disconnected PU detection					
	E107	Reset limit					
77	E400	Parameter write selection	1, 2	1	2	77	
117	N020	PU communication station number	0 to 31	1	0	106	
118	N021	PU communication speed	48, 96, 192, 384, 576, 768, 1152	1	192	106	
119	-	PU communication stop bit length / data length	0, 10	1	1	106	
	N022	PU communication data length	0, 1		0		
	N023	PU communication stop bit length	0, 1		1		
120	N024	PU communication parity check	0 to 2	1	2	106	
121	N025	Number of PU communication retries	0 to 10, 9999	1	1	106	
122	N026	PU communication check time interval	0, 0.1 to 999.8 s, 9999	0.1 s	9999	106	
123	N027	PU communication waiting time setting	0 to 150 ms, 9999	1 ms	9999	106	
124	N028	PU communication CR/LF selection	0 to 2	1	1	106	
161	E200	Key lock operation selection	0, 10	1	0	77	
168	E000	Parameter for manufacturer setting.					
	E080						
	E001						
	E081						
170	M020	Watt-hour meter clear	0, 10, 9999	1	9999	86	
178	T700	RDI terminal function selection	7, 62, 9999	1	9999	94	
187	T709	OH terminal function selection		1	7	94	
189	T711	RES terminal function selection		1	62	94	
190	M400	RDB terminal function selection		1	111	90	
191	M401	RDA terminal function selection	2, 8, 11, 17, 25, 26, 64, 68, 90, 94, 95, 98, 99, 102, 108, 111, 125, 126, 164, 168, 190, 194, 195, 198, 199, 206, 207, 209, 210, 214, 306, 307, 309, 310, 9999	1	11	90	
192	M402	IPF terminal function selection		1	2	90	
193	M403	RSO terminal function selection		1	209	90	
194	M404	FAN terminal function selection		1	25	90	
195	M405	ABC1 terminal function selection		1	99	90	
248	A006	Self power management selection		0, 1, 2	1	0	96
255	E700	Life alarm status display	(0 to 15)	1	0	80	
256	E701	Inrush current limit circuit life display	(0 to 100%)	1%	100%	80	

Pr.	Pr. group	Name	Setting range	Minimum setting increments	Initial value	Refer to page	Customer setting	
257	E702	Control circuit capacitor life display	(0 to 100%)	1%	100%	80		
261	A730	Power failure stop selection	0, 1, 2, 21, 22	1	0	99		
268	M022	Monitor decimal digits selection	0, 1, 9999	1	9999	86		
269	E023	Parameter for manufacturer setting. Do not set.						
290	M044	Monitor negative output selection	0, 2, 4, 6	1	0	86		
296	E410	Password lock level	0 to 3, 5, 6, 100 to 103, 105, 106, 9999	1	9999	78		
297	E411	Password lock/unlock	(0 to 5), 1000 to 9998, 9999	1	9999	78		
331	N030	RS-485 communication station number	0 to 31 (0 to 247)	1	0	106, 119		
332	N031	RS-485 communication speed	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152	1	96	106, 119		
333	-	RS-485 communication stop bit length / data length	0, 1, 10, 11	1	1	106		
	N032	RS-485 communication data length	0, 1	1	0			
	N033	RS-485 communication stop bit length	0, 1	1	1			
334	N034	RS-485 communication parity check selection	0 to 2	1	2	106, 119		
335	N035	RS-485 communication retry count	0 to 10, 9999	1	1	106		
336	N036	RS-485 communication check time interval	0 to 999.8 s, 9999	0.1 s	0 s	106		
337	N037	RS-485 communication waiting time setting	0 to 150 ms, 9999	1 ms	9999	106		
341	N038	RS-485 communication CR/LF selection	0 to 2	1	1	106		
342	N001	Communication EEPROM write selection	0, 1	1	0	105		
343	N080	Communication error count	-	1	0	119		
503	E710	Maintenance timer 1	0 (1 to 9998)	1	0	82		
504	E711	Maintenance timer 1 warning output set time	0 to 9998, 9999	1	9999	82		
539	N002	Modbus-RTU communication check time interval	0 to 999.8 s, 9999	0.1 s	9999	119		
549	N000	Protocol selection	0, 1	1	0	105, 119		
563	M021	Energization time carrying-over times	(0 to 65535)	1	0	86		
598	H102	Undervoltage level	350 to 430 V, 9999	0.1 V	9999	83		
663	M060	Control circuit temperature signal output level	0 to 100°C	1°C	0°C	93		
686	E712	Maintenance timer 2	0 (1 to 9998)	1	0	82		
687	E713	Maintenance timer 2 warning output set time	0 to 9998, 9999	1	9999	82		
688	E714	Maintenance timer 3	0 (1 to 9998)	1	0	82		
689	E715	Maintenance timer 3 warning output set time	0 to 9998, 9999	1	9999	82		
774	M101	Operation panel monitor selection 1	2, 8, 13, 20, 25, 43, 44, 55, 62, 98, 9999	1	9999	86		
775	M102	Operation panel monitor selection 2		1	9999	86		
776	M103	Operation panel monitor selection 3		1	9999	86		
872	H201	Input phase loss protection selection	0, 1	1	0	84		
876	T723	OH input selection	0 to 2	1	0	95		
888	E420	Free parameter 1	0 to 9999	1	9999	80		
889	E421	Free parameter 2	0 to 9999	1	9999	80		
891	M023	Cumulative power monitor digit shifted times	0, 4, 9999	1	9999	86		
990	E104	PU buzzer control	0, 1	1	1	76		
992	M104	Operation panel setting dial push monitor selection	2, 8, 13, 20, 25, 43, 44, 55, 62, 98	1	8	86		
997	H103	Fault initiation	0 to 255, 9999	1	9999	83		
1006	E020	Clock (year)	2000 to 2099	1	2000	73		
1007	E021	Clock (month, day)	1/1 to 12/31	1	101	73		

Pr. List

5

Parameter list

Parameter list (by parameter number)

Pr.	Pr. group	Name	Setting range	Minimum setting increments	Initial value	Refer to page	Customer setting
1008	E022	Clock (hour, minute)	0:00 to 23:59	1	0	73	
1048	E106	Display-off waiting time	0 to 60 minutes	1 minutes	0	76	
	Pr.CLR	Parameter clear	(0), 1	1	0	132	
	ALL.CL	All parameter clear	(0), 1	1	0	132	
	Err.CL	Fault history clear	(0), 1	1	0	132	
	Pr.CPY	Parameter copy	(0), 1 to 3	1	0	133	
	Pr.CHG	Initial value change list	-	1	0	136	
	Pr.MD	Group parameter setting	(0), 1, 2	1	0	69	

5.1.2 Parameter display by function group

The monitor display can be changed to the parameter display by function group.
Parameter numbers are displayed by function group. The related parameters can be set easily.

◆ Changing to the grouped parameter numbers

Pr.MD setting value	Description
0	Default parameter display method
1	Parameter display by parameter number
2	Parameter display by function group

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number Turn until Pr.MD (parameter display method) appears. Press SET . "0" (initial value) will appear.
4.	Changing to the group parameter display Turn to change the set value to "2" (Parameter display by function group). Press SET to select the parameter setting by function group "2" and "Pr.MD" flicker alternately after the setting is completed.

◆ Changing parameter settings in the group parameter display

Changing example Change the **P.M101 (Pr.774) Operation panel monitor selection 1**.

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Parameter group selection Press PRG several times until ESC appears. Parameter groups can now be selected.
4.	Parameter group selection Turn until PM 1 (monitor parameter 1) appears. Press SET to display "PM 1--" and make the group parameters of the monitor parameter 1 selectable.
5.	Parameter selection Turn until PM 10 1 (P.M101 Operation panel monitor selection 1) appears. Press SET to read the present set value. "9999" (initial value) appears.
6.	Changing the setting value Turn to change the set value to "2". Press SET to enter the setting. "2" and "PM 10 1" flicker alternately after the setting is completed.

5.1.3 Parameter list (by function group)

◆(E) Environment setting parameters

Parameters that set the converter unit operation characteristics.

Pr. group	Pr.	Name	Refer to page
E000	168	Parameter for manufacturer setting. Do not set.	
E001	169	Parameter for manufacturer setting. Do not set.	
E020	1006	Clock (year)	73
E021	1007	Clock (month, day)	73
E022	1008	Clock (hour, minute)	73
E023	269	Parameter for manufacturer setting. Do not set.	
E080	168	Parameter for manufacturer setting.	
E081	169	Parameter for manufacturer setting.	
E100	75	Reset selection	75
E101	75	Disconnected PU detection	75
E104	990	PU buzzer control	76
E106	1048	Display-off waiting time	76
E107	75	Reset limit	75
E200	161	Key lock operation selection	77
E300	30	Reset selection during power supply to main circuit	96
E400	77	Parameter write selection	77
E410	296	Password lock level	78
E411	297	Password lock/unlock	78
E420	888	Free parameter 1	80
E421	889	Free parameter 2	80
E700	255	Life alarm status display	80
E701	256	Inrush current limit circuit life display	80
E702	257	Control circuit capacitor life display	80
E710	503	Maintenance timer 1	82
E711	504	Maintenance timer 1 warning output set time	82
E712	686	Maintenance timer 2	82
E713	687	Maintenance timer 2 warning output set time	82
E714	688	Maintenance timer 3	82
E715	689	Maintenance timer 3 warning output set time	82

◆(H) Protective function parameters

Parameters to protect the converter unit.

Pr. group	Pr.	Name	Refer to page
H102	598	Undervoltage level	83
H103	997	Fault initiation	83
H201	872	Input phase loss protection selection	84
H300	65	Retry selection	84
H301	67	Number of retries at fault occurrence	84
H302	68	Retry waiting time	84
H303	69	Retry count display erase	84

◆(M) Monitor display and monitor output signal

Parameters regarding the converter unit's operating status. These parameters are used to set the monitors and output signals.

Pr. group	Pr.	Name	Refer to page
M020	170	Watt-hour meter clear	86
M021	563	Energization time carrying-over times	86
M022	268	Monitor decimal digits selection	86
M023	891	Cumulative power monitor digit shifted times	86
M044	290	Monitor negative output selection	86
M060	663	Control circuit temperature signal output level	93
M101	774	Operation panel monitor selection 1	86
M102	775	Operation panel monitor selection 2	86
M103	776	Operation panel monitor selection 3	86
M104	992	Operation panel setting dial push monitor selection	86
M400	190	RDB terminal function selection	90
M401	191	RDA terminal function selection	90
M402	192	IPF terminal function selection	90
M403	193	RSO terminal function selection	90
M404	194	FAN terminal function selection	90
M405	195	ABC1 terminal function selection	90

◆(T) Multi-function input terminal parameters

Parameters for the input terminals where converter unit commands are received through.

Pr. group	Pr.	Name	Refer to page
T700	178	RDI terminal function selection	94
T709	187	OH terminal function selection	94
T711	189	RES terminal function selection	94

◆(A) Application parameters

Parameters to set a specific application.

Pr. group	Pr.	Name	Refer to page
A006	248	Self power management selection	96
A702	57	Restart selection	98
A730	261	Power failure stop selection	99

◆(N) Operation via communication and its settings

Parameters for communication operation. These parameters set the communication specifications and operation.

Pr. group	Pr.	Name	Refer to page
N000	549	Protocol selection	105, 119
N001	342	Communication EEPROM write selection	105
N002	539	Modbus-RTU communication check time interval	119
N020	117	PU communication station number	106
N021	118	PU communication speed	106
N022	119	PU communication data length	106
N023	119	PU communication stop bit length	106
N024	120	PU communication parity check	106
N025	121	Number of PU communication retries	106
N026	122	PU communication check time interval	106
N027	123	PU communication waiting time setting	106
N028	124	PU communication CR/LF selection	106
N030	331	RS-485 communication station number	106, 119
N031	332	RS-485 communication speed	106, 119
N032	333	RS-485 communication data length	106
N033	333	RS-485 communication stop bit length	106
N034	334	RS-485 communication parity check selection	106, 119
N035	335	RS-485 communication retry count	106
N036	336	RS-485 communication check time interval	106
N037	337	RS-485 communication waiting time setting	106
N038	341	RS-485 communication CR/LF selection	106
N080	343	Communication error count	105

5.2 (E) Environment setting parameters

Purpose	Parameter to set			Refer to page
To set the time	Real time clock function	P.E020 to P.E022	Pr.1006 to Pr.1008	73
To set a limit for the reset function. To shut off output if the operation panel disconnects.	Reset selection / disconnected PU detection / reset limit	P.E100, P.E101, P.E107	Pr.75	75
To control the buzzer of the operation panel	PU buzzer control	P.E104	Pr.990	76
To turn OFF the operation panel when not using it for a certain period of time	Display-off mode	P.E106	Pr.1048	76
To disable the operation panel.	Operation panel operation selection	P.E200	Pr.161	77
To prevent parameter rewriting	Parameter write disable selection	P.E400	Pr.77	77
To restrict parameters with a password	Password function	P.E410, P.E411	Pr.296, Pr.297	78
To use parameters freely	Free parameter	P.E420, P.E421	Pr.888, Pr.889	80
To understand the maintenance time of converter unit parts and peripheral devices	Converter unit parts life display	P.E700 to P.E702	Pr.255 to Pr.257	80
	Maintenance output function	P.E710 to P.E715	Pr.503, Pr.504, Pr.686 to Pr.689	82

5.2.1 Real time clock function

The time can be set. The time can only be updated while the converter unit power is ON.

The real time clock function is enabled using an optional LCD operation panel (FR-LU08).

Pr.	Name	Initial value	Setting range	Description
1006 E020	Clock (year)	2000	2000 to 2099	Set the year.
1007 E021	Clock (month, day)	101 (January 1)	101 to 131, 201 to 228, (229), 301 to 331, 401 to 430, 501 to 531, 601 to 630, 701 to 731, 801 to 831, 901 to 930, 1001 to 1031, 1101 to 1130, 1201 to 1231	Set the month and day. 1000 and 100 digits: January to December 10 and 1 digits: 1 to the end of month (28, 29, 30 or 31) For December 31, set "1231".
1008 E022	Clock (hour, minute)	0 (00:00)	0 to 59, 100 to 159, 200 to 259, 300 to 359, 400 to 459, 500 to 559, 600 to 659, 700 to 759, 800 to 859, 900 to 959, 1000 to 1059, 1100 to 1159, 1200 to 1259, 1300 to 1359, 1400 to 1459, 1500 to 1559, 1600 to 1659, 1700 to 1759, 1800 to 1859, 1900 to 1959, 2000 to 2059, 2100 to 2159, 2200 to 2259, 2300 to 2359	Set the hour and minute using the 24-hour clock. 1000 and 100 digits: 0 to 23 hours 10 and 1 digits: 0 to 59 minutes For 23:59, set "2359".

◆ Simple clock function

- When the year, month, day, time and minute are set in the parameters, the converter unit counts the date and time. The date and time can be checked by reading the parameters.

NOTE


- The clock's count-up data is saved in the inverter's EEPROM every 10 minutes.
- The clock does not count up while the control circuit power supply is OFF. The clock function must be reset after turning ON the power supply. Use a separate power supply, such as an external 24 V power supply, for the control circuit of the simple clock function, and supply power continuously to this control circuit.
- Converter reset is performed if supplying power to the main circuit power supply is started with power supplied only to the control circuit power supply. Thus, the clock information stored in the EEPROM is restored. Reset at the start of supplying power to the main circuit can be disabled by setting **Pr.30 Reset selection during power supply to main circuit**. (Refer to [page 96](#))
- The set clock is also used for functions such as faults history.

(E) Environment setting parameters

◆ Real time clock function

- When the FR-LU08 is connected to the inverter, the clock of FR-LU08 is synchronized with the internal clock of the inverter. (Real time clock function)

With a battery (CR1216), the FR-LU08 time count continues even if the main power of the inverter is turned OFF. (The time count of the inverter internal clock does not continue when the inverter power is turned OFF.)



- When the time is set using the inverter parameters, the time of FR-LU08 is set to the time of inverter internal clock.

NOTE

- Time adjustment between the inverter internal clock and the FR-LU08 is performed every one minute.
- When the time of FR-LU08 is faster than the time of inverter internal clock, the FR-LU08 time setting is valid.
- When the FR-LU08 clock is initialized, the inverter internal clock is valid.

5.2.2 Reset selection / disconnected PU detection / reset limit

The reset input acceptance, the disconnected operation panel (FR-DU08) connector detection function, and the reset limit function can be selected.

Pr.	Name	Initial value	Setting range	Description
75	Reset selection/disconnected PU detection/reset limit	14	14 to 17, 114 to 117	For the initial setting, reset is always enabled, PU disconnection is not detected, and the reset limit function is disabled.
E100	Reset selection	0	0	Reset input is always enabled.
			1	Reset input is enabled only when the protective function is activated.
E101	Disconnected PU detection	0	0	Operation continues even when the PU is disconnected.
			1	The inverter output is shut off when the PU is disconnected.
E107	Reset limit	0	0	Reset limit is disabled.
			1	Reset limit is enabled.

The parameters above will not return to their initial values even if parameter (all) clear is executed.

Pr.75 Setting value	Reset selection	Disconnected PU detection	Reset limit function
14 (initial value)	Reset input always enabled	Operation continues even when PU is disconnected.	Invalid
15	Reset input enabled only when the protective function activated.		
16	Reset input always enabled		
17	Reset input enabled only when the protective function activated.	Inverter output shut off when PU is disconnected.	Enabled
114	Reset input always enabled	Operation continues even when PU is disconnected.	
115	Reset input enabled only when the protective function activated.		
116	Reset input always enabled	Inverter output shut off when PU is disconnected.	
117	Reset input enabled only when the protective function activated.		

◆ Reset selection (P.E100)

- When **P.E100**="1" or **Pr.75**="15, 17, 115, or 117", reset (reset command via RES signal or communication) input is enabled only when the protective function is activated.

NOTE

- When the reset signal (RES) is input during operation, the inverter is also reset. The motor coasts since the inverter being reset shuts off the output. Also, the cumulative value of electronic thermal O/L relay is cleared.
- The input of the PU reset key is only enabled when the protective function is activated, regardless of the **P.E100** and **Pr.75** settings.

◆ Disconnected PU detection (P.E101)

- If the PU (FR-DU08) is detected to be disconnected from the converter unit for 1 s or longer while **P.E101**="1" or **Pr.75**="16, 17, 116 or 117", PU disconnection (E.PUE) is displayed and the inverter output is shut off.

NOTE

- When the PU has been disconnected since before power-ON, the output is not shut off.
- To restart, confirm that the PU is connected and then reset.
- When RS-485 communication operation is performed through the PU connector, the reset selection is valid but the disconnected PU detection function is invalid. (The communication is checked according to **Pr.122 PU communication check time interval**.)

(E) Environment setting parameters

◆ Reset limit function (P.E107)

- Setting **P.E107="1"** or **Pr.75 = any of "114 to 117"** will make the inverter to refuse any reset operation (RES signal, etc.) for 3 minutes after the first activation of an electronic thermal function (E.THC).


NOTE

- Resetting the converter unit power (turning OFF the control power) will clear the accumulated thermal value.
- When the retry function is set enabled (**Pr.67 Number of retries at fault occurrence** ≠ "0"), the reset limit function is disabled.

⚠ Caution

- Do not perform a reset while an inverter start signal is being input. Doing so will cause a sudden start of the motor, which is dangerous.**

Parameters referred to

Pr.67 Number of retries at fault occurrence  [page 84](#)

5.2.3 Buzzer control

- The buzzer can be set to "beep" when the keys of the operation panel (FR-DU08) are operated.

Pr.	Name	Initial value	Setting range	Description
990 E104	PU buzzer control	1	0	Without buzzer
			1	With buzzer

NOTE

- When with buzzer is set, the buzzer sounds if a converter unit fault occurs.

5.2.4 Display-off mode

- The LED of the operation panel can be turned OFF when it has not been used for a certain period of time.



Pr.	Name	Initial value	Setting range	Description
1048 E106	Display-off waiting time	0	0	Display-off mode is disabled.
			1 to 60 minutes	Set time until the LED of the operation panel is turned OFF.

- If the operation panel has not been operated for the time set in **Pr.1048**, the display-off mode is enabled and its LED is turned OFF.
- In the display-off mode, the "MON" LED flickers slowly.
- The count to display off is reset to "0" to restart at installation/removal of the operation panel, power-ON/OFF of the converter unit, or converter reset.
- Display-off mode end condition
 - Operation of the operation panel
 - Occurrence of a warning, alarm, or fault
 - Installation/removal of the operation panel, power-ON/OFF of the converter unit, or converter reset


5.2.5 Setting dial key lock operation selection

The key operation of the operation panel can be disabled.

Pr.	Name	Initial value	Setting range	Description
161 E200	Key lock operation selection	0	0	Key lock mode disabled
			10	Key lock mode enabled

- Operation using the setting dial and keys of the operation panel can be disabled to prevent unexpected parameter changes.
- Set **Pr.161** to "10" and then press  for 2 s to disable setting dial or key operations.
- When setting dial and key operations are disabled, *HOLD* appears on the operation panel. If setting dial or key operation is attempted while dial and key operations are disabled, *HOLD* appears. (When a setting dial or key operation is not performed for 2 s, the monitor display appears.)
- To enable the setting dial and key operation again, press  for 2 s.

NOTE

- Even if setting dial and key operations are disabled, the monitor indicator and  are enabled.

5.2.6 Parameter write selection

Whether to enable the writing to various parameters or not can be selected. Use this function to prevent parameter values from being rewritten by misoperation.

Pr.	Name	Initial value	Setting range	Description
77 E400	Parameter write selection	2	1	Parameter writing is disabled.
			2	Parameter writing is enabled.

- **Pr.77** can be set at any time. (Setting through communication is unavailable.)

◆ Disabling parameter write (Pr.77="1")

- Parameter write, parameter clear and all parameter clear are disabled. (Parameter read is enabled.)
- The following parameters can be written even if **Pr.77**="1".

Pr.	Name
75	Reset selection/disconnected PU detection/ reset limit
77	Parameter write selection
296	Password lock level
297	Password lock/unlock
997	Fault initiation

◆ Writing parameters (Pr.77="2")

- These parameters can always be written.

5.2.7 Password function

Registering a 4-digit password can restrict parameter reading/writing.

Pr.	Name	Initial value	Setting range	Description
296 E410	Password lock level	9999	0 to 3, 5, 6, 100 to 103, 105, 106	Select restriction level of parameter reading/writing when a password is registered.
			9999	No password lock
297 E411	Password lock/unlock	9999	1000 to 9998	Register a 4-digit password.
			(0 to 5) *1	Displays password unlock error count. (Reading only) (Valid when Pr.296 = "100 to 103, 105 or 106")
			9999 *1	No password lock

*1 When Pr.297="0, 9999", writing is always enabled, but setting is disabled. (The display cannot be changed.)

◆Parameter reading/writing restriction level (Pr.296)

- The level of the reading/writing restriction using the operation panel or via RS-485 communication can be selected with Pr.296.

Pr.296 setting	Operation panel		RS-485 communication	
	Read	Write*1	Read	Write*1
9999	○	○	○	○
0, 100	×	×	×	×
1, 101	○	×	○	×
2, 102	○	×	○	○
3, 103	○	○	○	×
5, 105	×	×	○	○
6, 106	○	○	×	×

○: Enabled, ×: Disabled

*1 If the parameter writing is restricted by the Pr.77 Parameter write selection setting, those parameters are unavailable for writing even when "○" is indicated.

◆Registering a password (Pr.296, Pr.297)

- The following section describes how to register a password.
 - Set the parameter reading/writing restriction level. (Pr.296 ≠ "9999")

Pr.296 setting	Password unlock error restriction	Pr.297 display
0 to 3, 5, 6	No restriction	Always displays 0
100 to 103, 105, 106*1	Restricted at fifth error	Displays the error count (0 to 5)

*1 During Pr.296= any of "100 to 103, 105 or 106", if password unlock error has occurred five times, correct password will not unlock the restriction. All parameter clear can unlock the restriction. (In this case, the parameters are returned to their initial values.)

- Write a four-digit number (1000 to 9998) to Pr.297 as a password. Writing is disabled when Pr.296 = "9999".) When a password is registered, parameter reading/writing is restricted with the restriction level set in Pr.296 until unlocking.

NOTE

- After registering a password, the read value of Pr.297 is always one of "0" to "5".
- LOCd appears when a password restricted parameter is read/written.
- Even if a password is registered, the parameters, which the converter unit itself writes, such as converter unit parts life are overwritten as needed.

◆ Unlocking a password (Pr.296, Pr.297)

- There are two ways of unlocking the password.
- Enter the password in **Pr.297**. If the password matches, it unlocks. If the password does not match, an error occurs and the password does not unlock. During **Pr.296** = any of "100 to 103, 105 or 106", if password unlock error has occurred five times, correct password will not unlock the restriction. (Password lock in operation.)
- Perform all parameter clear.

NOTE

- If the password is forgotten, it can be unlocked with all parameter clear, but doing so will also clear the other parameters.
- All parameter clear cannot be performed during the operation.
- For the all parameter clear method, refer to the following.
(For the operation panel (FR-DU08), refer to [page 132](#) for the Mitsubishi inverter protocol of RS-485 communication, refer to [page 108](#), and for the Modbus-RTU communication protocol, refer to [page 119](#).)

◆ Parameter operations during password locking/unlocking

Operation	Password unlocked		Password locked	Password lock in operation
	Pr.296 = 9999 Pr.297 = 9999	Pr.296 ≠ 9999 Pr.297 = 9999	Pr.296 ≠ 9999 Pr.297 = 0 to 4 (read value)	Pr.296 = 100 to 103, 105, 106 Pr.297 = 5 (read value)
Pr.296	Read	○	○	○
	Write	○	○	×
Pr.297	Read	○	○	○
	Write	×	○	○*1
Parameter clear execution	○	○	×	×
All parameter clear execution	○	○	○	○
Parameter copy execution	○	○	×	×


○: Enabled, ×: Disabled

*1 Correct password will not unlock the restriction.

NOTE

- When the password is being locked, parameter copy using the operation panel (FR-DU08) is not enabled.

Parameters referred to

Pr.77 Parameter write selection  [page 77](#)

5.2.8 Free parameter

Any number within the setting range of 0 to 9999 can be input.

For example, these numbers can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Pr.	Name	Initial value	Setting range	Description
888 E420	Free parameter 1	9999	0 to 9999	Any value can be input. The settings are retained even if the converter unit power is turned OFF.
889 E421	Free parameter 2	9999	0 to 9999	

NOTE

- Pr.888 and Pr.889 do not influence the operation of the converter unit.

5.2.9 Converter unit parts life display

The degree of deterioration of the control circuit capacitor, cooling fan, and inrush current limit circuit can be diagnosed on the monitor.


When a part approaches the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Note that the life diagnosis of this function should be used as a guideline only, because the life values are theoretical calculations.)

Pr.	Name	Initial value	Setting range	Description
255 E700	Life alarm status display	0	(0 to 15)	Displays whether or not the parts of the control circuit capacitor, cooling fan, and inrush current limit circuit have reached the life alarm output level. Read-only.
256 E701	Inrush current limit circuit life display	100%	(0 to 100%)	Displays the deterioration degree of the inrush current limit circuit. Read-only.
257 E702	Control circuit capacitor life display	100%	(0 to 100%)	Displays the deterioration degree of the control circuit capacitor. Read-only.

◆ Life alarm display and signal output (Y90 signal, Pr.255)

- Whether or not the parts of the control circuit capacitor, cooling fan, or inrush current limit circuit have reached the life alarm output level can be checked with **Pr.255 Life alarm status display** and the life alarm signal (Y90).



Pr.255		bit 3	bit 2	bit 0
Decimal	Binary			
13	1101	○	○	○
12	1100	○	○	×
9	1001	○	×	○
8	1000	○	×	×
5	0101	×	○	○
4	0100	×	○	×
1	0001	×	×	○
0	0000	×	×	×

○: With warnings, ×: Without warnings

- The life alarm signal (Y90) turns ON when any of the control circuit capacitor, cooling fan, or inrush current limit circuit reaches the life alarm output level.
- For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) in any of **Pr.190 to Pr.195 (output terminal function selection)**.

NOTE

- Changing the terminal assignment using **Pr.190 and Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

◆ Life display of the inrush current limit circuit (Pr.256)

- The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in **Pr.256**.
- The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (0 time) every 1%/10,000 times. As soon as 10% (900,000 times) is reached, **Pr.255** bit 3 is turned ON and also a warning is output to the Y90 signal.

◆ Life display of the control circuit capacitor (Pr.257)

- The deterioration degree of the control circuit capacitor is displayed in **Pr.257**.
- In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%. As soon as the control circuit capacitor life falls below 10%, **Pr.255** bit 0 is turned ON and also a warning is output to the Y90 signal

◆ Life display of the cooling fan

- If a cooling fan speed of less than about 1700 r/min is detected, Fan alarm FN (FN) is displayed on the operation panel (FR-DU08). As an alarm display, **Pr.255** bit 2 is turned ON and also a warning is output to the Y90 signal and Alarm (LF) signal.
- For the terminal used for the LF signal, set "98" (positive logic) or "198" (negative logic) in any of **Pr.190 to Pr.195 (output terminal function selection)**.

NOTE


- When the converter unit is mounted with two or more cooling fans, "FN" is displayed with one or more fans with the speed below the warning level.
- Changing the terminal assignment using **Pr.190 and Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.
- For replacement of each part, contact the nearest Mitsubishi FA center.

5.2.10 Maintenance timer alarm

The maintenance timer output signal (Y95) is output when the converter unit's cumulative energization time reaches the time period set with the parameter. MT1, MT2 or MT3 is displayed on the operation panel (FR-DU08).

This can be used as a guideline for the maintenance time of peripheral devices.

Pr.	Name	Initial value	Setting range	Description
503 E710	Maintenance timer 1	0	0 (1 to 9998)	Displays the converter unit's cumulative energization time in increments of 100 h (read-only). Writing the setting of "0" clears the cumulative energization time while Pr.503 = "1 to 9998". (Writing is disabled when Pr.503 ="0".)
504 E711	Maintenance timer 1 warning output set time	9999	0 to 9998	Set the time until the maintenance timer signal (Y95) is output. MT1 is displayed on the operation panel.
			9999	No function
686 E712	Maintenance timer 2	0	0 (1 to 9998)	The same function as Pr.503 .
687 E713	Maintenance timer 2 warning output set time	9999	0 to 9998	The same function as Pr.504 .
			9999	MT2 is displayed on the operation panel.
688 E714	Maintenance timer 3	0	0 (1 to 9998)	The same function as Pr.503 .
689 E715	Maintenance timer 3 warning output set time	9999	0 to 9998	The same function as Pr.504 .
			9999	MT3 is displayed on the operation panel.



Operation example of the maintenance timer 1 (**Pr.503**, **Pr.504**) (with both MT2 and MT3 OFF)

- The cumulative energization time of the converter unit is stored in the EEPROM every hour and displayed in **Pr.503** (**Pr.686**, **Pr.688**) in 100 h increments. **Pr.503** (**Pr.686**, **Pr.688**) is clamped at 9998 (999800 h).
- When the value in **Pr.503** (**Pr.686**, **Pr.688**) reaches the time (100 h increments) set in **Pr.504** (**Pr.687**, **Pr.689**), Maintenance timer signal (Y95) is output, and also $M\Gamma 1$ (MT1), $M\Gamma 2$ (MT2), or $M\Gamma 3$ (MT3) is displayed on the operation panel.
- For the terminal used for Y95 signal output, assign the function by setting "95 (positive logic)" or "195 (negative logic)" in any of **Pr.190 to Pr.195** (output terminal function selection).

NOTE

- The Y95 signal turns ON when any of MT1, MT2 or MT3 is activated. It does not turn OFF unless all of MT1, MT2 and MT3 are cleared.
- If all of MT1, MT2 and MT3 are activated, they are displayed in the priority of "MT1 > MT2 > MT3".
- The cumulative energization time is counted every hour. Energization time of less than 1 h is not counted.
- Changing the terminal assignment using **Pr.190 and Pr.195** (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

◀ Parameters referred to ▶

Pr.190 to Pr.195 (output terminal function selection) page 90

5.3 (H) Protective function parameter

Purpose	Parameter to set			Refer to page
	Parameter name	Parameter code	Parameter value	
To vary the operating level of the undervoltage protective function	Undervoltage level	P.H102	Pr.598	83
To initiate an inverter protective function	Fault initiation	P.H103	Pr.997	83
To disable the I/O phase loss protective function	Input phase loss protection selection	P.H201	Pr.872	84
To restart using the retry function when the protective function is activated	Retry operation	P.H300 to P.H303	Pr.65, Pr.67 to Pr.69	84

5.3.1 Varying the activation level of the undervoltage protective function

If the undervoltage protection (E.UVT) is activated due to unstable voltage in the power supply, the undervoltage level (DC bus voltage value) can be changed.

Pr.	Name	Initial value	Setting range	Description
598 H102	Undervoltage level	9999	350 to 430 VDC	Set the DC voltage value at which E.UVT occurs.
			9999	E.UVT occurs at 430 VDC.

NOTE

- Do not use this function when switching to an external battery, since the inrush current when power is restored increases, as the undervoltage level is decreased.

5.3.2 Initiating a protective function

A fault (protective function) is initiated by setting the parameter.

This function is useful to check how the system operates at activation of a protective function.

Pr.	Name	Initial value	Setting range	Description
997 H103	Fault initiation	9999	16 to 253	The setting range is same with the one for fault data codes of the converter unit (which can be read through communication). Written data is not stored in EEPROM.
			9999	The read value is always "9999". With this setting, the protective function is not activated.

- To initiate a fault (protective function), set the assigned number of the protective function you want to initiate in **Pr.997**.
- The value set in **Pr.997** is not stored in EEPROM.
- When a protective function is activated, the inverter trips, a fault is displayed, and a fault signal (ALM, ALM2) is output.
- The latest fault in the faults history is displayed while the fault initiation function is in operation. After a reset, the faults history goes back to the previous status. (The protective function generated by the fault is not saved in the faults history.)
- Perform converter reset to cancel the protective function.
- For the selectable parameter by **Pr.997** and the corresponding protective functions, refer to [page 141](#).

NOTE

- If a protective function is already operating, no protective function cannot be initiated by **Pr.997**.
- The retry function is disabled when a protective function has been initiated by fault initiation function.
- If a fault occurs after a protective function has been activated, the protective function indication does not change. The fault is not saved in the faults history either.

5.3.3 Input phase loss protection selection

The input phase loss protective function on the converter unit input side (R/L1, S/L2, T/L3) can be enabled.

Pr.	Name	Initial value	Setting range	Description
872 H201	Input phase loss protection selection	0	0	Without input phase loss protection
			1	With input phase loss protection

- When Pr.872 = "1", the Input phase loss (E.ILF) protection will be activated if one of three phases is detected to be lost for 1 s continuously.

NOTE

- In the case of R/L1, S/L2 phase loss, the input phase loss protection will not operate, and the inverter will trip.
- If an input phase loss continues for a long time, the converter unit capacitor life will be shorter.

5.3.4 Retry function

If a protective function activates (fault display), the converter unit resets itself automatically to restart. The retry generating protective functions can be also selected.

When the automatic restart after instantaneous power failure function is selected (Pr.57 ≠ "9999"), the restart operation is also performed after a retry operation as well as after an instantaneous power failure. (Refer to page 98 for the restart operation.)

Pr.	Name	Initial value	Setting range	Description
65 H300	Retry selection	0	0 to 4	The fault that will cause a retry can be selected. (Refer to the table on the next page.)
67 H301	Number of retries at fault occurrence	0	0	No retry function
			1 to 10	Set the number of retries at a fault occurrence. A fault output is not provided during the retry operation.
			101 to 110	Set the number of retries at a fault occurrence. (The setting value minus 100 is the number of retries.) A fault output is provided during the retry operation.
68 H302	Retry waiting time	1 s	0.1 to 600 s	Set the waiting time from a fault occurrence to a retry.
69 H303	Retry count display erase	0	0	Clears the number of successful restarts made by retries.

◆ Setting the retry function (Pr.67, Pr.68)


- When the converter unit protective function is operating (fault indication), the retry function automatically cancels (resets) the protective function after the time set in Pr.68.
- Retry operation is enabled when Pr.67 ≠ "0". For Pr.67, set the number of retries at activation of the protective function.

Pr.67 setting	Fault output during retry operation	Retry count
0	—	No retry function
1 to 10	Not used	1 to 10 times
101 to 110	With	1 to 10 times

- When retries fail consecutively more than the number of times set in Pr.67, a Retry count excess (E.RET) occurs. (Refer to the retry failure example.)
- For Pr.68, set the waiting time from a protective function activation to a retry in the range of 0.1 to 600 s.
- During retry operation, the During retry (Y64) signal is ON. For the Y64 signal, assign the function by setting "64 (positive logic)" or "164 (negative logic)" in any of Pr.190 to Pr.195 (output terminal function selection).

◆ Retry count check (Pr.69)

- By reading **Pr.69**, the number of successful restarts made by retries can be obtained. The cumulative count in **Pr.69** increases by 1 when a retry is successful. Retry is regarded as successful when normal operation continues without a fault for the **Pr.68** setting multiplied by four or longer (3.1 s at the shortest). (When retry is successful, the cumulative number of retry failures is cleared.)
- Writing "0" in **Pr.69** clears the cumulative count.



Retry success example

Retry failure example

◆ Selecting retry generating faults (Pr.65)

- Using **Pr.65**, you can select the fault that will cause a retry. No retry will be made for the fault not indicated. (For the fault details, refer to [page 142](#).) ● indicates the faults selected for retry.

Retry-making fault	Pr.65 setting				
	0	1	2	3	4
E.OVT	●		●	●	●
E.THC	●				
E.IPF	●				●
E.UVT	●				●

Retry-making fault	Pr.65 setting				
	0	1	2	3	4
E.OHT	●				
E.PE	●				●
E.SER	●				●
E.ILF	●				●

NOTE

- Use the retry function only when the operation can be resumed after resetting a protective function activation. Making a retry against the protective function, which is activated by an unknown condition, will lead the converter unit to be faulty. Identify what condition the protective function was activated, and eliminate such condition before resuming the operation.
- Only the fault details for the first fault that occurred are stored in the faults history.
- The reset by the retry function does not clear the accumulated data of the electronic thermal O/L relay, etc. (This is different from power supply reset or reset by RES signal.)
- When the parameter storage device fault (E.PE) has occurred and reading of the retry-function-related parameters has failed, the retry operation cannot be performed.
- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

Caution

- When the retry function is set enabled, stay away from the motor and machine in the case of an inverter trip. The motor and machine will start suddenly (after the reset time has elapsed) after the inverter trip. If the retry function has been selected, apply the CAUTION stickers, which are supplied with the Inverter Manual, to easily visible places.

Parameters referred to

Pr.57 Restart selection [page 98](#)

5.4 (M) Monitor display and monitor output signal

Purpose	Parameter to set			Refer to page
To change the monitored item on the operation panel	Operation panel monitor selection Cumulative monitor clear	P.M020 to P.M023, P.M044, P.M100 to P.M104	Pr.170, Pr.268, Pr.290, Pr.563, Pr.774 to Pr.776, Pr.891, Pr.992	86
To assign functions to output terminals	Output terminal function assignment	P.M400 to P.M405	Pr.190 to Pr.195	90
To detect the control circuit temperature	Control circuit temperature monitor	P.M060	Pr.663	93

5.4.1 Monitor display selection using operation panel or via communication

The monitored item to be displayed on the operation panel (FR-DU08) can be selected.

Pr.	Name	Initial value	Setting range	Description
774 M101	Operation panel monitor selection 1	9999 (Converter output voltage)	2, 8, 13, 20, 25, 43, 44, 55, 62, 98, 9999	The converter output voltage, input current and electronic thermal relay function load factor monitor that are displayed in monitor mode on the operation panel can be switched to a specified monitor.
775 M102	Operation panel monitor selection 2	9999 (Input current)		
776 M103	Operation panel monitor selection 3	9999 (Electric thermal relay function load factor)		
992 M104	Operation panel setting dial push monitor selection	8 (Converter output voltage)	2, 8, 13, 20, 25, 43, 44, 55, 62, 98	Select the monitor to be displayed when the setting dial on the operation panel is pushed.
170 M020	Watt-hour meter clear	9999	0	Set "0" to clear the watt-hour monitor.
			10	Sets the maximum value for the monitoring from 0 to 9999 kWh.
			9999	Sets the maximum value for the monitoring from 0 to 65535 kWh.
563 M021	Energization time carrying-over times	0	(0 to 65535) (Read-only.)	Displays the numbers of times that the cumulative energization time monitor exceeded 65535 h. Read-only.
268 M022	Monitor decimal digits selection	9999	0	Displays as integral value.
			1	Displays in 0.1 increments.
			9999	No function
891 M023	Cumulative power monitor digit shifted times	9999	0 to 4	Set the number of times to shift the cumulative power monitor digit. The monitored value is clamped at the maximum value.
			9999	No shift. The monitored value is cleared when it exceeds the maximum value.
290 M044	Monitor negative output selection	0	0, 2, 4, 6	Set the availability of output with a minus sign for the operation panel display or monitoring via communication.

◆ Monitor description list (Pr.774 to Pr.776, Pr.992)

- Use **Pr.774 to Pr.776 and Pr.992** to select a monitored item to be displayed on the operation panel (FR-DU08).
- Refer to the following table and set the monitor to be displayed. (The items with — are not available for monitoring.) The circle in the minus (—) display column denotes availability of the minus sign display.

Types of monitor	Unit	Pr.774 to Pr.776, Pr.992	RS-485 communication dedicated monitor (hexadecimal)	Modbus-RTU Real time monitor	Minus (-) display	Description
Input current*2*3*6	0.1 A	2	H02	40202		Displays the converter unit input current effective value.
Converter output voltage*2	0.1 V	8	H08	40208		Displays the DC bus voltage value.
Input power	0.1 kW	13	H0D	40213		Displays the power at the converter unit input side.
Cumulative energization time*1	1 h	20	H14	40220		Displays the cumulative energization time since the converter unit shipment. Check how many times the monitor value exceeded 65535 h with Pr.563 .
Cumulative power*2	0.1 kWh	25	H19	40225		Displays the cumulative energy based on the input power monitor. This can be cleared by Pr.170 . (Refer to page 88)
Station number (RS-485 terminals)	1	43	H2B	40243		Displays which station number (0 to 31) can currently be used for communication from the RS-485 terminal block.
Station number (PU)	1	44	H2C	40244		Displays which station number (0 to 31) can currently be used for communication from the PU connector.
Input terminal status	—	55	H0F*4	40215*4		Displays input terminal ON/OFF state of the converter unit. (Refer to page 88 for DU display.)
Output terminal status	—		H10*5	40216*5		Displays output terminal ON/OFF state of the converter unit. (Refer to page 88 for DU display.)
Electric thermal relay function load factor	0.1%	62	H3E	40262		Displays the accumulated heat value of the converter thermal O/L relay. The converter overload trip (electronic thermal relay function) (E.THC) occurs at 100%.
32-bit cumulative power (lower 16 bits)	1 kWh	—	H4D	40277		Displays the 32-bit cumulative power value in multiplies of 16 bits. Monitoring can be performed via RS-485 communication.
32-bit cumulative power (upper 16 bits)	1 kWh	—	H4E	40278		
32-bit cumulative power (lower 16 bits)	0.1 kWh	—	H4F	40279		
32-bit cumulative power (upper 16 bits)	0.1 kWh	—	H50	40280		
Control circuit temperature	1°C	98	H62	40298	○	Displays the temperature of the control circuit board. Without minus sign: 0 to 100°C With minus sign: -20 to 100°C

*1 The cumulative energization time is accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0.

*2 Since the voltage and current display on the operation panel (FR-DU08) is shown in four digits, a monitor value of more than "9999" is displayed as "----".

*3 0 A appears during regenerative driving.

*4 Input terminal monitor details ("1" denotes terminal ON, "0" denotes terminal OFF, and "—" denotes undetermined value.)

b15

—	—	—	—	—	RES	—	OH	—	—	—	—	—	—	—	—	—	b0
																	RDI

*5 Output terminal monitor details ("1" denotes terminal ON, "0" denotes terminal OFF, and "—" denotes undetermined value.)

b15


—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	b0				
																	ABC1	FAN	RSO	IPF	RDA	RDB

*6 The monitored values are retained even if a converter unit fault occurs. Resetting will clear the retained values.

(M) Monitor display and monitor output signal

◆ Monitor display for operation panel (Pr.774 to Pr.776)

- The monitor displayed at power ON is the first monitor (the converter output voltage monitor in the initial setting). Display the monitor that will be the first monitor, and continue pressing **SET** for 1 s. (To return to the converter output voltage monitor, display the converter output voltage monitor and press **SET** for 1 s.)



- Pr.774** sets the first monitor, **Pr.775** sets the second monitor, and **Pr.776** sets the third monitor to be displayed.

◆ Operation panel setting dial push monitor selection (Pr.992)


- The monitored item to be displayed at the operation panel (FR-DU08)'s setting dial push can be selected with **Pr.992**. In the initial setting (**Pr.992** = "8"), the converter output voltage monitor is displayed.

◆ Operation panel (FR-DU08) I/O terminal monitor (Pr.774 to Pr.776)

- When **Pr.774 to Pr.776** = "55", the I/O terminal status can be monitored on the operation panel (FR-DU08).
- The LED is ON when the terminal is ON, and the LED is OFF when the terminal is OFF. The center line of LED is always ON.

Pr.774 to Pr.776 setting	Monitor description
55	Displays the I/O terminal ON/OFF state of the converter unit.

- On the I/O terminal monitor (**Pr.774 to Pr.776** = "55"), the upper LEDs denote the input terminal state, and the lower LEDs denote the output terminal state.



◆ Cumulative power monitor and clear (Pr.170, Pr.891)

- On the cumulative power monitor (**Pr.774 to Pr.776** = "25"), the input power monitor value is added up and updated in 100 ms increments. (The values are saved in EEPROM every hour.)
- Display increments and display ranges of the operation panel (FR-DU08) and communication (RS-485 communication) are as indicated below.

Operation panel *1		Communication		
Range	Unit	Range		Unit
		Pr.170 = 10	Pr.170 = 9999	
0 to 999.99 kWh	0.01 kWh	0 to 9999 kWh	0 to 65535 kWh (initial value)	1 kWh
1000.0 to 9999.9 kWh	0.1 kWh			
10000 to 99999 kWh	1 kWh			

*1 Power is measured in the range of 0 to 99999.99 kWh, and displayed in five digits. When the monitor value exceeds "999.99", a carry occurs, for example "1000.0", so the value is displayed in 0.1 kWh increments.

- Digits in the cumulative power monitor can be shifted to the right for the numerical set in **Pr.891 Cumulative power monitor digit shifted times**.

For example, if the cumulative power value is 1278.56 kWh when **Pr.891** = "2", the operation panel display is 12.78 (display in 100 kWh increments) and the communication data is 12.

- If the maximum value is exceeded at **Pr.891** = "0 to 4", the monitor value is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at **Pr.891** = "9999", the monitor value returns to 0, and the counting starts again.
- Writing "0" in **Pr.170** clears the cumulative power monitor.

NOTE

- If "0" is written to **Pr.170**, and **Pr.170** is read again, "9999" or "10" is displayed.

◆ **Cumulative energization time monitor (Pr.563)**

- Cumulative energization time monitor (**Pr.774 to Pr.776** = "20") accumulates energization time from shipment of the converter unit every one hour.
- If the number of monitor value exceeds 65535, it is added up from 0. Use **Pr.563** to check the numbers of times that the cumulative energization time monitor exceeded 65535 h.
- Writing "0" in **Pr.171** clears the actual operation time monitor. (The energization time monitor cannot be cleared.)

NOTE

- The cumulative energization time does not increase if the power is ON for less than an hour.

◆ **Hiding the decimal places for the monitors (Pr.268)**

- As the operation panel (FR-DU08) display is 5 digits long, the decimal places may vary during analog input, etc. The decimal places can be hidden by selecting the decimal digits with **Pr.268**.

Pr.268 setting	Description
9999 (initial value)	No function
0	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first decimal place and smaller are rounded to display an integral value (1 increments). The monitor value equal to or smaller than 0.99 is displayed as 0.
1	When monitoring with the second decimal place (0.01 increments), the 0.01 decimal place is dropped and the monitor displays the first decimal place (0.1 increments). When the monitor display is incremented by one, the display will not change.

NOTE

- The number of display digits on the cumulative energization time (**Pr.774 to Pr.776**="20") and the cumulative power (**Pr.774 to Pr.776**="25") does not change.

◆ **Minus sign display for the monitors (Pr.290)**

- Values with minus signs can be displayed on the monitor indicator of the operation panel (FR-DU08). For a list of monitored items that can be displayed with minus signs, refer to the monitor description list (on [page 87](#)).

Pr.290 setting	Minus-sign display on operation panel	Monitoring via communication
0 (initial value)	-	-
2	Displayed with minus sign.	-
4	-	Displayed with minus sign.
6	Displayed with minus sign.	Displayed with minus sign.

-: Output without minus sign (positive only)

5.4.2 Output terminal function selection

Use the following parameters to change the functions of the open collector output terminals and relay output terminals.

Pr.	Name	Initial value	Initial signal	Setting range
190 M400	RDB terminal function selection	111	RDB (Inverter operation enable (NC contact))	2, 8, 11, 17, 25, 26, 64, 68, 90, 94, 95, 98, 99, 102, 108, 111, 125, 126, 164, 168, 190, 194, 195, 198, 199, 206, 207, 209, 210, 214, 306, 307, 309, 310, 9999
191 M401	RDA terminal function selection	11	RDA (Inverter operation enable (NO contact))	
192 M402	IPF terminal function selection	2	IPF (Instantaneous power failure/undervoltage)	
193 M403	RSO terminal function selection	209	RSO (Inverter reset)	
194 M404	FAN terminal function selection	25	FAN (Fan fault output)	
195 M405	ABC1 terminal function selection	99	ALM (Fault)	

◆ Output signal list

- The functions of the output terminals can be set.
- Refer to the following table and set the parameters. (0 to 99: Positive logic, 100 to 199: Negative logic)

Setting		Signal name	Function	Operation	Related parameter	Refer to page
Positive logic	Negative logic					
2	102	IPF	Instantaneous power failure/undervoltage	Output when an instantaneous power failure or undervoltage protection operation occurs.	Pr.57	98
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the cumulative electronic thermal O/L relay value reaches 85% of the trip level. (Electronic thermal O/L relay protection (E.THC) is activated when the value reaches 100%.)	—	91
11	—	RDA	Inverter operation enable (NO contact)	Output when the converter unit operation is ready.	—	92
—	111	RDB	Inverter operation enable (NC contact)	Output when a converter unit fault occurs or the converter is reset. (inverse to the logic of RDA)	—	
17	—	Y17	Control signal for main circuit power supply MC	Output while the self power management function is enabled. Turns OFF when a fault activating the self power management operation occurs.	Pr.248, Pr.30	96
25	125	FAN	Fan fault output	Output when a fan fault occurs.	—	91
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection operation temperature.	—	144
64	164	Y64	During retry	Output during retry processing.	Pr.65 to Pr.69	84
68	168	EV	24 V external power supply operation	Output while operating with a 24 V power supply input from an external source.	—	40
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, the inrush current limit circuit, or the cooling fan approaches the end of its life.	Pr.255 to Pr.257	80
94	194	ALM2	Fault output 2	Output when the converter unit's protective function is activated to stop the output (at fault occurrence). The signal output continues even during a converter reset, and the signal output stops after the reset release. *1	—	92
95	195	Y95	Maintenance timer signal	Output when Pr.503 reaches the Pr.504 setting or higher.	Pr.503, Pr.504	82
98	198	LF	Alarm	Output when an alarm (fan fault or communication error warning) occurs.	Pr.121	91, 113, 130
99	199	ALM	Fault	Output when the converter unit's protective function is activated to stop the output (at fault occurrence). The signal output is stopped after a reset.	—	92

Setting		Signal name	Function	Operation	Related parameter	Refer to page
Positive logic	Negative logic					
206	306	Y206	Cooling fan operation command signal	Output when the cooling fan operation is commanded.	—	92
207	307	Y207	Control circuit temperature signal	Output when the temperature of the control circuit board reaches the detection level or higher.	Pr.663	93
209	309	RSO	Inverter reset	Output at the converter reset.	—	92
210	310	PWF	Power failure stop signal	Output during instantaneous power failure, undervoltage, or input phase loss.	Pr.261	99
214	—	Y214	Converter unit fault (E.CPU, E.OHT)	The signal turns ON when the converter unit is in the normal state. The signal turns OFF when the converter unit's protective function (E.CPU, E.OHT) is activated (at fault occurrence).	—	—
9999	—	—	No function	—	—	—


*1 When the power is reset, the fault output 2 signal (ALM2) turns OFF at the same time as the power turns OFF.

NOTE

- The same function may be set to more than one terminal
- The terminal conducts during function operation when the setting is "0 to 99, 200 to 299", and does not conduct when the setting is "100 to 199, 300 to 399".
- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.
- Do not assign signals which frequently repeat switching between ON and OFF to terminals A1B1C1. Otherwise the life of the relay contacts decreases.

◆ Electronic thermal O/L relay pre-alarm (TH) and warning signal (THP)

- If the accumulated electronic thermal value reaches 85%, Electronic thermal relay function pre-alarm (TH) is displayed and the Electronic thermal O/L relay pre-alarm (THP) signal is output. If the value reaches 100% of the setting, the electronic thermal O/L relay protection (E.THC) is activated to shut off the inverter output. The inverter output is not shut off with the TH display.
- For the terminal used for THP signal output, set "8 (positive logic)" or "108 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)** to assign the function.



- 100%: Electronic thermal O/L relay activation value

NOTE

- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

◆ Fan fault output signal (FAN)

- A cooling fan operates at power ON of the converter unit. If the fan stops at this time, fan operation is regarded as faulty, Fan alarm F_N (FN) is displayed on the operation panel, and the Fan fault output (FAN) and Alarm (LF) signals are output.
- To assign the FAN signal to the terminal, set "25 (positive logic) or 125 (negative logic)" in one of **Pr.190 to Pr.195 (output terminal function selection)**. To assign the LF signal, set "98 (positive logic) or 198 (negative logic)".

(M) Monitor display and monitor output signal


◆ Cooling fan operation command signal (Y206)

- The cooling fan operation command signal (Y206 signal) can be output when the converter unit cooling fan meets the conditions for running. The function can be used when the fan installed on the enclosure is synchronized with the converter unit cooling fan.
- Y206 signal indicates the operating command condition of the converter unit cooling fan depending on the power supply ON/OFF. The signal does not indicate the actual operation of the cooling fan. (The signal is output even if the cooling fan is stopped due to a fault.)
- To use the Y206 signal, set "206 (positive logic) or 306 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)** to assign the function to the output terminal.

NOTE


- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

◆ Inverter operation enable signals (RDA and RDB) and inverter reset signal (RSO)



- The inverter operation enable (NO contact) (RDA) signal turns ON when the converter unit operation is ready, and turns OFF when a converter unit fault occurs or the converter is reset.
- A logic inverse to that of RDA is applied to the inverter operation enable (NC contact) (RDB) signal. (However, the RDB signal is in the OFF status while the converter unit power supply is turned OFF.)
- The RDA and RDB signals are initially assigned to the terminals RDA and RDB respectively. By setting "11" for the RDA signal or "111" for the RDB signal in either **Pr.190 to Pr.195 (output terminal function selection)**, the signals can be assigned to other terminals.
- When the converter reset (RES) signal is input to the converter unit, the inverter reset (RSO) signal is output to the inverter.
- The RSO signal is assigned to the terminal RSO in the initial status. The RSO signal can also be assigned to other terminals by setting "209 (positive logic) or 309 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)**.

◆ Fault output signals (ALM, ALM2)



- The Fault (ALM, ALM2) signals are output when the converter unit protective function is activated.
- The ALM2 signal stays ON during the reset period after the fault occurs.
- To use the ALM2 signal, set "94 (positive logic) or 194 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)** to assign the function to the output terminal.
- The ALM signal is assigned to the A1B1C1 contacts in the initial status.

NOTE

- For the details of converter unit faults, refer to [page 142](#).

5.4.3 Detection of control circuit temperature

The temperature of the control circuit board of the converter unit can be monitored, and a signal can be output according to the predetermined temperature setting.

Pr.	Name	Initial value	Setting range	Description
663 M060	Control circuit temperature signal output level	0°C	0 to 100°C	Set the temperature where the Y207 signal turns ON.

◆ Control circuit temperature monitor

- The operation panel can be used to monitor the temperature of the control circuit board within the range of 0 to 100°C.
- The range becomes -20 to 100°C by setting the display with a minus sign in **Pr.290 Monitor negative output selection**.


◆ Control circuit temperature detection (Pr.663, Y207 signal)

- The Y207 signal can be output when the control circuit temperature reaches the **Pr.663** setting or higher.
- For the Y207 signal, set "207 (positive logic) or 307 (negative logic)" in one of **Pr.190 to Pr.195 (output terminal function selection)** to assign the function to the output terminal.

NOTE

- The Y207 signal is turned OFF when the control circuit temperature becomes 5°C or more lower than the **Pr.663** setting.
- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

Parameters referred to

Pr.190 to Pr.195 (output terminal function selection)  [page 90](#)

Pr.290 Monitor negative output selection  [page 86](#)

5.5 (T) Multi-function input terminal parameters

Purpose	Parameter to set			Refer to page
To assign functions to input terminals	Input terminal function selection	P.T700, P.T709, P.T711	Pr.178, Pr.187, Pr.189	94
To change operation when the OH signal is input	OH input selection	P.T723	Pr.876	95

5.5.1 Input terminal function selection

Use the following parameters to select or change the input terminal functions.

Pr.	Name	Initial value	Initial signal	Setting range
178 T700	RDI terminal function selection	9999	No function	7, 62, 9999
187 T709	OH terminal function selection	7	OH (External thermal relay input)	
189 T711	RES terminal function selection	62	RES (Converter reset)	

◆ Input terminal function assignment

- Using **Pr.178, Pr.187, and Pr.189**, set the functions of the input terminals.
- Refer to the following table and set the parameters.

Setting value	Signal name	Function	Related parameter	Refer to page
7	OH	External thermal relay input *1	Pr.876	95
62	RES	Converter reset	—	75
9999	—	No function	—	—

*1 OH signal will operate with the relay contact "open".

NOTE


- Same function can be assigned to two or more terminals. In this case, the logic of terminal input is OR.
- When the terminal assignment is changed using **Pr.178, Pr.187, and Pr.189 (input terminal function selection)**, the terminal name will be different, which may result in an error of wiring, or affect other functions. Set parameters after confirming the function of each terminal.

5.5.2 Operation selection for the external thermal relay input (Pr.876)

The operation when the external thermal relay input (OH) signal is input can be changed by the **Pr.876** setting.

Pr.	Name	Initial value	Setting range	Description
876 T723	OH input selection	0	0	No function
			1	Turning the OH signal OFF trips the converter unit. (NC contact)
			2	Turning the OH signal ON trips the converter unit. (NO contact)

◆ External thermal relay (OH signal, E.OHT)



External thermal relay input connection diagram

- The External thermal relay input (OH) signal is used when using the external thermal relay or the thermal protector built into the motor to protect the motor from overheating.
- When the thermal relay is activated, the inverter trips by the External thermal relay operation (E.OHT).
- The OH signal is assigned to the terminal OH in the initial status. Set "7" in any of **Pr.178**, **Pr.187**, or **Pr.189 (input terminal function selection)** to assign the OH signal to another terminal.

NOTE

- Changing the terminal assignment using **Pr.178**, **Pr.187**, or **Pr.189 (input terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

◆ Operation selection for the OH signal (Pr.876)

- The OH signal input status and the **Pr.876** setting for the converter operation are as shown below.

OH signal input status (external terminal)	Converter unit operation		
	Pr.876 = "0"	Pr.876 = "1" (NC contact)	Pr.876 = "2" (NO contact)
ON	No function	Continuous operation	Inverter trip (E.OHT)
OFF	No function	Inverter trip (E.OHT)	Continuous operation

5.6 (A) Application parameters

Purpose	Parameter to set			Refer to page
To reduce the standby power	Self power management	P.A006, P.E300	Pr.30, Pr.248	96
To restart after instantaneous power failure	Automatic restart operation after instantaneous power failure	P.A702	Pr.57	98
To decelerate the motor to a stop at instantaneous power failure	Power failure time deceleration-to-stop function	P.A730	Pr.261	99


5.6.1 Self power management

By turning ON the magnetic contactor (MC) on the input side before the motor is started and turning OFF the MC after the motor is stopped, power is not supplied to the main circuit, reducing the standby power.


Pr.	Name	Initial value	Setting range	Description
248 A006	Self power management selection	0	0	Self power management function disabled
			1	Self power management function enabled (main circuit OFF at protective function activation)
			2	Self power management function enabled (main circuit OFF at protective function activation due to a circuit failure)
30 E300	Reset selection during power supply to main circuit	0	0	When power is supplied only to the control circuit, and then switched to be supplied to both the control and main circuits, converter reset is performed.
			100	When power is supplied only to the control circuit, and then switched to be supplied to both the control and main circuits, converter reset is not performed.

◆ Connection diagram

- For sink logic and Pr.192="17" (terminal R1, S1 inputs)



- For sink logic and Pr.192="17" (24 V external power supply input)



◆ Operation of the self power management function

- This is a function to control the input side magnetic contactor (MC) with output relay to reduce standby power. Use separate power supplies for the main circuit and the control circuit by using terminals R1/L11 or S1/L21 (refer to [page 39](#)) or 24 V external power supply input (refer to [page 40](#)). Control the main circuit power supply MC by the electronic bypass MC1 signal of the inverter.
- Set **Pr.248 Self power management selection** = "1 or 2", and **Pr.190 to Pr.195 (output terminal function selection)** = "17 (positive logic)" to assign the control signal for main circuit power supply MC (Y17 signal) to an output terminal. (Set **Pr.248** in accordance with the **Pr.248** setting of the inverter.)
- Y17 signal turns ON while the self power management function is enabled.
- When the protective function of the converter unit is activated, Y17 signal immediately turns OFF according to the **Pr.248** setting.

When **Pr.248** = "1", Y17 signal turns OFF whenever a protective function is activated.

When **Pr.248** = "2", Y17 signal turns OFF only when a protective function is activated by a fault originating in the converter unit circuit or a connection fault (refer to the table below). (For the fault details, refer to [page 142](#).)

Fault record
Inrush current limit circuit fault (E.IOH)
CPU fault (E.CPU)
CPU fault (E.6)
CPU fault (E.7)
Parameter storage device fault (E.PE)
Parameter storage device fault (E.PE2)
24 VDC power fault (E.P24)
Operation panel power supply short circuit RS-485 terminals power supply short circuit (E.CTE)
Internal circuit fault (E.13/E.PBT)

NOTE

- When the retry function is used for resetting during self power management operation, Y17 signal retains the value before the reset.
- Repeated operation of the magnetic contactor due to frequent start and stop or activation of the protective function may shorten the inverter and the converter unit life.
- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

◆ Selection between resetting or not resetting during power supply to main circuit (Pr.30 = "100")

- Converter reset is not performed if **Pr.30 Reset selection during power supply to main circuit** = "100", and supplying power to the main circuit (R/L1, S/L2, T/L3 input) is started when power is supplied only to the control circuit (R1/L11, S1/L12 input, or 24 V external power supply input).

NOTE

- When supplying power to the main circuit is started when power is supplied only to the control circuit, there is a little waiting time before starting.
- When supplying power to the main circuit is started while the protective function of the converter unit is activated, converter reset is performed even when "not resetting after power-ON" is selected.


Parameters referred to

Pr.190 to Pr.195 (output terminal function selection)  [page 90](#)

5.6.2 Automatic restart after instantaneous power failure selection

The converter unit can be restarted after power restoration from instantaneous power failure.

Pr.	Name	Initial value	Setting range	Description
57 A702	Restart selection	9999	0	Restarts the motor after power restoration from instantaneous power failure
			9999	Does not restart the motor.



- When the automatic restart after instantaneous power failure is selected on the inverter side, set **Pr.57 Restart selection** = "0" on the converter unit side.
- When the automatic restart after instantaneous power failure function is set, the motor is restarted after power restoration from instantaneous power failure or undervoltage condition. (E.IPF and E.UVT are not activated.)
- When **Pr.57** = "9999" (initial value), the inverter output is shut off at the activation of the instantaneous power failure protection (E.IPF or E.UVT) of the converter unit, even when the automatic restart after instantaneous power failure is selected on the inverter side. (Refer to [page 142](#) for E.IPF or E.UVT.)
- When E.IPF or E.UVT is activated, the Instantaneous power failure/undervoltage (IPF) signal is output.
- The IPF signal is assigned to the terminal IPF in the initial status. The IPF signal can also be assigned to other terminals by setting "2 (positive logic) or 102 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)**.

Caution

- **If the automatic restart after instantaneous power failure function has been selected, motor suddenly restarts at the power restoration after an instantaneous power failure (after the reset time has elapsed).
Stay away from the motor and machine.
If the automatic restart after instantaneous power failure function has been selected, apply the CAUTION stickers, which are supplied with the Inverter Manual, to easily visible places.**

5.6.3 Power failure time deceleration-to-stop function

This is a function to decelerate the motor to a stop when an instantaneous power failure or undervoltage occurs.

Pr.	Name	Initial value	Setting range	Description
261 A730	Power failure stop selection	0	0	Power failure time deceleration-to-stop function disabled
			1, 2, 21, 22	Power failure time deceleration-to-stop function enabled

◆Parameter setting

- When using the power failure time deceleration-to-stop function, set **Pr.261** of the converter unit as shown in the table below in accordance with the **Pr.261** setting of the inverter.

Pr.261 setting		Description	Power failure time deceleration-to-stop function when the automatic restart after instantaneous power failure is enabled (Pr.57 ≠ "9999")
Inverter	Converter unit		
0	0	Power failure time deceleration-to-stop function disabled	—
1, 11	1	Power failure time deceleration-to-stop function enabled	Disabled
2, 12	2		Enabled
21	21		Disabled
22	22		Enabled

◆Power failure stop signal (PWF signal)

- Power failure stop signal (PWF) turns ON during instantaneous power failure, undervoltage, or input phase loss.
- For the PWF signal, assign the function by setting "210 (positive logic)" or "310 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)**.

When the input specification of the power failure stop external signal (X48 signal) is the NC contact, set the negative logic for the PWF signal of the converter unit. When the input specification of the power failure stop external signal (X48 signal) is the NO contact, set the positive logic for the PWF signal of the converter unit. (For the X48 signal, the initial setting is the NC contact input specification. For changing the input logic, refer to the Instruction Manual of the inverter.)

NOTE

- When the power failure time deceleration-to-stop function is selected, undervoltage protection (E.UVT), instantaneous power failure protection (E.IPF) and input phase loss protection (E.ILF) are not invalid.
- Changing the terminal assignment using **Pr.190 to Pr.195 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

Parameters referred to

Pr.190 to Pr.195 (output terminal function selection)  page 90

Pr.872 Input phase loss protection selection  page 84

5.7 (N) Operation via communication and its settings


Purpose	Parameter to set			Refer to page
To start operation via communication	Initial setting of operation via communication	P.N000, P.N001	Pr.549, Pr.342	105
To operate via communication from PU connector	Initial setting of computer link communication (PU connector)	P.N020 to P.N028	Pr.117 to Pr.124	106
To operate via communication from RS-485 terminals	Initial setting of computer link communication (RS-485 terminals)	P.N030 to P.N038	Pr.331 to Pr.337, Pr.341	
	Modbus-RTU communication specification	P.N002, P.N030, P.N031, P.N034, P.N080,	Pr.539, Pr.331, Pr.332, Pr.334, Pr.343,	119

5.7.1 Wiring and configuration of PU connector

Using the PU connector enables communication operation from a personal computer, etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the converter unit or read and write parameters.

◆PU connector pin-outs




Pin number	Name	Description
1	SG	Earthing (grounding)
2	-	Operation panel power supply
3	RDA	Converter unit receive+
4	SDB	Converter unit send-
5	SDA	Converter unit send+
6	RDB	Converter unit receive-
7	SG	Earthing (grounding)
8	-	Operation panel power supply

NOTE


- Pins No. 2 and 8 provide power to the operation panel. Do not use these pins during RS-485 communication.
- Do not connect the cable to a computer's LAN board, to a fax modem socket, or to a telephone connector. Doing so may damage the product due to the differences in the electric specifications.

◆ Configuration and wiring of PU connector communication system

• System configuration



• Wiring of computer by RS-485



*1 Make connection in accordance with the Instruction Manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.

NOTE

- When performing RS-485 communication with multiple converter units, use the RS-485 terminals. (Refer to [page 103](#).)
- Computer-converter unit connection cable

Refer to the following for the connection cable (RS-232C ↔ RS-485 converter) between the computer with an RS-232C interface and a converter unit. Commercially available products (as of February 2012)

Model	Manufacturer
Interface embedded cable DAFXIH-CAB (D-SUB25P for personal computer side) DAFXIH-CABV (D-SUB9P for personal computer side) +	Diatrend Corp.
Connector conversion cable DINV-485CAB (for converter unit side) *2	
Interface embedded cable dedicated for converter unit DINV-CABV *2	

*2 The conversion cable cannot connect multiple converter units. (The computer and the converter unit are connected in a 1:1 pair.) This product is a RS-232C ↔ RS-485 conversion cable that has a built-in converter. No additional cable or connector is required. For the product details, contact the cable manufacturer.


- Refer to the following table when fabricating the cable on the user side. Commercially available products (as of February 2012)

Name	Model	Manufacturer
Communication cable	SGLPEV-T (Cat5e/300 m) 24AWG × 4P*3	Mitsubishi Cable Industries, Ltd.
RJ-45 connector	5-554720-3	Tyco Electronics

*3 Do not use pins No. 2 and 8 of the communication cable.

5.7.2 Wiring and configuration of RS-485 terminals

◆RS-485 terminal layout



Name	Description
RDA1 (RXD1+)	Converter unit receive+
RDB1 (RXD1-)	Converter unit receive-
RDA2 (RXD2+)	Converter unit receive+ (for branch)
RDB2 (RXD2-)	Converter unit receive- (for branch)
SDA1 (TXD1+)	Converter unit send+
SDB1 (TXD1-)	Converter unit send-
SDA2 (TXD2+)	Converter unit send+ (for branch)
SDB2 (TXD2-)	Converter unit send- (for branch)
P5S (VCC)	5V Permissible load current 100 mA
SG (GND)	Earthing (grounding) (connected to terminal SD)

◆Connection of RS-485 terminals and wires


- The size of RS-485 terminal block is the same as the control circuit terminal block. Refer to [page 36](#) for the wiring method.

NOTE

- To avoid malfunction, keep the RS-485 terminal wires away from the control circuit board.


◆ System configuration of RS-485 terminals

- Computer and converter unit connection (1:1)



*Set the terminating resistor switch to the "100 Ω" position.


- Combination of computer and multiple converter units (1:n)




(N) Operation via communication and its settings

◆ How to wire RS-485 terminals

- Wiring of one converter unit and one computer with RS-485 terminals




- Wiring of n converter units (multiple units) and one computer with RS-485 terminals



- *1 Make connection in accordance with the Instruction Manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.
- *2 For the converter unit farthest from the computer, set the terminating resistor switch to ON (100 Ω side).


NOTE

- For branching, connect the wires as shown below.



◆ Two-wire type connection

- If the computer is 2-wire type, a connection from the converter unit can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the RS-485 terminals.



NOTE

- A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.

5.7.3 Initial setting of operation via communication

Set the action when the converter unit is performing operation via communication.

- Set the communication protocol. (Mitsubishi inverter protocol/Modbus-RTU protocol)
- Set the action at fault occurrence or at writing of parameters.

Pr.	Name	Initial value	Setting range	Description
549 N000	Protocol selection	0	0	Mitsubishi inverter (computer link) protocol
			1	Modbus-RTU protocol
342 N001	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
			1	Parameter values written by communication are written to the RAM.

◆ Setting the communication protocol (Pr.549)

- Select the communication protocol.
- The Modbus-RTU protocol can be used by communication from the RS-485 terminals.

Pr.549 setting	Communication protocol
0 (initial value)	Mitsubishi inverter (computer link) protocol
1	Modbus-RTU protocol

◆ Communication EEPROM write selection (Pr.342)

- Storage device of the parameter setting can be changed to RAM only from EEPROM+RAM for the parameter writing from the RS-485 communication via the converter unit PU connector or the RS-485 terminals. Use this function if parameter settings are changed frequently.
- When changing the parameter values frequently, set "1" in **Pr.342 Communication EEPROM write selection** to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).

NOTE

- Turning OFF the converter unit's power supply clears the modified parameter settings when **Pr.342 = "1 (write only to RAM)"**. Therefore, parameter settings at next power-ON will be the ones that are last stored to EEPROM.
- The parameter setting written in RAM cannot be checked on the operation panel. (The values displayed on the operation panel are the ones stored in EEPROM.)

5.7.4 Initial settings and specifications of RS-485 communication

Use the following parameters to perform required settings for the RS-485 communication between the converter unit and a personal computer.

- There are two types of communication, communication using the converter unit's PU connector and communication using the RS-485 terminals.
- Parameter setting, monitoring, etc. can be performed using the Mitsubishi inverter protocol or the Modbus-RTU communication protocol.
- To make communication between the personal computer and the converter unit, initial setting of the communication specifications must be made to the converter unit in advance.

Data communication cannot be made if the initial settings are not made or if there is any setting error.

[Parameters related to PU connector communication]

Pr.	Name	Initial value	Setting range	Description	
117 N020	PU communication station number	0	0 to 31	Specify the converter unit station number. Set the converter unit station numbers when two or more converter units are connected to one personal computer.	
118 N021	PU communication speed	192	48, 96, 192, 384, 576, 768, 1152	Set the communication speed. The setting value × 100 equals the communication speed. For example, if 192 is set, the communication speed is 19200 bps.	
N022	PU communication data length	0	0 1	Data length 8 bits Data length 7 bits	
N023	PU communication stop bit length	1	0 1	Stop bit length 1 bit Stop bit length 2 bits	
119	PU communication stop bit length / data length	1	0	Stop bit length 1 bit	Data length 8 bits
			1	Stop bit length 2 bits	
			10	Stop bit length 1 bit	Data length 7 bits
			11	Stop bit length 2 bits	
120 N024	PU communication parity check	2	0 1 2	Without parity check With odd parity With even parity	
121 N025	Number of PU communication retries	1	0 to 10	Set the permissible number of retries for unsuccessful data reception. If it is still unsuccessful after the permissible number of retries, the inverter will trip.	
			9999	The inverter will not trip even when the communication is unsuccessful.	
122 N026	PU communication check time interval	9999	0	PU connector communication is disabled.	
			0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time. If a no-communication state persists for longer than the permissible time, the inverter will trip.	
			9999	No communication check (signal loss detection)	
123 N027	PU communication waiting time setting	9999	0 to 150 ms	Set the waiting time between data transmission to the converter unit and the response.	
			9999	Set with communication data.	
124 N028	PU communication CR/LF selection	1	0	Without CR/LF	
			1	With CR	
			2	With CR/LF	

(N) Operation via communication and its settings

[Parameters related to communication with the RS-485 terminals]

Pr.	Name	Initial value	Setting range	Description
331 N030	RS-485 communication station number	0	0 to 31 (0 to 247) *1*2	Set the converter unit station number. (Same specifications as Pr.117)
332 N031	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152	Select the communication speed. (Same specifications as Pr.118)
N032	RS-485 communication data length	0	0, 1	Select the data length. (the same specifications as P.E022)*3
N033	RS-485 communication stop bit length	1	0, 1	Select the stop bit length. (the same specifications as P.E023)*4
333	RS-485 communication stop bit length / data length	1	0, 1, 10, 11	Select the stop bit length and the data length. (the same specifications as Pr.119)*3*4
334 N034	RS-485 communication parity check selection	2	0, 1, 2	Select the parity check specifications. (Same specifications as Pr.120)
335 N035 *5	RS-485 communication retry count	1	0 to 10, 9999	Set the permissible number of retries for unsuccessful data reception. (Same specifications as Pr.121)
336 N036 *5	RS-485 communication check time interval	0 s	0	The RS-485 communication is available, but a communication error occurs.
			0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time. (Same specifications as Pr.122)
			9999	No communication check (signal loss detection)
337 N037 *5	RS-485 communication waiting time setting	9999	0 to 150 ms, 9999	Set the waiting time between data transmission to the converter unit and the response. (Same specifications as Pr.123)
341 N038 *5	RS-485 communication CR/LF selection	1	0, 1, 2	Select the presence/absence of CR/LF. (Same specifications as Pr.124)

*1 When **Pr.549** = "1" (Modbus-RTU protocol), the setting range within parentheses is applied.

*2 When a value outside the setting range is set, the converter unit operates at the initial value.

*3 In the Modbus-RTU protocol, the data length is fixed at 8 bits.

*4 In the Modbus-RTU protocol, **Pr.334** setting is applied as the stop bit length. (Refer [page 119](#).)

*5 In the Modbus-RTU protocol, this is invalid.

NOTE

- The monitored items and parameter settings can be read during communication with the **Pr.336 RS-485 communication check time interval** = "0 (initial value)" setting, but a converter unit communication error (E.SER) occurs.
To perform operation or parameter writing via communication, set "9999" or a large setting value in **Pr.336**. (The setting value is determined by the computer program.) (Refer [page 113](#).)
- Always reset the converter after making the initial settings of the parameters. After changing the communication-related parameters, communication cannot be made until the converter is reset.

5.7.5 Mitsubishi inverter protocol (computer link communication)

Parameter settings and monitoring are possible by using the Mitsubishi inverter protocol (computer link communication) via inverter PU connector and the RS-485 terminals.


◆ Communication specifications

- The communication specifications are given below.

Item	Description	Related parameter
Communication protocol	Mitsubishi protocol (computer link)	Pr.551
Conforming standard	EIA-485 (RS-485)	—
Connectable units	1:N (maximum 32 units), setting is 0 to 31 stations	Pr.117 Pr.331
Communication speed	PU connector	Selected among 4800/9600/19200/38400 bps
	RS-485 terminals	Selected among 300/600/1200/2400/4800/9600/19200/38400/57600/76800/115200 bps
Control procedure	Start-stop synchronization method	—
Communication method	Half-duplex system	—
Communication specifications	Character system	ASCII (7 bits or 8 bits can be selected.)
	Start bit	1 bit
	Stop bit length	1 bit or 2 bits can be selected.
	Parity check	Check (even or odd) or no check can be selected.
	Error check	Sum code check
Terminator	CR/LF (presence/absence selectable)	Pr.124 Pr.341
Waiting time setting	Selectable between presence and absence	Pr.123 Pr.337

◆ Communication procedure

- Data communication between the computer and the converter unit is made in the following procedure.
 - Request data is sent from the computer to the converter unit. (The converter unit will not send data unless requested.)
 - After waiting for the waiting time,
 - The converter unit sends reply data to the computer in response to the computer request.
 - After waiting for the converter unit data processing time,
 - An answer from the computer in response to reply data (c) of the converter unit is transmitted. (Even if (e) is not sent, subsequent communication is made properly.)



- *1 If a data error is detected and a retry must be made, perform retry operation with the user program. The converter unit trips when the number of consecutive retries exceeds the parameter setting.
- *2 On receipt of a data error occurrence, the converter unit returns reply data (c) to the computer again. The converter unit trips when the number of consecutive data errors exceeds the parameter setting.

◆ Communication operation presence/absence and data format types

- Data communication between the computer and the converter unit is made in ASCII code (hexadecimal code).
- Communication operation presence/absence and data format types are as follows.

Symbol	Operation	Special monitor write	Pr. write	Converter reset	Monitor	Pr. read	
a	Communication request is sent to the converter unit in accordance with the user program in the computer.	A1	A	A	B	B	
b	Converter unit data processing time	With	With	Without	With	With	
c	Reply data from the computer unit (Data a) is checked for an error)	No error *1 (Request accepted)	C	C	C*2	E, E1, E2, E3	E
		With error (Request rejected)	D	D	D*2	D	D
d	Computer processing delay time	10 ms or more					
e	Answer from computer in response to reply data c (Data c is checked for error)	No error *1 (No converter unit processing)	Without	Without	Without	Without (C)	Without (C)
		With error (Converter unit output c again.)	Without	Without	Without	F	F

*1 In the communication request data from the computer to the converter unit, 10 ms or more is also required after "no data error (ACK)". (Refer [page 112.](#))

*2 Reply from the converter unit to the converter reset request can be selected. (Refer to [page 116.](#))

- Data writing format

a. Communication request data from the computer to the converter unit

Format	Number of characters												
	1	2	3	4	5	6	7	8	9	10	11	12	13
A	ENQ *1	Converter unit station No.*2	Instruction code		*3	Data					Sum check	*4	
A1	ENQ *1	Converter unit station No.*2	Instruction code		*3	Data	Sum check				*4		

c. Reply data from the converter unit to the computer (No data error detected)

Format	Number of characters			
	1	2	3	4
C	ACK *1	Converter unit station No.*2		*4

c. Reply data from the converter unit to the computer (Data error detected)

Format	Number of characters				
	1	2	3	4	5
D	NAK *1	Converter unit station No.*2	Error code		*4

*1 Indicates a control code.

*2 Specifies the converter unit station numbers in the range of H00 to H1F (stations 0 to 31) in hexadecimal.

*3 When **Pr.123 and Pr.337 (Waiting time setting)** ≠ 9999, create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)

*4 CR, LF code: When data is transmitted from the computer to the converter unit, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must be also made on the converter unit according to the computer. Whether the CR and LF codes will be present or absent can be selected using **Pr.124 and Pr.341 (CR/LF selection)**.

(N) Operation via communication and its settings

- Data reading format
 - a. Communication request data from the computer to the converter unit

Format	Number of characters								
	1	2	3	4	5	6	7	8	9
B	ENQ *1	Converter unit station No. *2		Instruction code		*3	Sum check		*4

- c. Reply data from the converter unit to the computer (No data error detected)

Format	Number of characters												
	1	2	3	4	5	6	7	8	9	10	11	12	13
E	STX *1	Converter unit station No. *2		Read data				ETX *1	Sum check		*4		
E1	STX *1	Converter unit station No. *2		Read data		ETX *1	Sum check		*4				
E2	STX *1	Converter unit station No. *2		Read data (model information, capacity)					ETX *1	Sum check		*4	

Format	Number of characters													
	1	2	3	4 to 23						24	25	26	27	
E3	STX *1	Converter unit station No. *2		Read data (model information, model name)						ETX *1	Sum check		*4	

- c. Reply data from the converter unit to the computer (Data error detected)

Format	Number of characters				
	1	2	3	4	5
D	NAK *1	Converter unit station No. *2		Error code	*4

- e. Transmission data from the computer to the converter unit

Format	Number of characters			
	1	2	3	4
C (No data error detected)	ACK *1	Converter unit station No. *2		*4
F (Data error detected)	NAK *1	Converter unit station No. *2		*4

- *1 Indicates a control code.
- *2 Specifies the converter unit station numbers in the range of H00 to H1F (stations 0 to 31) in hexadecimal.
- *3 When **Pr.123 and Pr.337 (Waiting time setting)** ≠ 9999, create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- *4 CR, LF code: When data is transmitted from the computer to the converter unit, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must be also made on the converter unit according to the computer. Whether the CR and LF codes will be present or absent can be selected using **Pr.124 and Pr.341 (CR/LF selection)**.

◆ Data definitions

- Control code

Signal name	ASCII code	Description
STX	H02	Start Of Text (Start of data)
ETX	H03	End Of Text (End of data)
ENQ	H05	Enquiry (Communication request)
ACK	H06	Acknowledge (No data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (Data error detected)

- Converter unit station No.

Specify the station number of the converter unit which communicates with the computer.

- Instruction code


Specify the processing request, for example, monitoring, given by the computer to the converter unit. Therefore, the converter unit can be run and monitored in various ways by specifying the instruction code appropriately. (Refer [page 116](#).)

- Data

Indicates the data such as frequency and parameters transferred to and from the converter unit. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer [page 116](#).)

- Waiting time

Specify the waiting time between the receipt of data at the converter unit from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer in the range of 0 to 150 ms in 10 ms increments. (Example; 1: 10 ms, 2: 20 ms)




NOTE


- When **Pr.123 and Pr.337 (Waiting time setting) ≠ 9999**, create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time varies depending on the instruction code. (Refer [page 112](#).)

- Sum check code

The sum check code is a 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



* When the **Pr. 123 Waiting time setting ≠ "9999"**, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)




(N) Operation via communication and its settings

- Error code

If any error is found in the data received by the converter unit, its error definition is sent back to the computer together with the NAK code.

Error code	Error item	Fault definition	Converter unit operation
H0	Computer NAK error	The transmission request data from the computer was containing errors for the permissible number of retries or more.	Trips (E.PUE/E.SER) if error occurs continuously more than the permissible number of retries.
H1	Parity error	The parity check result does not match the specified parity.	
H2	Sum check error	The sum check code in the computer does not match that of the data received by the converter unit.	
H3	Protocol error	The data received by the converter unit has a grammatical mistake. Or, data receive is not completed within the predetermined time. CR or LF is not as set in the parameter.	
H4	Framing error	The stop bit length differs from the initial value.	
H5	Overrun	New data has been sent by the computer before the converter unit completes receiving the preceding data.	
H6	—	—	—
H7	Character error	The character received is invalid (other than 0 to 9, A to F, control code).	Does not accept the received data. The converter unit does not trip.
H8	—	—	—
H9	—	—	—
HA	Mode error	Parameter write was attempted in other than the computer link operation mode, when operation command source is not selected or during converter unit operation.	Does not accept the received data. The fault does not occur.
HB	Instruction code error	The specified instruction code does not exist.	
HC	Data range error	Invalid data has been specified for parameter writing, etc.	
HD	—	—	—
HE	—	—	—
HF	Normal (no error)	—	—

◆ Response time



[Formula for data transmission time]

$$\frac{1}{\text{Communication speed (bps)}} \times \text{Number of data characters (Refer to page 109.)} \times \text{Communication specifications (Total number of bits) = data transmission time (s)}$$

Refer to the following section.

- Communication specifications

Name	Number of bits
Stop bit length	1 bit 2 bits
Data length	7 bits 8 bits
Parity check	With 1 bit
	Without 0

- Data check time


Item	Check time
Various monitored values	<12 ms
Parameter read/write	<30 ms
Parameter clear / all clear	<5 s
Reset command	No answer

In addition to the above, 1 start bit is necessary.
 Minimum number of total bits 9 bits
 Maximum number of total bits 12 bits


◆ Retry count setting (Pr.121, Pr.335)

- Set the permissible number of retries for data receive error occurrence. (Refer to [page 112](#) for data receive error for retry.)
- When the data receive errors occur consecutively and the number of retries exceeds the permissible number setting, a communication fault (PU connector communication: E.PUE, RS-485 terminal communication: E.SER) occurs and the inverter trips.
- When a data transmission error occurs while "9999" is set, the inverter does not trip but outputs the Alarm (LF) signal. To use the LF signal, set "98 (positive logic) or 198 (negative logic)" in any of **Pr.190 to Pr.195 (output terminal function selection)** to assign the function to an output terminal.

Example: PU connector communication, Pr. 121 = "1" (initial value)




Example: PU connector communication, Pr. 121 = "9999"



◆ Signal loss detection (Pr.122, Pr.336)

- If a signal loss (communication stop) is detected between the converter unit and the computer as a result of a signal loss detection, a communication fault (PU connector communication: E.PUE, RS-485 terminal communication: E.SER) occurs and the inverter trips.
- When the setting is "9999", communication check (signal loss detection) is not made.
- When the setting is "0", communication from the PU connector is not possible. The monitored items and parameter settings can be read during communication via RS-485 terminals, but a communication error (E.SER) occurs.
- A signal loss detection is made when the setting is any of "0.1 s to 999.8 s". To make a signal loss detection, it is necessary to send data (for details on control codes, refer to [page 111](#)) from the computer within the communication check time interval. (The converter unit makes a communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master.)

Example: PU connector communication, Pr. 122 = "0.1 to 999.8 s"



◆ Instructions for the program

- When data from the computer has any error, the converter unit does not accept that data. Hence, in the user program, always insert a retry program for data error.
- All data communication, for example, monitoring, are started when the computer gives a communication request. The converter unit does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- Program example) Writing "0" in **Pr.57**

Microsoft® Visual C++® (Ver. 6.0) programming example

```
#include <stdio.h>
#include <windows.h>

void main(void){
    HANDLE      hCom;          // Communication handle
    DCB          hDcb;        // Structure for setting communication settings
    COMMTIMEOUTS hTim;       // Structure for setting timeouts


    char        szTx[0x10];   // Send buffer
    char        szRx[0x10];   // Receive buffer
    char        szCommand[0x10]; // Command
    int         nTx,nRx;      // For storing buffer size
    int         nSum;        // For calculating sum code
    BOOL        bRet;
    int         nRet;
    int         i;

    //**** Open COM1 port ****
    hCom = CreateFile("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
    if(hCom != NULL) {
        //**** Set COM1 port communication ****
        GetCommState(hCom,&hDcb); // Get current communication information
        hDcb.DCBLength = sizeof(DCB); // Structure size setting
        hDcb.BaudRate = 19200; // Communication speed = 19200 bps
        hDcb.ByteSize = 8; // Data length = 8 bits
        hDcb.Parity = 2; // Even parity
        hDcb.StopBits = 2; // Stop bit = 2 bits
        bRet = SetCommState(hCom,&hDcb); // Setting of changed communication information
        if(bRet == TRUE) {
            //**** Set COM1 port timeout ****
            GetCommTimeouts(hCom,&hTim); // Get current timeout values
            hTim.WriteTotalTimeoutConstant = 1000; // Write timeout 1 second
            hTim.ReadTotalTimeoutConstant = 1000; // Read timeout 1 second
            SetCommTimeouts(hCom,&hTim); // Setting of changed timeout values
            //**** Setting a command to write "0" in Pr.57 of the station number 1 converter unit ****
            sprintf(szCommand,"01B910000"); // Send data (Parameter write)
            nTx = strlen(szCommand); // Send data size
            //**** Generate sum code ****
            nSum = 0; // Initialize sum data
            for(i = 0;i < nTx;i++) {
                nSum += szCommand[i]; // Calculate sum code
                nSum &= (0xff); // Mask data
            }

            //**** Generate send data ****
            memset(szTx,0,sizeof(szTx)); // Initialize send buffer
            memset(szRx,0,sizeof(szRx)); // Initialize receive buffer
            sprintf(szTx,"%5s%02X",szCommand,nSum); // ENQ code + send data + sum code
            nTx = 1 + nTx + 2; // Number of ENQ codes + number of send data + number of sum codes

            nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
            //**** Send ****
            if(nRet != 0) {
                nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);
                //**** Receive ****
                if(nRet != 0) {
                    //**** Display receive data ****
                    for(i = 0;i < nRx;i++) {
                        printf("%02X ",(BYTE)szRx[i]); // Output received data to console
                        // Display ASCII code in Hexadecimal! In case of 0, "30" is displayed.
                    }
                    printf("\n\r");
                }
            }
            CloseHandle(hCom); // Close communication port
        }
    }
}
```

General flowchart



⚠ Caution

- Always set the communication check time interval before starting operation to prevent hazardous conditions.
- Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will trip (E.PUE, E.SER).
The inverter can be coasted to a stop by switching ON the RES signals or by switching the power OFF.
- If communication is broken due to signal cable breakage, computer fault etc., the converter unit does not detect such a fault. This should be fully noted.

(N) Operation via communication and its settings

◆ Setting items and set data

- After completion of parameter settings, set the instruction codes and data, then start communication from the computer to allow reading/writing of parameters and monitoring.

Item	Read/write	Instruction code	Data description	Number of data digits (Format)*1																																																			
Monitor	Converter output voltage	Read	H6F	H0000 to HFFFF: Converter output voltage (hexadecimal) in 0.1 V increments	4 digits (B.E/D)																																																		
	Input current	Read	H70	H0000 to HFFFF: Input current (hexadecimal) in 0.1 A increments	4 digits (B.E/D)																																																		
	Electric thermal relay function load factor	Read	H71	H0000 to HFFFF: Electronic thermal relay function load factor (hexadecimal) in 0.1% increments	4 digits (B.E/D)																																																		
	Special monitor	Read	H72	H0000 to HFFFF: Monitor data selected in the instruction code HF3	4 digits (B.E/D)																																																		
	Special monitor selection No.	Read	H73	Monitor selection data (Refer to page 86 on selection No.)	2 digits (B.E1/D)																																																		
		Write	HF3		2 digits (A1, C/D)																																																		
	Fault record	Read	H74 to H77	<p>H0000 to HFFFF: Two latest fault records</p> <table style="margin-left: 40px;"> <tr> <td style="text-align: center;">b15</td> <td style="text-align: center;">b8 b7</td> <td style="text-align: center;">b0</td> </tr> <tr> <td>H74</td> <td>Second fault in past</td> <td>Latest fault</td> </tr> <tr> <td>H75</td> <td>Fourth fault in past</td> <td>Third fault in past</td> </tr> <tr> <td>H76</td> <td>Sixth fault in past</td> <td>Fifth fault in past</td> </tr> <tr> <td>H77</td> <td>Eighth fault in past</td> <td>Seventh fault in past</td> </tr> </table> <p>Fault record display example (instruction code H74)</p> <p>With the read data H3040 (Last fault : E.THG) (Present fault : E.FIN)</p> <table style="margin-left: 40px;"> <tr> <td style="text-align: center;">b15</td> <td style="text-align: center;">b8 b7</td> <td style="text-align: center;">b0</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> <tr> <td colspan="8" style="text-align: center;">Last fault (H30)</td> <td colspan="8" style="text-align: center;">Present fault (H40)</td> </tr> </table> <p>(Refer to page 141 for details on fault record read data.)</p>	b15	b8 b7	b0	H74	Second fault in past	Latest fault	H75	Fourth fault in past	Third fault in past	H76	Sixth fault in past	Fifth fault in past	H77	Eighth fault in past	Seventh fault in past	b15	b8 b7	b0	0	0	1	1	0	0	0	0	0	1	0	0	0	0	0	0	Last fault (H30)								Present fault (H40)								4 digits (B.E/D)
	b15	b8 b7	b0																																																				
	H74	Second fault in past	Latest fault																																																				
	H75	Fourth fault in past	Third fault in past																																																				
H76	Sixth fault in past	Fifth fault in past																																																					
H77	Eighth fault in past	Seventh fault in past																																																					
b15	b8 b7	b0																																																					
0	0	1	1	0	0	0	0	0	1	0	0	0	0	0	0																																								
Last fault (H30)								Present fault (H40)																																															
Converter status monitor (extended)	Read	H79	Status of the output signals can be monitored. (For the details, refer to page 118 .)	4 digits (B.E/D)																																																			
Converter status monitor	Read	H7A		2 digits (B.E1/D)																																																			
Converter reset	Write	HFD	H9696: Converter unit reset • As the converter unit is reset at the start of communication by the computer, the converter unit cannot send reply data back to the computer.	4 digits (A, C/D)																																																			
			H9966: Converter unit reset • When data is sent normally, ACK is returned to the computer, and then the converter is reset.	4 digits (A, D)																																																			
Faults history batch clear	Write	HF4	H9696: Faults history batch clear	4 digits (A, C/D)																																																			

(N) Operation via communication and its settings

Item	Read/write	Instruction code	Data description	Number of data digits (Format)*1	
Parameter clear All clear	Write	HFC	<p>All parameters return to initial values. Whether to clear communication parameters or not can be selected according to the data.</p> <ul style="list-style-type: none"> • Parameter clear H9696: Communication parameters are cleared. H5A5A: Communication parameters are not cleared.*2 • All parameter clear H9966: Communication parameters are cleared. H55AA: Communication parameters are not cleared.*2 <p>For the details of whether or not to clear parameters, refer to page 168. When a clear is performed with H9696 or H9966, communication related parameter settings also return to the initial values. When resuming the operation, set the parameters again. Performing a clear will clear the instruction code HEC, HF3, and HFF settings. Only H9966 and H55AA (all parameter clear) are valid during the password lock (refer to page 78).</p>	4 digits (A, C/D)	
Parameter	Read	H00 to H63	Refer to the instruction code (page 168) and write and/or read parameter values as required.	4 digits (B,E/D)	
	Write	H80 to HE3	When setting Pr.100 and later, the link parameter extended setting must be set.	4 digits (A, C/D)	
Link parameter extended setting	Read	H7F	Parameter settings are switched according to the H00 to H0D settings.	2 digits (B,E1/D)	
	Write	HFF	For details of the settings, refer to the instruction code (page 168).	2 digits (A1, C/D)	
Model information monitor	Model	Read	H7C	<p>Reading the model in ASCII code. "H20" (blank code) is set for blank area. For "FR-CC2" H46, H52, H2D, H43, H43, H32, H20, H20 H20</p>	20 digits (B, E3/D)
	Capacity	Read	H7D	<p>Reading the converter capacity in ASCII code. Data is read in increments of 0.1 kW. "H20" (blank code) is set for blank area. Example) 315K....." 3150" (H20, H20, H33, H31, H35, H30)</p>	6 digits (B, E2/D)

*1 Refer to [page 109](#) for data formats (A, A1, B, C, C1, D, E, E1, E2, E3, F).

*2 Turning OFF the power supply while clearing parameters with H5A5A or H55AA sets back the communication parameter settings to the initial settings.

NOTE

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when a converter reset or all clear is performed.
- When a 32-bit parameter setting or monitored value is read and the read value exceeds HFFFF, the reply data will be HFFFF.

◆ Converter status monitor

Item	Instruction code	Bit length	Description*1	Example
Converter status monitor	H7A	8 bits	b0: RDB (inverter operation enable signal (NC contact)) b1: Fixed to 0 b2: Fixed to 0 b3: RDA (inverter operation enable signal (NO contact)) b4: RSO (inverter reset signal) b5: IPF (instantaneous power failure/undervoltage) b6: FAN (fan fault signal) b7: ABC1 (Fault)	[Example 1] H01...Inverter operation enable signal (NC contact) ON b7 b0 0 0 0 0 0 0 0 1 [Example 2] H80...Fault occurrence b7 b0 1 0 0 0 0 0 0 0
Converter status monitor (extended)	H79	16 bits	b0: RDB (inverter operation enable signal (NC contact)) b1: Fixed to 0 b2: Fixed to 0 b3: RDA (inverter operation enable signal (NO contact)) b4: RSO (inverter reset signal) b5: IPF (instantaneous power failure/undervoltage) b6: FAN (fan fault signal) b7: ABC1 (Fault) b8 to b14: — b15: Fault occurrence	[Example 1] H0001...Inverter operation enable signal (NC contact) ON b15 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 [Example 2] H8080...Fault occurrence b15 b0 1 0 0 0 0 0 0 0 0 1 0 0 0 0 0 0

*1 The signal within parentheses () is the initial status. The description changes depending on the setting of Pr.190 to Pr.195 (output terminal function selection).

5.7.6 Modbus-RTU communication specification

Operation by Modbus-RTU communication or parameter setting is possible by using the Modbus-RTU communication protocol from the RS-485 terminals of the converter unit.

Pr.	Name	Initial value	Setting range	Description
331 N030	RS-485 communication station number	0	0	Broadcast communication
			1 to 247	Specify the converter unit station number. Set the converter unit station numbers when two or more converter units are connected to one personal computer.
332 N031	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152	Set the communication speed. The setting value × 100 equals the communication speed. For example, if 96 is set, the communication speed is 9600 bps.
334 N034	RS-485 communication parity check selection	2	0	Without parity check Stop bit length 2 bits
			1	With odd parity Stop bit length 1 bit
			2	With even parity Stop bit length 1 bit
343 N080	Communication error count	0	—	Displays the communication error count during Modbus-RTU communication. Read-only.
539 N002	Modbus-RTU communication check time interval	9999	0	The Modbus-RTU communication is available, but a communication error occurs.
			0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time. (Same specifications as Pr.122)
			9999	No communication check (signal loss detection)
549 N000	Protocol selection	0	0	Mitsubishi inverter (computer link) protocol
			1	Modbus-RTU protocol

NOTE

- To use the Modbus-RTU protocol, set "1" to **Pr.549 Protocol selection**.
- If Modbus-RTU communication is performed from the master to the address 0 (station number 0), broadcast communication is performed, and the converter unit does not send any reply to the master. To obtain replies from the converter unit, set **Pr.331 RS-485 communication station number** ≠ "0 (initial value)".
Some functions are disabled in broadcast communication. (Refer [page 121.](#))

◆ Communication specifications

- The communication specifications are given below.

Item	Description	Related parameter	
Communication protocol	Modbus-RTU protocol	Pr.549	
Conforming standard	EIA-485 (RS-485)	—	
Connectable units	1:N (maximum 32 units), setting is 0 to 247 stations	Pr.331	
Communication speed	Selected among 300/600/1200/2400/4800/9600/19200/38400/57600/76800/115200 bps	Pr.332	
Control procedure	Start-stop synchronization method	—	
Communication method	Half-duplex system	—	
Communication specifications	Character system	Binary (fixed at 8 bits)	
	Start bit	1 bit	
	Stop bit length	Select from the following three types: No parity check, stop bit length 2 bits Odd parity check, stop bit length 1 bit Even parity check, stop bit length 1 bit	Pr.334
	Parity check		
	Error check	CRC code check	
Terminator	Not used	—	
Waiting time setting	Not used	—	

(N) Operation via communication and its settings


◆ Overview

- The Modbus communication protocol was developed by Modicon for programmable controllers.
- The Modbus protocol uses exclusive message frames to perform serial communication between a master and slaves. These exclusive message frames are provided with a feature called "functions" that allows data to be read or written. These functions can be used to read or write parameters from the converter unit, or check the converter unit's operating status, for example. This product classifies the data of each converter unit into holding register area (register address 40001 to 49999). The master can communicate with converter units (slaves) by accessing preassigned holding register addresses.

NOTE

- There are two serial transmission modes, the ASCII (American Standard Code for Information Interchange) mode and the RTU (Remote Terminal Unit) mode. However, this product supports only the RTU mode, which transfers 1 byte data (8 bits) as it is. Also, only communication protocol is defined by the Modbus protocol. Physical layers are not stipulated.

◆ Message format



- Data check time

Item	Check time
Various monitored values	<12 ms
Parameter read/write	<30 ms
Parameter clear / all clear	<5 s
Reset command	No answer

- Query

A message is sent to the slave (for instance, the converter unit) having the address specified by the master.

- Normal Response

After the query from the master is received, the slave executes the requested function, and returns the corresponding normal response to the master.

- Error Response

When an invalid function code, address or data is received by the slave, the error response is returned to the master. This response is appended with an error code that indicates the reason why the request from the master could not be executed.

This response cannot be returned for errors detected by the hardware, frame error, and CRC check error.

- Broadcast

The master can broadcast messages to all slaves by specifying address 0. All slaves that receive a message from the master execute the requested function. With this type of communication, slaves do not return a response to the master.


NOTE

- During broadcast communication, functions are executed regardless of the converter unit station number (**Pr.331**) setting.

◆ Message frame (protocol)

- Communication method

Basically, the master sends a Query message (question), and slaves return the Response message (response). At normal communication, the Device Address and Function Code are copied as they are, and at erroneous communication (illegal function code or data code), bit 7 (= H80) of the Function Code is turned ON, and the error code is set at Data Bytes.



Message frames comprise of the four message fields shown in the figures above.

A slave recognizes message data as a message by the message data being prefixed and appended with a no data time of 3.5 characters (T1: start/end).

- Details of protocol

The following table explains the four message fields.

Start	ADDRESS	FUNCTION	DATA	CRC CHECK		End
T1	8 bits	8 bits	n × 8 bits	L 8 bits	H 8 bits	T1

Message field	Description
ADDRESS field	For the address, 0 to 247 can be set in single byte lengths (8 bits). Set "0" when sending broadcast messages (instructions to all addresses), and "1 to 247" to send messages to individual slaves. The address set by the master is also returned when the response is sent from the slave. The value set to Pr.331 RS-485 communication station number is the slave address.
FUNCTION field	For the function code, 1 to 255 can be set in single byte lengths (8 bits). The master sets the function to be sent to the slave as the request, and the slave performs the requested operation. For the supported function codes, refer to the "Function code list" on page 122 . An error response is generated when a function code other than one in the "Function code list" is set. At a response from the slave, the function code set by the master is returned in the case of a normal response. At an error response, H80 + the function code is returned.
DATA field	The format changes according to the function code. (Refer to page 123 .) The data, for example, includes the byte count, number of bytes, and accessing content of holding registers.
CRC CHECK field	Errors in the received message frame are detected. Errors are detected in the CRC check, and the message is appended with data 2 bytes long. When the message is appended with the CRC, the lower bytes are appended first, followed by the upper bytes. The CRC value is calculated by the sender that appends the message with the CRC. The receiver recalculates the CRC while the message is being received, and compares the calculation result against the actual value that was received in the error check field. If the two values do not match, the result is treated as an error.

◆ Function code list

Function name	Read/write	Code	Overview	Broadcast communication	Message format reference page
Read Holding Register	Read	H03	The data of the holding registers is read. The various data of the converter unit can be read from Modbus registers. System environmental variable (Refer to page 129.) Real time monitor (Refer to page 87.) Faults history (Refer to page 129.) Model information monitor (Refer to page 130.) Converter unit parameters (Refer to page 129.)	Not available	page 123
Preset Single Register	Write	H06	Data is written to holding registers. Data can be written to Modbus registers to set parameters in the converter unit. System environmental variable (Refer to page 129.) Converter unit parameters (Refer to page 129.)	Available	page 124
Diagnostics	Read	H08	Functions are diagnosed. (communication check only) A communication check can be made since the query message is sent and returned as it is as the return message (subfunction code H00 function). Subfunction code H00 (Return Query Data)	Not available	page 125
Preset Multiple Registers	Read	H10	Data is written to consecutive multiple holding registers. Data can be written to consecutive multiple Modbus registers to set parameters in the converter unit. System environmental variable (Refer to page 129.) Converter unit parameters (Refer to page 129.)	Available	page 126
Read Holding Register Access Log	Read	H46	The number of registers that were successfully accessed by the previous communication is read. Queries by function codes H03 and H10 are supported. The number and start address of holding registers successfully accessed by the previous communication are returned. "0" is returned for both the number and start address for queries other than the function codes H03 and H10.	Not available	page 127

◆ Read Holding Register (reading of data of holding registers) (H03 or 03)

- Query message

a. Slave Address	b. Function	c. Starting Address		d. No. of Points		CRC Check	
(8 bits)	H03 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Normal response (Response message)

a. Slave Address	b. Function	e. Byte Count	f. Data			CRC Check	
(8 bits)	H03 (8 bits)	(8 bits)	H (8 bits)	L (8 bits)	... (n × 16 bits)	L (8 bits)	H (8 bits)

- Query message setting

Message		Description
a	Slave Address	Set the address to send messages to. Broadcast communication is not available. (Invalid when "0" is set.)
b	Function	Set H03.
c	Starting Address	Set the holding register address from which to start reading the data. Start address = start register address (decimal) - 40001 For example, when start register address 0001 is set, the data of holding register address 40002 is read.
d	No. of Points	Set the number of holding registers to read. Data can be read from up to 125 registers.

- Content of normal response

Message		Description
e	Byte Count	The setting range is H02 to HFA (2 to 250). Twice the number of reads specified by d is set.
f	Data	The amount of data specified by d is set. Read data is output Hi bytes first followed by Lo bytes, and is arranged as follows: data of start address, data of start address+1, data of start address+2, and so forth.

Example) Read the register values of 41067 (**Pr.67**) to 41069 (**Pr.69**) from slave address 17 (H11).

Query message

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H11 (8 bits)	H03 (8 bits)	H04 (8 bits)	H2B (8 bits)	H00 (8 bits)	H03 (8 bits)	— (8 bits)	— (8 bits)

Normal response (Response message)

Slave Address	Function	Byte Count	Data						CRC Check	
H11 (8 bits)	H03 (8 bits)	H06 (8 bits)	H00 (8 bits)	H00 (8 bits)	H00 (8 bits)	H0A (8 bits)	H00 (8 bits)	H00 (8 bits)	— (8 bits)	— (8 bits)

Read value

Register 41067 (**Pr.67**): H0000 (0)

Register 41068 (**Pr.68**): H000A (1.0 s)

Register 41069 (**Pr.69**): H0000 (0)

(N) Operation via communication and its settings

◆ Preset Single Register (writing of data to holding registers) (H06 or 06)

- The content of the "system environmental variables" and "inverter parameters" assigned to the holding register area (refer to the register list (page 129)) can be written.
- Query message

a. Slave Address	b. Function	c. Register Address		d. Preset Data		CRC Check	
(8 bits)	H06 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Normal response (Response message)

a. Slave Address	b. Function	c. Register Address		d. Preset Data		CRC Check	
(8 bits)	H06 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Query message setting

Message		Description
a	Slave Address	Set the address to send messages to. Setting "0" enables broadcast communication.
b	Function	Set H06.
c	Register Address	Set the holding register address to write data to. Register address = holding register address (decimal) - 40001 For example, when the register address 0001 is set, data is written to the holding register address 40002.
d	Preset Data	Set the data to write to the holding register. Write data is fixed at 2 bytes.

- Content of normal response
With a normal response, the contents in the response (a to d, including the CRC check) are the same as those in the query messages.
In the case of broadcast communication, no response is returned.

Example) Write 114 (H0072) to 41075 (Pr.75) of slave address 5 (H05).

Query message

Slave Address	Function	Register Address		Preset Data		CRC Check	
H05 (8 bits)	H06 (8 bits)	H04 (8 bits)	H32 (8 bits)	H00 (8 bits)	H72 (8 bits)	— (8 bits)	— (8 bits)

Normal response (Response message)
Same data as query message

NOTE

- With broadcast communication, no response is generated even if a query is executed. When the next query is made, it must be made after waiting for the inverter data processing time after the previous query is executed.

◆Diagnostics (diagnosis of functions) (H08 or 08)

- A communication check can be made since the query message is sent and returned as it is as the return message (subfunction code H00 function).

Subfunction code H00 (Return Query Data)

- Query message

a. Slave Address	b. Function	c. Subfunction		d. Data		CRC Check	
(8 bits)	H08 (8 bits)	H00 (8 bits)	H00 (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Normal response (Response message)

a. Slave Address	b. Function	c. Subfunction		d. Data		CRC Check	
(8 bits)	H08 (8 bits)	H00 (8 bits)	H00 (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Query message setting

Message		Description
a	Slave Address	Set the address to send messages to. Broadcast communication is not available. (Invalid when "0" is set.)
b	Function	Set H08.
c	Subfunction	Set H0000.
d	Data	Any data 2 bytes long can be set. The setting range is H0000 to HFFFF.

- Content of normal response

With a normal response, the contents in the response (**a to d**, including the CRC check) are the same as those in the query messages.

NOTE

- With broadcast communication, no response is generated even if a query is executed. When the next query is made, it must be made after waiting for the inverter data processing time after the previous query is executed.

(N) Operation via communication and its settings

◆ Preset Multiple Registers (writing of data to multiple holding registers) (H10 or 16)

- Data can be written to multiple holding registers.
- Query message

a. Slave Address	b. Function	c. Starting Address		d. No. of Registers		e. ByteCount	f. Data				CRC Check	
(8 bits)	H10 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H (8 bits)	L (8 bits)	... (n × 2 × 8 bits)		L (8 bits)	H (8 bits)

- Normal response (Response message)

a. Slave Address	b. Function	c. Starting Address		d. No. of Registers		CRC Check	
(8 bits)	H10 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Query message setting

Message		Description
a	Slave Address	Set the address to send messages to. Setting "0" enables broadcast communication.
b	Function	Set H10.
c	Starting Address	Set the holding register address from which to start writing the data. Start address = start register address (decimal) - 40001 For example, when start register address 0001 is set, the data of holding register address 40002 is read.
d	No. of Points	Set the number of holding registers to write to. Data can be written to up to 125 registers.
e	Byte Count	The setting range is H02 to HFA (2 to 250). Set twice the value specified by d.
f	Data	Set the amount of data specified by d. Write data is set Hi bytes first followed by Lo bytes, and is arranged as follows: data of start address, data of start address+1, data of start address+2, and so forth.

- Content of normal response

With a normal response, the contents in the response (a to d, including the CRC check) are the same as those in the query messages.

Example) Write 2 (H02) to 41190 (**Pr.190**) and 8 (H08) to 41191 (**Pr.191**) of slave address 25 (H19).

Query message

Slave Address	Function	Starting Address		No. of Points		Byte Count	Data				CRC Check	
H19 (8 bits)	H10 (8 bits)	H04 (8 bits)	HA5 (8 bits)	H00 (8 bits)	H02 (8 bits)	H04 (8 bits)	H00 (8 bits)	H02 (8 bits)	H00 (8 bits)	H08 (8 bits)	— (8 bits)	— (8 bits)

Normal response (Response message)

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H19 (8 bits)	H10 (8 bits)	H04 (8 bits)	HA5 (8 bits)	H00 (8 bits)	H02 (8 bits)	— (8 bits)	— (8 bits)

◆ Read Holding Register Access Log (H46 or 70)

- Queries by function codes H03 and H10 are supported.

The number and start address of holding registers successfully accessed by the previous communication are returned.

"0" is returned for both the number and start address for queries other than the above function codes.

- Query message

a. Slave Address	b. Function	CRC Check	
(8 bits)	H46 (8 bits)	L (8 bits)	H (8 bits)

- Normal response (Response message)

a. Slave Address	b. Function	c. Starting Address		d. No. of Points		CRC Check	
(8 bits)	H46 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	L (8 bits)	H (8 bits)

- Query message setting

Message		Description
a	Slave Address	Set the address to send messages to. Broadcast communication is not available. (Invalid when "0" is set.)
b	Function	Set H46.

- Content of normal response

Message		Description
c	Starting Address	The start address of the holding register that was successfully accessed is returned. Start address = start register address (decimal) - 40001 For example, when start address 0001 is returned, the holding register address that was successfully accessed is 40002.
d	No. of Points	The number of holding registers that were successfully accessed is returned.

Example) Read the successful register start address and number of successful accesses from slave address 25 (H19).

Query message

Slave Address	Function	CRC Check	
H19 (8 bits)	H46 (8 bits)	— (8 bits)	— (8 bits)

Normal response (Response message)

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H19 (8 bits)	H46 (8 bits)	H04 (8 bits)	H32 (8 bits)	H00 (8 bits)	H02 (8 bits)	— (8 bits)	— (8 bits)

Two successful reads with the start address 41075 (**Pr.75**) are returned.

(N) Operation via communication and its settings

◆ Error response

- An error response is returned if the query message received from the master contains an illegal function, address or data. No response is returned for parity, CRC, overrun, framing, and busy errors.

NOTE

- No response is returned also in the case of broadcast communication.
- Error response (Response message)

a. Slave Address	b. Function	c. Exception Code	CRC Check	
(8 bits)	H80 + Function (8 bits)	(8 bits)	L (8 bits)	H (8 bits)

	Message	Description
a	Slave Address	The address received from the master is set.
b	Function	The function code requested by the master + H80 is set.
c	Exception Code	The codes in the following table are set.

- Error code list

Code	Error item	Fault definition
01	ILLEGAL FUNCTION	The query message from the master is set with a function code that cannot be handled by the slave.
02	ILLEGAL DATA ADDRESS *1	The query message from the master is set with a register address that cannot be handled by the converter unit. (No parameter, parameter cannot be read, parameter cannot be written)
03	ILLEGAL DATA VALUE	The query message from the master is set with data that cannot be handled by the converter unit. (Out of parameter write range, a mode is specified, other error)

*1 An error does not occur in the following cases:

- Function code H03 (read data of holding register)
When there are 1 or more number of reads (No. of Points) and there is 1 or more holding register from where data can be read.
- Function code H10 (write data to multiple holding registers)
When there are 1 or more number of writes (No. of Points) and there is 1 or more holding registers to which data can be written.

In other words, when function code H03 or H10 is used and multiple holding registers are accessed, an error will not occur even if a non-existent holding register or a holding register that cannot be read or written is accessed.

NOTE

- An error will occur if all accessed holding registers do not exist. The data read value of non-existent holding registers is 0, and data is invalid when written to non-existent holding registers.
- Error detection of message data

The following errors are detected in message data from the master. Tripping does not occur even if an error is detected.

Error check items

Error item	Fault definition	Converter unit operation
Parity error	The data received by the converter unit has different parity from the specified one (Pr.334 setting).	When this error occurs, Pr.343 is incremented by one. When this error occurs, the LF signal is output.
Framing error	The data received by the converter unit has a different stop bit length from the specified one (Pr.334 setting).	
Overrun error	The next data has been sent by the master before the converter unit completes receiving the preceding data.	
Message frame error	The data length of the message frame is checked, and an error is generated if the received data length is less than 4 bytes.	
CRC check error	An error is generated if the data in the message frame does not match the calculation result.	

NOTE

- The LF signal can be assigned to an output terminal by setting Pr.190 to Pr.195 (output terminal function selection). Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.

◆ Modbus register

- System environmental variable

Register	Definition	Read/write	Remarks
40002	Converter reset	Write	Any value can be written.
40003	Parameter clear	Write	Set H965A for the write value.
40004	All parameter clear	Write	Set H99AA for the write value.
40006	Parameter clear *1	Write	Set H5A96 for the write value.
40007	All parameter clear *1	Write	Set HAA99 for the write value.
40009	Converter unit status	Read	Refer to the following section.

*1 Communication parameter settings are not cleared.

<Converter unit status>

Bit	Description
0	RDB (inverter operation enable (NC contact))*2
1	0
2	0
3	RDA (inverter operation enable (NO contact))*2
4	RSO (inverter reset)*2
5	IPF (instantaneous power failure/under voltage)*2
6	FAN (fan fault)*2
7	ABC1 (fault)*2
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	Fault occurrence

*2 The signal within parentheses () is the initial status. The description changes depending on the setting of Pr.190 to Pr.195 (output terminal function selection) (page 90).

- Real time monitor

Refer to page 86 for the register numbers and monitored items of the real time monitor.

- Parameter

Pr.	Register	Name	Read/write	Remarks
0 to 999	41000 to 41999	For parameter names, refer to the parameter list (page 66).	Read/write	The parameter number + 41000 is the register number.
1000 to 1999	45000 to 45359	For parameter names, refer to the parameter list (page 66).	Read/write	The parameter number + 44000 is the register number.

- Faults history

Register	Definition	Read/write	Remarks
40501	Faults history 1	Read/write	Data is 2 bytes and so is stored in "H0000". The lowest 1 byte can be referred to for the error code. (For the error codes, refer to page 141.) The faults history is batch-cleared by writing to the register 40501. Set any value for the data.
40502	Faults history 2	Read	
40503	Faults history 3	Read	
40504	Faults history 4	Read	
40505	Faults history 5	Read	
40506	Faults history 6	Read	
40507	Faults history 7	Read	
40508	Faults history 8	Read	

(N) Operation via communication and its settings

- Model information monitor

Register	Definition	Read/write	Remarks
44001	Model (First and second characters)	Read	Reading the model in ASCII code. "H20" (blank code) is set for blank area. For "FR-CC2" H46, H52, H2D, H43, H43, H32, H20H20
44002	Model (Third and fourth characters)	Read	
44003	Model (Fifth and sixth characters)	Read	
44004	Model (Seventh and eighth characters)	Read	
44005	Model (Ninth and tenth characters)	Read	
44006	Model (Eleventh and twelfth characters)	Read	
44007	Model (Thirteenth and fourteenth characters)	Read	
44008	Model (Fifteenth and sixteenth characters)	Read	
44009	Model (Seventeenth and eighteenth characters)	Read	
44010	Model (Nineteenth and twentieth characters)	Read	
44011	Capacity (First and second characters)	Read	Reading the converter unit capacity in ASCII code. Data is read in increments of 0.1 kW. "H20" (blank code) is set for blank area. Example) 315K " 3150" (H20, H20, H33, H31, H35, H30)
44012	Capacity (Third and fourth characters)	Read	
44013	Capacity (Fifth and sixth characters)	Read	

NOTE

- When a 32-bit parameter setting or monitored value is read and the read value exceeds HFFFF, the reply data will be HFFFF.

◆ Pr.343 Communication error count

- The cumulative count of communication error occurrences can be checked.


Parameter	Setting range	Minimum setting range	Initial value
343	(Read-only)	1	0

NOTE

- The communication error count is temporarily stored in the RAM memory. The value is not stored in EEPROM, and so is cleared to 0 when power is reset and the converter is reset.

◆ Output signal LF "alarm output (communication error warning)"

- During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the terminal to be used using any of **Pr.190 to Pr.195 (output terminal function selection)**.



NOTE


- The LF signal can be assigned to an output terminal by setting **Pr.190 to Pr.195**. Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.

◆ Signal loss detection (Pr.539 Modbus-RTU communication check time interval)


- If a signal loss (communication stop) is detected between the converter unit and the master as a result of a signal loss detection, a Communication fault (inverter) (E.SER) occurs and the inverter trips.
 - When the setting is "9999", communication check (signal loss detection) is not made.
 - The monitored items and parameter settings can be read when "0" is set, but E.SER occurs.
 - A signal loss detection is made when the setting is any of "0.1 s to 999.8 s". To make a signal loss detection, it is necessary to send data from the master within the communication check time interval. (The inverter makes a communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master.)
 - The communication check time by query communication includes a no data time (3.5 bytes).
- This no data time differs according to the communication speed, so take this no data time into consideration when setting the communication check time.

Example: RS-485 terminal communication, Pr. 539 = "0.1 to 999.8s"

Query communication






Broadcast communication



5.8 Parameter clear / all parameter clear

 **POINT**

- Set "1" to **Pr.CLR Parameter clear, ALL.CL All parameter clear** to initialize all parameters. (Parameters cannot be cleared when **Pr.77 Parameter write selection= "1"**.)
- Terminal function selection parameters are not cleared with Pr.CL.
- Refer to the parameter list on [page 168](#) for availability of parameter clear and all parameter clear for each parameter.

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press <input type="button" value="MODE"/> to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number To perform a parameter clear, turn  to <i>Pr.CLR</i> , and to perform all parameter clear, turn it to <i>ALLCL</i> and press <input type="button" value="SET"/> . "0" (initial value) appears.
4.	Parameter clear Turn  to change the set value to "1". Press <input type="button" value="SET"/> to enter the setting. "1" and "Pr.CLR" (<i>ALLCL</i>) flicker alternately after parameters are cleared. <ul style="list-style-type: none"> • Turn  to read another parameter. • Press <input type="button" value="SET"/> to show the setting again. • Press <input type="button" value="SET"/> twice to show the next parameter.

Setting value	Description	
	Pr.CLR Parameter clear	ALL.CL All parameter clear
0	Initial display (Parameters are not cleared.)	
1	Returns parameters excluding terminal function selection parameters , etc. to their initial values.	Returns all parameters which can be cleared including terminal function selection parameters to their initial values.

5.9 Copying and verifying parameters

Pr.CPY setting value	Description
0.---	Initial display
1.RD	Copy the source parameters to the operation panel.
2.WR	The parameters copied to the operation panel can be also copied to the destination converter units.
3.VFY	Verify parameters in the converter unit and the operation panel. (Refer to page 135 .)






NOTE

- When the destination is other than the FR-CC2 series or when parameter copy is attempted after the parameter copy reading was stopped, "model error (r-E 4)" appears.
- Refer to the parameter list on [page 168](#) for availability of parameter copy.
- When the power is turned OFF or an operation panel is disconnected, etc. during parameter copy writing, write again or check the setting values by parameter verification.
- If parameters are copied from an older converter unit to a newer converter unit that has additional parameters, out-of-range setting values may be written in some parameters. In that case, those parameters operate as if they were set to their initial values.

5.9.1 Parameter copy

- The converter unit parameter settings can be copied to other converter units.







◆ Reading the parameter settings of the converter unit to the operation panel

Operation	
1.	Connects the operation panel to the source converter unit.
Parameter setting mode	
2.	Press  to choose the parameter setting mode. (The parameter number read previously appears.)
Selecting the parameter number	
3.	Turn  to Pr.CPY (parameter copy), and press  . "0.---" appears.
Reading to the operation panel	
4.	Turn  to change the set value to "RD". Press  to start reading of the converter unit parameter settings by the operation panel. (It takes about 30 seconds to read all the settings. During reading, "RD" flickers.)
End reading	
5.	"RD" and "Pr.CPY" flicker alternately after settings are read.

NOTE

- r-E 1 appears... Why?
-Parameter read error. Perform the operation from step 3 again.

◆ Copying parameter settings read to the operation panel to the converter unit







Operation	
1.	Connects the operation panel to the destination converter unit.
Parameter setting mode	
2.	Press  to choose the parameter setting mode. (The parameter number read previously appears.)
Selecting the parameter number	
3.	Turn  to <i>P_r_CPY</i> (parameter copy), and press  . "0- - - -" appears.
Selecting parameter copy	
4.	Turn  to change the set value to "2WR", then press  . 2. ALL appears.
Copying to the converter unit	
5.	Press  to start copying to the converter unit. (It takes about 60 seconds to copy all the settings. During copying, "2. ALL" flickers.)
Ending copying	
6.	"2WR" and "P_r_CPY" flicker alternately after copying ends.
7.	When parameters are written to the destination converter unit, reset the converter unit before operation by, for example, turning the power supply OFF.

NOTE


- *r-E2* appears... Why?
-Parameter write error. Perform the operation from step 3 again.

5.9.2 Parameter verification

- Whether the parameter settings of converter units are the same or not can be checked.







Operation	
1.	Copy the parameter settings of the verification source converter unit to the operation panel according to the procedure on page 133 .
2.	Move the operation panel to the converter unit to be verified.
3.	Screen at power-ON The monitor display appears.
4.	Parameter setting mode Press  to choose the parameter setting mode. (The parameter number read previously appears.)
5.	Selecting the parameter number Turn  to PrCPY (parameter copy), and press  . "0. - - -" appears.
6.	Parameter verification Turn  to change to the setting value " 3VFY " (parameter copy verification mode). Press  . Verification of the parameter settings copied to the operation panel and the parameter settings of the verification destination converter unit is started. (It takes about 60 seconds to verify all the settings. During verification, " 3VFY " flickers.) <ul style="list-style-type: none"> • If there are different parameters, the different parameter number and "rE3" flicker. • To continue verification, press .
7.	"PrCPY" and " 3VFY " flicker alternately after verification ends.

NOTE

- **rE3** flickers... Why?
-The parameter settings may be different between the verification source converter unit and the verification destination converter unit. To continue verification, press .

5.10 Checking parameters changed from their initial values (Initial value change list)

Parameters changed from their initial values can be displayed.

	Operation
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press  to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number Turn  to <i>Pr.CHG</i> (initial value change list), and press  . "P. - - - -" appears.
4.	Checking the initial value change list Turn  . The parameter numbers that have been changed from their initial value appear in order. • If  is pressed with parameters that have been changed, the parameter settings can be changed as they are. (Parameter numbers are no longer displayed in the list when they are returned to their initial values.) Other changed parameters appear by turning  . • "P. - - - -" appears again when the last changed parameter is displayed.

NOTE

- The initial value change list can be used also for parameter setting.

6 PROTECTIVE FUNCTIONS

This chapter explains the "PROTECTIVE FUNCTION" that operates in this product.

Always read the instructions before using the equipment.

6.1	Converter unit fault and alarm indications.....	138
6.2	Reset method for the protective functions.....	138
6.3	Check and clear of the faults history	139
6.4	Faults history and the list of fault displays	141
6.5	Causes and corrective actions	142
6.6	Check first when you have trouble	148

6.1 Converter unit fault and alarm indications

- When the converter unit detects a fault, depending on the nature of the fault, the operation panel displays an error message or warning, or a protective function activates to trip the inverter.
- When a protective function is activated, take an appropriate corrective action, then reset the converter unit (inverter), and resume the operation. Restarting the operation without a reset may break or damage the converter unit (inverter).
- When a protective function is activated, note the following points.

Item	Description
Fault output signal	Opening the magnetic contactor (MC) provided on the input side of the converter unit at a fault occurrence shuts off the control power to the converter unit, therefore, the fault output will not be retained.
Fault or alarm indication	When a protective function is activated, the operation panel displays a fault indication.
Operation restart method	While a protective function is activated, the inverter output is kept shutdown. Reset the converter unit (inverter) to restart the operation.

- Converter unit fault or alarm indications are categorized as below.

Displayed item	Description
Error message	A message regarding an operational fault and setting fault by the operation panel (FR-DU08) is displayed. The inverter does not trip.
Warning	The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
Alarm	The inverter does not trip. An Alarm (LF) signal can also be output with a parameter setting.
Fault	A protective function is activated to trip the inverter and output a Fault (ALM) signal.

NOTE


- The past eight faults can be displayed on the operation panel. (Faults history) (For the operation, refer to [page 139](#).)

6.2 Reset method for the protective functions


Reset the converter unit by performing any of the following operations. Note that the accumulated heat value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the converter unit.

The converter unit recovers about 1s after the reset is released.


- On the operation panel, press  to reset the converter unit. (This may only be performed when a fault occurs. (Refer to [page 144](#) of the Instruction Manual for faults.))



- Switch power OFF once, then switch it ON again.



- Turn ON the reset signal (RES) for 0.1s or more. (If the RES signal is kept ON, "Err" appears (flickers) to indicate that the converter unit is in a reset status.)




NOTE

- Resetting a converter unit fault with the inverter start signal ON restarts the inverter suddenly. OFF status of the inverter start signal must be confirmed before resetting.

6.3 Check and clear of the faults history

The operation panel stores the fault indications which appears when a protective function is activated to display the fault record for the past eight faults. (Faults history)

◆ Check for the faults history











◆ Faults history clearing procedure



POINT

- Set Err.CL Fault history clear = "1" to clear the faults history.

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Parameter setting mode Press  to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number Turn  until Err.CL (faults history clear) appears. Press  to read the present set value. "0" (initial value) appears.
4.	Faults history clear Turn  to change the set value to "1". Press  to start clear. "1" and "Err.CL" flicker alternately after parameters are cleared. <ul style="list-style-type: none">• Turn  to read another parameter.• Press  to show the setting again.• Press  twice to show the next parameter.

6.4 Faults history and the list of fault displays

If the displayed message does not correspond to any of the following or if you have any other problem, please contact your sales representative.

◆ Error message

- A message regarding an operational fault and setting fault by the operation panel (FR-DU08) is displayed. The inverter does not trip.

Operation panel indication	Name	Refer to page
E-----	Faults history	139
HOLD	Operation panel lock	142
LOCd	Password locked	142
Er 1	Parameter write error	142
rE 1to rE4	Copy operation error	142 143
Err.	Error	143

◆ Warning

- The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.

Operation panel indication	Name	Refer to page
EH	Electronic thermal relay function pre-alarm	143
Mf 1to Mf3	Maintenance timer 1 to 3	143
EV	24 V external power supply operation	143

◆ Alarm

- The inverter does not trip. An Alarm (LF) signal can be output with a parameter setting.

Operation panel indication	Name	Refer to page
FN	Fan alarm	144

◆ Fault

- When a protective function activates, the inverter trips. The Fault (ALM)
- data codes are used to check the fault record via communication or used for **Pr.997 Fault initiation**.



Operation panel indication	Name	Data code	Refer to page
E. OVF	Overvoltage trip	32 (H20)	144
E. FHC	Converter overload trip (electronic thermal relay function)	48 (H30)	144
E. FIN	Heatsink overheat	64 (H40)	144
E. IPF	Instantaneous power failure	80 (H50)	145
E. UVF	Undervoltage	81 (H51)	145
E. ILF	Input phase loss	82 (H52)	145
E. OMF	External thermal relay operation	144 (H90)	145
E. PE	Parameter storage device fault	176 (HB0)	145
E. PUE	PU disconnection	177 (HB1)	146
E. REF	Retry count excess	178 (HB2)	146
E. PE2	Parameter storage device fault	179 (HB3)	146
E. CPU	CPU fault	192 (HC0)	146
E. 5		245 (HF5)	
E. 6		246 (HF6)	
E. 7		247 (HF7)	
E. CFE	Operation panel power supply short circuit RS-485 terminals power supply short circuit	193 (HC1)	146
E. P24	24 VDC power fault	194 (HC2)	147
E. IOH	Inrush current limit circuit fault	197 (HC5)	147
E. SER	Communication fault (inverter)	198 (HC6)	147
E. Pbf	Internal circuit fault	202 (HCA)	147
E. 13		253 (HFD)	
E. 1	Option fault	241 (HF1)	147

If faults other than the above appear, contact your sales representative.

6.5 Causes and corrective actions

◆ Error message

A message regarding operational troubles is displayed. The inverter does not trip.


Operation panel indication	HOLD	HOLD
Name	Operation panel lock	
Description	Operation lock is set. Operation other than  is invalid. (Refer to page 77 .)	
Check point	—————	
Corrective action	Press  for 2 s to release the lock.	

Operation panel indication	LOCD	LOCD
Name	Password locked	
Description	Password function is active. Display and setting of parameters are restricted.	
Check point	—————	
Corrective action	Enter the password in Pr.297 Password lock/unlock to unlock the password function before operating. (Refer to page 78 .)	

Operation panel indication	Er1	Er 1
Name	Parameter write error	
Description	<ul style="list-style-type: none"> Parameter setting was attempted while Pr.77 Parameter write selection is set to disable parameter write. The operation panel and converter unit cannot make normal communication. 	
Check point	<ul style="list-style-type: none"> Check the Pr.77 setting. (Refer to page 77.) Check the connection between the operation panel and the converter unit. 	

Operation panel indication	rE1	rE 1
Name	Parameter read error	
Description	A failure has occurred at the operation panel side EEPROM while reading the copied parameters.	
Check point	—————	
Corrective action	<ul style="list-style-type: none"> Perform parameter copy again. (Refer to page 133.) The operation panel may be faulty. Please contact your sales representative. 	

Operation panel indication	rE2	rE 2
Name	Parameter write error	
Description	A failure has occurred at the operation panel side EEPROM while writing the copied parameters.	
Check point	—————	
Corrective action	<ul style="list-style-type: none"> The operation panel may be faulty. Please contact your sales representative. Perform parameter copy again. (Refer to page 133.) 	

Operation panel indication	rE3	rE 3
Name	Parameter verification error	
Description	<ul style="list-style-type: none"> The data in the converter unit are different from the data in the operation panel. A failure has occurred at the operation panel side EEPROM during parameter verification. 	
Check point	Check the parameter setting of the source converter unit against the setting of the destination converter unit.	
Corrective action	<ul style="list-style-type: none"> Continue the verification by pressing . Perform parameter verification again. (Refer to page 135.) The operation panel may be faulty. Please contact your sales representative. 	

Operation panel indication	rE4	rE4
Name	Model error	
Description	<ul style="list-style-type: none"> • A different model was used when parameter copy from the operation panel or parameter verification was performed. • The data in the operation panel were not correct when parameter copy from the operation panel or parameter verification was performed. 	
Check point	<ul style="list-style-type: none"> • Check that the parameter copy or verification source converter unit is of the same model. • Check that parameter copy to the operation panel was not interrupted by switching OFF the power or by disconnecting the operation panel. 	
Corrective action	<ul style="list-style-type: none"> • Perform parameter copy and parameter verification between converter units of the same model (FR-CC2 series). • Perform parameter copy to the operation panel from the converter unit again. 	

Operation panel indication	Err.	Err.
Description	<ul style="list-style-type: none"> • The RES signal is turned ON. • The operation panel and converter unit cannot make normal communication. (contact faults of the connector). • This error may occur when the voltage at the input side of the converter unit drops. • When using a separate power source for the control circuit power (R1/L11, S1/L21) from the main circuit power (R/L1, S/L2, T/L3), this error may appear at turning ON of the main circuit. It is not a fault. 	
Corrective action	<ul style="list-style-type: none"> • Turn OFF the RES signal. • Check the connection between the operation panel and the converter unit. • Check the voltage on the input side of the converter unit. 	

◆ Warning

The inverter output is not shut off when a protective function is activated.

Operation panel indication	TH	TH
Name	Electronic thermal relay function pre-alarm	
Description	If the accumulated electronic thermal value reaches 85%, TH is displayed and the THP signal is output. If the value reaches 100% of the setting, Converter overload trip (electronic thermal relay function) (E.THC) occurs. For the terminal used for the THP signal output, set "8 (positive logic)" or "108 (negative logic)" in any of Pr.190 to Pr.195 (output terminal function selection) to assign the function.	
Check point	Check for large load or sudden acceleration.	
Corrective action	Reduce the load and frequency of operation.	

Operation panel indication	MT1 to MT3	MT 1 to MT 3
Name	Maintenance timer 1 to 3	
Description	Appears when the converter unit's cumulative energization time reaches or exceeds the parameter set value. Set the time until the MT is displayed by setting Pr.504 Maintenance timer 1 warning output set time (MT1) , Pr.687 Maintenance timer 2 warning output set time (MT2) , and Pr.689 Maintenance timer 3 warning output set time (MT3) . MT does not appear when the settings of Pr.504 , Pr.687 , and Pr.689 are initial values (9999).	
Check point	The set time of maintenance timer has been exceeded. (Refer to page 82 .)	
Corrective action	Take appropriate countermeasures according to the purpose of the maintenance timer setting. Setting "0" in Pr.503 Maintenance timer 1 , Pr.686 Maintenance timer 2 , and Pr.688 Maintenance timer 3 erases the indication.	

Operation panel indication	EV	EV
Name	24 V external power supply operation	
Description	Flickers when the main circuit power supply is off and the 24 V external power supply is being input.	
Check point	Power is supplied from a 24 V external power supply.	
Corrective action	<ul style="list-style-type: none"> • Turning ON the power supply (main circuit) of the converter unit clears the indication. • If the indication is still displayed after turning ON of the power supply (main circuit) of the converter unit, the power supply voltage may be low. 	

◆ Alarm

The inverter output is not shut off when a protective function is activated. An alarm can also be output with a parameter setting.

(Set "98" in **Pr.190 to Pr.195 (output terminal function selection)**). (Refer to [page 90](#).)

Operation panel indication	FN	FN
Name	Fan alarm	
Description	FN appears on the operation panel when the cooling fan of the converter unit stops due to a fault or when the speed decreases.	
Check point	Check the cooling fan for a failure.	
Corrective action	Check for fan failure. Please contact your sales representative.	

◆ Fault

When a protective function activates, the inverter trips and a fault signal is output.

Operation panel indication	E.OVT	E. OVT
Name	Overvoltage trip	
Description	If the converter unit's internal main circuit DC voltage reaches or exceeds the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.	
Check point	<ul style="list-style-type: none"> • Check for sudden load change or excessive regeneration. • Check for power fault. 	
Corrective action	<ul style="list-style-type: none"> • Keep the load stable. • Check the power supply. 	

Operation panel indication	E.THC	E. THC
Name	Converter overload trip (electronic thermal relay function)*1	
Description	For the protection of converter unit diode, the electronic thermal O/L relay is activated in inverse-time characteristics against the converter unit input current to shut off the inverter output.	
Check point	<ul style="list-style-type: none"> • Check the motor for the use under overload. • Check that the capacity of the inverter used is not larger than that of the converter unit. 	
Corrective action	<ul style="list-style-type: none"> • Reduce the load. • Check the configuration of the inverter and the converter unit again. 	

*1 Resetting the converter unit initializes the internal cumulative heat value of the electronic thermal O/L relay function.

Operation panel indication	E.FIN	E. FIN
Name	Heatsink overheat	
Description	When the heatsink overheats, the temperature sensor activates, and the inverter output is stopped. The FIN signal can be output when the temperature reaches approximately 85% of the heatsink overheat protection operation temperature. For the terminal used for the FIN signal output, assign the function by setting "26 (positive logic) or 126 (negative logic)" in any of Pr.190 to Pr.195 (output terminal function selection) . (Refer to page 90 .)	
Check point	<ul style="list-style-type: none"> • Check for too high surrounding air temperature. • Check for heatsink clogging. • Check that the cooling fan is not stopped. (Check that FN is not displayed on the operation panel.) 	
Corrective action	<ul style="list-style-type: none"> • Set the surrounding air temperature to within the specifications. • Clean the heatsink. • Replace the cooling fan. 	

Operation panel indication	E.IPF	E. I PF
Name	Instantaneous power failure	
Description	If a power failure occurs for longer than 15 ms (this also applies to converter unit input shut-off), the instantaneous power failure protective function is activated to trip the inverter in order to prevent the control circuit from malfunctioning. If a power failure persists for 100 ms or longer, the fault output is not provided, and the inverter restarts if the inverter start signal is ON upon power restoration. (The inverter continues operating if an instantaneous power failure is within 15 ms.) In some operating status (load magnitude, acceleration/deceleration time setting, etc.), overcurrent or other protection may be activated by the inverter upon power restoration. When instantaneous power failure protection is activated, the IPF signal is output. (Refer to page 98 .)	
Check point	Find the cause of the instantaneous power failure occurrence.	
Corrective action	<ul style="list-style-type: none"> • Recover from the instantaneous power failure condition. • Prepare a backup power supply in case of an instantaneous power failure. • Set the function of automatic restart after instantaneous power failure (Pr.57). (Refer to page 98.) 	

Operation panel indication	E.UVT	E. UVT
Name	Undervoltage	
Description	If the power supply voltage of the converter unit decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases to about 300 VAC or below, this function shuts off the inverter output. When undervoltage protection is activated, the IPF signal is output. (Refer to page 98 .)	
Check point	Check if a high-capacity motor is driven.	
Corrective action	<ul style="list-style-type: none"> • Check the power supply system equipment such as the power supply. • If the problem still persists after taking the above measure, contact your sales representative. 	

Operation panel indication	E.ILF	E. I LF
Name	Input phase loss	
Description	The inverter trips if the function is enabled in Pr.872 Input phase loss protection selection (the parameter is set to "1") and one of the three power input phases is lost. This protective function is not available in the initial setting of Pr.872 (Pr.872 = "0"). (Refer to page 84 .)	
Check point	Check for a break in the cable for the three-phase power supply input.	
Corrective action	<ul style="list-style-type: none"> • Wire the cables properly. • Repair a break portion in the cable. 	

Operation panel indication	E.OHT	E. OHT
Name	External thermal relay operation	
Description	While "1" (NC contact) or "2" (NO contact) is set in Pr.876 OH input selection to enable the function, the inverter trips if output of the device such as a thermostat is input as the OH signal, and the OH signal turns ON (NO contact input) or turns OFF (NC contact input). The OH signal function is assigned to the terminal OH in the initial status. This protective function is not available in the initial setting of Pr.876 (Pr.876 = "0"). (Refer to page 95 .)	
Check point	<ul style="list-style-type: none"> • Check for overheating of the thermostat for overheat protection of peripheral devices. • Check that the value "7" (OH signal) is set correctly to any of Pr.178, Pr.187 or Pr.189 (input terminal function selection). 	
Corrective action	<ul style="list-style-type: none"> • Reduce the load and operation duty. • Even if the thermostat automatically returns to normal, the converter unit (inverter) will not restart unless it is reset. 	

Operation panel indication	E.PE	E. PE
Name	Parameter storage device fault (control circuit board)	
Description	The inverter trips if a fault occurs in the parameter stored. (EEPROM failure)	
Check point	Check for too many number of parameter write times.	
Corrective action	Please contact your sales representative. When performing parameter writing frequently for communication purposes, set "1" in Pr.342 Communication EEPROM write selection to enable RAM write. Note that writing to RAM goes back to the initial status at power OFF.	


Causes and corrective actions

Operation panel indication	E.PUE	E. PUE
Name	PU disconnection	
Description	<ul style="list-style-type: none"> The inverter trips if the communication between PU and the converter unit is canceled by removing the operation panel with the disconnected PU detection function enabled by Pr.75 Reset selection/disconnected PU detection/reset limit. The inverter trips if communication errors occur consecutively for the permissible number of retries or more during the RS-485 communication from the PU connector with Pr.121 Number of PU communication retries ≠ "9999." The inverter trips if communication is broken for the period of time set in Pr.122 PU communication check time interval during the RS-485 communication from the PU connector. 	
Check point	<ul style="list-style-type: none"> Check that the operation panel is connected properly. Check the Pr.75 setting. 	
Corrective action	Connect the operation panel securely.	

Operation panel indication	E.RET	E. RET
Name	Retry count excess	
Description	<p>The inverter trips if it has tried and failed to properly restart the operation exceeding the number of retries set in Pr.67 Number of retries at fault occurrence.</p> <p>This function is available when Pr.67 is set. This protective function is not available in the initial setting (Pr.67 = "0").</p>	
Check point	Find the cause of the fault occurrence.	
Corrective action	Eliminate the cause of the error preceding this error indication.	

Operation panel indication	E.PE2	E. PE2
Name	Parameter storage device fault (main circuit board)	
Description	The inverter trips if a fault occurs in the parameter stored. (EEPROM failure)	
Check point		
Corrective action	Please contact your sales representative.	

Operation panel indication	E.CPU	E. CPU
	E.5	E. 5
	E.6	E. 6
	E.7	E. 7
Name	CPU fault	
Description	The inverter trips if the communication fault of the built-in CPU occurs.	
Check point	Check for devices producing excess electrical noises around the converter unit.	
Corrective action	<ul style="list-style-type: none"> Take measures against noises if there are devices producing excess electrical noises around the converter unit. Please contact your sales representative. 	

Operation panel indication	E.CTE	E. CTE
Name	Operation panel power supply short circuit RS-485 terminals power supply short circuit	
Description	<ul style="list-style-type: none"> When the power supply for the operation panel (PU connector) is shorted, the power output is shutoff and the inverter trips. At this time, the use of the operation panel and the RS-485 communication via the PU connector are disabled. To reset, enter the RES signal, reset via communication through the RS-485 terminals, or switch power OFF then ON again. When the power supply for the RS-485 terminals are short circuited, this function shuts off the power output. At this time, communication from the RS-485 terminals cannot be made. To reset, use  of the operation panel, enter the RES signal, or switch power OFF then ON again. 	
Check point	<ul style="list-style-type: none"> Check that the PU connector cable is not shorted. Check that the RS-485 terminals are connected correctly. 	
Corrective action	<ul style="list-style-type: none"> Check the operation panel and the cable. Check the connection of the RS-485 terminals. 	

Operation panel indication	E.P24	E. P24
Name	24 VDC power fault	
Description	<ul style="list-style-type: none"> • If the 24 VDC power supply output from the terminal PC is shorted, or the voltage of the external 24 VDC power supply is low, the power output is shutoff. At this time, all external contact inputs turn OFF. The inverter cannot be reset by inputting the RES signal. To reset it, use the operation panel, or switch power OFF, then ON again. 	
Check point	<ul style="list-style-type: none"> • Check for a short circuit in the PC terminal output. • Check if the voltage supplied from the 24 V external power supply is correct. 	
Corrective action	<ul style="list-style-type: none"> • Repair the short-circuited portion. • Supply the power at 24 V. (If the power with insufficient voltage is supplied to the 24 V input circuit for a long time, the internal circuit may heat up. Input power at correct voltage although it will not damage the converter unit.) 	

Operation panel indication	E.IOH	E. IOH
Name	Inrush current limit circuit fault	
Description	The inverter trips when the resistor of the inrush current limit circuit is overheated. The inrush current limit circuit failure	
Check point	<ul style="list-style-type: none"> • Check that frequent power ON/OFF is not repeated. • Check if the input side fuse (5A) in the power supply circuit of the inrush current limit circuit contactor is blown. • Check that the power supply circuit of inrush current limit circuit contactor is not damaged. 	
Corrective action	<ul style="list-style-type: none"> • Configure a circuit where power ON/OFF is not repeated. • If the situation does not improve after taking the above measure, please contact your sales representative. 	

Operation panel indication	E.SER	E. SER
Name	Communication fault (inverter)	
Description	The inverter trips when communication error occurs consecutively for the permissible number of retries or more when Pr.335 RS-485 communication retry count ≠ "9999" during RS-485 communication from the RS-485 terminals. The inverter also trips if communication is broken for the period of time set in Pr.336 RS-485 communication check time interval .	
Check point	Check the RS-485 terminal wiring.	
Corrective action	Perform wiring of the RS-485 terminals properly.	

Operation panel indication	E.PBT	E. PBT
	E.13	E. 13
Name	Internal circuit fault	
Description	The inverter trips when an internal circuit fault occurs in the converter unit.	
Corrective action	Please contact your sales representative.	

Operation panel indication	E. 1	E. 1
Name	Option fault	
Description	The inverter trips if a plug-in option is disconnected while the converter unit power is ON.	
Check point	<ul style="list-style-type: none"> • Check if a plug-in option is connected. • Check for excessive noise around the converter unit. 	
Corrective action	<ul style="list-style-type: none"> • Disconnect the plug-in option. (Plug-in options cannot be used.) • Take measures against noises if there are devices producing excess electrical noises around the converter unit. <p>If the situation does not improve after taking the above measure, please contact your sales representative.</p>	

NOTE

- If faults other than the above appear, contact your sales representative.

6.6 Check first when you have trouble

POINT

- If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then set the required parameter values and check again.

6.6.1 Converter unit does not operate properly

Checkpoints	Cause	Countermeasure	Refer to page
Main circuit Control Circuit	Wiring or installation is improper.	Check for the wiring and the installation.	25
Main circuit	Appropriate power supply voltage is not applied. (Operation panel display is not provided.)	Power on a molded case circuit breaker (MCCB), an earth leakage circuit breaker (ELB), or a magnetic contactor (MC).	—
		Check for the decreased input voltage, input phase loss, and wiring.	—
		If only the control power is ON when using a separate power source for the control circuit, turn ON the main circuit power.	39

6.6.2 The power lamp is OFF

Checkpoints	Cause	Countermeasure	Refer to page
Main circuit Control Circuit	Wiring or installation is improper.	Check for the wiring and the installation. Power lamp is lit when power is supplied to the control circuit (R1/L11, S1/L21).	28

6.6.3 The charge lamp is OFF

Checkpoints	Cause	Countermeasure	Refer to page
Main circuit Control Circuit	Wiring or installation is improper.	Check for the wiring and the installation. Charge lamp is lit when power is supplied to the control circuit (R1/L1, S/L2, T/L3).	28

6.6.4 Operation panel (FR-DU08) display is not operating

Checkpoints	Cause	Countermeasure	Refer to page
Main circuit Control Circuit	Power is not input.	Input the power.	25
Front cover	Operation panel is not properly connected to the converter unit.	Check that the front cover is installed securely.	15

6.6.5 Inverter cannot be operated

Checkpoints	Cause	Countermeasure	Refer to page
Control Circuit	The terminals RDA and SE of the converter unit are not connected to the terminals MRS (X10 signal) and SD of the inverter respectively.	Check for the wiring.	25
PARAMETER	Inverter parameter settings are incorrect.	Check for the inverter parameter settings.	Refer to the Instruction Manual (Detailed) of the inverter.

6.6.6 Unable to write parameter setting

Checkpoints	Cause	Countermeasure	Refer to page
Parameter setting	Parameter is disabled by the Pr.77 Parameter write selection setting.	Check the Pr.77 setting.	77
	Key lock mode is enabled by the Pr.161 Key lock operation selection setting.	Check the Pr.161 setting.	77

6.6.7 Breaker trips

Checkpoints	Cause	Countermeasure	Refer to page
Main circuit	Wiring or installation is improper.	Check for the wiring and the installation.	25
	Appropriate power supply voltage is not applied.	Check that the power supply voltage is applied.	—

6.6.8 Converter unit generates abnormal noise

Checkpoints	Cause	Countermeasure	Refer to page
fan	Fan cover was not correctly installed when a cooling fan was replaced.	Install a fan cover correctly.	157

MEMO

7 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter explains the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" for this product.

Always read the instructions before using the equipment.

7.1	Inspection item.....	152
7.2	Measurement of main circuit voltages, currents and powers	159

Inspection item

The converter unit is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

● Precautions for maintenance and inspection

When accessing the converter unit for inspection, wait for at least 10 minutes after the power supply has been switched OFF because the smoothing capacitor voltage remains high for a while, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the converter unit is not more than 30 VDC using a tester, etc.

7.1 Inspection item

7.1.1 Daily inspection

Basically, check for the following faults during operation.

- Motor operation fault
- Improper installation environment
- Cooling system fault
- Abnormal vibration, abnormal noise
- Abnormal overheat, discoloration

7.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- Check and clean the cooling system. Clean the air filter, etc.
- Check the tightening and retighten. The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.
Tighten them according to the specified tightening torque. (Refer to [page 30.](#))
- Check the conductors and insulating materials for corrosion and damage.
- Measure the insulation resistance.
- Check and change the cooling fan and relay.

7.1.3 Daily and periodic inspection

Area of inspection	Inspection item	Description	Inspection interval		Corrective action at fault occurrence	Check by the user		
			Daily	Periodic *3				
General	Surrounding environment	Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	○		Improve the environment.			
	Overall unit	Check for unusual vibration and noise.	○		Check fault location and retighten.			
		Check for dirt, oil, and other foreign material.*1	○		Clean.			
	Power supply voltage	Check that the main circuit voltages and control voltages are normal.*2	○		Inspect the power supply.			
Main circuit	General	(1) Check with megger (across main circuit terminals and earth (ground) terminal).		○	Contact the manufacturer.			
		(2) Check for loose screws and bolts.		○	Retighten.			
		(3) Check for overheat traces on the parts.		○	Contact the manufacturer.			
		(4) Check for stain.		○	Clean.			
	Conductors, cables	(1) Check conductors for distortion. (2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.).			○	Contact the manufacturer.		
					○	Contact the manufacturer.		
	Transformer/reactor	Check for unusual odor and abnormal increase of whining sound.	○		Stop the equipment and contact the manufacturer.			
Terminal block	Check for a damage.			○	Stop the equipment and contact the manufacturer.			
Smoothing aluminum electrolytic capacitor	(1) Check for liquid leakage. (2) Check for safety valve projection and bulge. (3) Visual check and judge by the life check of the main circuit capacitor. (Refer to page 156 .)			○	Contact the manufacturer.			
				○	Contact the manufacturer.			
Relay/contactors	Check that the operation is normal and no chattering sound is heard.			○	Contact the manufacturer.			
Control circuit protection circuit	Operation check	(1) Check that the output voltages across phases are balanced while operating the inverter alone.			○	Contact the manufacturer.		
		(2) Check that no fault is found in protective and display circuits in a sequence protective operation test.			○	Contact the manufacturer.		
	Components check	Overall	(1) Check for unusual odor and discoloration.			○	Stop the equipment and contact the manufacturer.	
			(2) Check for serious rust development.			○	Contact the manufacturer.	
	Aluminum electrolytic capacitor	(1) Check for liquid leakage in a capacitor and deformation trace. (2) Visual check and judge by the life check of the control circuit capacitor. (Refer to page 156 .)			○	Contact the manufacturer.		
					○	Contact the manufacturer.		
Cooling system	Cooling fan	(1) Check for unusual vibration and noise.	○		Replace the fan.			
		(2) Check for loose screws and bolts.			○	Fix with the fan cover fixing screws		
(3) Check for stain.				○	Clean.			
	Heatsink	(1) Check for clogging.			○	Clean.		
		(2) Check for stain.			○	Clean.		

Inspection item

Area of inspection	Inspection item	Description	Inspection interval		Corrective action at fault occurrence	Check by the user
			Daily	Periodic *3		
Display	Indication	(1) Check that display is normal. (2) Check for stain.	○	○	Contact the manufacturer. Clean.	
	Meter	Check that reading is normal.	○		Stop the equipment and contact the manufacturer.	
Load motor	Operation check	Check for vibration and abnormal increase in operation noise.	○		Stop the equipment and contact the manufacturer.	

*1 Oil component of the heat dissipation grease used inside the converter unit may leak out. The oil component, however, is not flammable, corrosive, nor conductive and is not harmful to humans. Wipe off such oil component.

*2 It is recommended to install a voltage monitoring device for checking the voltage of the power supplied to the converter unit.

*3 One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

NOTE

- Continuous use of a leaked, deformed, or degraded smoothing aluminum electrolytic capacitor (as shown in the table above) may lead to a burst, breakage or fire. Replace such capacitor without delay.

7.1.4 Checking the converter module

◆Preparation

- Disconnect the external power supply cables (R/L1, S/L2, T/L3, P/+, and N/-).
- Prepare a tester. (For the resistance measurement, use the 100 Ω range.)


◆Checking method

Change the polarity of the tester alternately at the converter unit terminals R/L1, S/L2, T/L3, P/+, and N/- and check the electric continuity.

NOTE

- Before measurement, check that the smoothing capacitor is discharged.
- At the time of electric discontinuity, the measured value is almost ∞. When there is an instantaneous electric continuity, due to the smoothing capacitor, the tester may not indicate ∞. At the time of electric continuity, the measured value is several Ω to several tens of Ω. If all measured values are almost the same, although these values are not constant depending on the module type and tester type, the modules are without fault.

◆Module device numbers and terminals to be checked



Converter module	Tester polarity		Result
	⊕	⊖	
D1	R/L1	P/+	Discontinuity
	P/+	R/L1	Continuity
D2	S/L2	P/+	Discontinuity
	P/+	S/L2	Continuity
D3	T/L3	P/+	Discontinuity
	P/+	T/L3	Continuity
D4	R/L1	N/-	Continuity
	N/-	R/L1	Discontinuity
D5	S/L2	N/-	Continuity
	N/-	S/L2	Discontinuity
D6	T/L3	N/-	Continuity
	N/-	T/L3	Discontinuity

(Assumes the use of an analog meter.)

7.1.5 Cleaning

Always run the converter unit in a clean status.

When cleaning the converter unit, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.

NOTE

- Do not use solvent, such as acetone, benzene, toluene and alcohol, as these will cause the converter unit surface paint to peel off.
- The display, etc. of the operation panel (FR-DU08) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

7.1.6 Replacement of parts

The converter unit consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the converter unit. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part name	Estimated lifespan*1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years*2	Replace (as required)
On-board smoothing capacitor	10 years*2	Replace the board (as required)
Relays	—	As required
Main circuit fuse	10 years	Replace (as required)

*1 Estimated lifespan for when the yearly average surrounding air temperature is 40°C.
(without corrosive gas, flammable gas, oil mist, dust and dirt etc.)

*2 Input current: 80% of the converter unit rating



- For parts replacement, contact the nearest Mitsubishi FA center.

◆ Converter unit parts life display

The converter unit diagnoses the control circuit capacitor, cooling fan, and inrush current limit circuit by itself and estimates their lives.

The self-diagnostic warning is output when the life span of each part is near its end. It gives an indication of replacement time.

The life warning output can be used as a guideline for life judgment.

Parts	Judgment level
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10% (Power ON: 100,000 times left)
Cooling fan	Less than 50% of the specified speed.




- Refer to [page 80](#) to perform the life check of the converter unit parts.

◆ Replacement procedure of the cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration are noticed during inspection, the cooling fan must be replaced immediately.

◆ Removal


- 1) Remove the fan cover fixing screws, and remove the fan cover.
- 2) Disconnect the fan connector and remove the fan block.
- 3) Remove the fan fixing screws, and remove the fan.



*1 The number of cooling fans differs according to the converter unit capacity.

◆ Reinstallation

- 1) After confirming the orientation of the fan, reinstall the fan so that the "AIR FLOW" faces up.



- 2) For reconnection of the fan, refer to the above figure.

NOTE

- Installing the fan in the opposite direction of air flow can cause the converter unit life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power OFF before replacing fans. Since the converter unit circuits are charged with voltage even after power OFF, replace fans only when the converter unit cover is on the converter unit to prevent an electric shock accident.

◆Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the surrounding air temperature and operating conditions. When the converter unit is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

The appearance criteria for inspection are as follows:

- Case: Check the side and bottom faces for expansion.
- Sealing plate: Check for remarkable warp and extreme crack.
- heck for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.

NOTE

- The converter unit diagnoses the control circuit capacitor by itself and can judge its life. (Refer to [page 80.](#))

◆Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).


◆Main circuit fuse

A fuse is used inside the converter unit. The replacement intervals vary with the surrounding air temperature and operating conditions. When the converter unit is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

7.1.7 Converter unit replacement

The converter unit can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the converter unit.

- 1) Loosen the two mounting screws at the both side of the control circuit terminal block. (These screws cannot be removed.)
Slide down the control circuit terminal block to remove it.



- 2) Be careful not to bend the pins of the converter unit's control circuit connector, reinstall the control circuit terminal block, and fix it with the mounting screws.

NOTE

- Before starting converter unit replacement, switch power OFF, wait for at least 10 minutes, and then check the voltage with a tester and such to ensure safety.


7.2 Measurement of main circuit voltages, currents and powers

Since the voltages and currents on the converter unit power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured. When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

NOTE

- When installing meters etc. on the converter unit output side
When the wiring length between the converter unit and the inverter is large, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

◆ Examples of measuring points and instruments



◆ Measuring points and instruments

Item	Measuring point	Measuring instrument	Remarks (reference measured value)
Power supply voltage V1	Across R/L1 and S/L2, S/L2 and T/L3, T/L3 and R/L1	Moving-iron type AC voltmeter*1	Commercial power supply Within permissible AC voltage fluctuation (Refer to page 164.)
Power supply side current I1	R/L1, S/L2, T/L3 line current	Moving-iron type AC ammeter*1	
Power supply side power P1	R/L1, S/L2, T/L3 and Across R/L1 and S/L2, S/L2 and T/L3, T/L3 and R/L1	Digital power meter (for inverter) or electrodynamic type single-phase wattmeter	P1=W11 + W12 + W13 (3-wattmeter method)
Power supply side power factor Pf1	Calculate after measuring power supply voltage, power supply side current and power supply side power. $Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100 \%$		
Converter output	Across P/+ and N/-	Moving-coil type (such as tester)	Converter unit LED is ON. 1.35 × V1
Input signal	Across RDI, OH, RES(+) and SD (for sink logic)	Moving-coil type (such as tester) (internal resistance 50 kΩ or more)	When open 20 to 30 VDC ON voltage: 1 V or less "SD" is common
Fault signal	Across A1 and C1 Across B1 and C1	Moving-coil type (such as tester)	Continuity check*2 [Normal] [Fault] Across A1 and C1 Discontinuity Continuity Across B1 and C1 Continuity Discontinuity

*1 A digital power meter (designed for inverter) can also be used to measure.
*2 When the setting of Pr.195 ABC1 terminal function selection is the positive logic

7.2.1 Measurement of powers


Use a digital power meter (for inverter) for the input side of converter unit. Alternatively, measure using electrodynamic type single-phase wattmeters for the input side of the converter unit in two-wattmeter or three-wattmeter method. Since current on the input side tends to be especially unbalanced, measurement using the three-wattmeter method is recommended.

Examples of measured value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or three-wattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

[Measurement conditions]


Constant output of 60Hz or more frequency with a constant-torque (100%). The value obtained by the 3-wattmeter method with a 4-pole 3.7 kW induction motor is assumed to be 100%.



Example of measuring inverter input power

[Measurement conditions]

Constant output of 60Hz or more frequency with a constant-torque (100%). The value obtained by the 3-wattmeter method with a 4-pole 3.7 kW induction motor is assumed to be 100%.



Example of measuring inverter output power

7.2.2 Measurement of voltages and use of PT

◆ Converter unit input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

◆ PT

A PT can be used in the input side of the converter unit.

7.2.3 Measurement of currents

Use moving-iron type meter on the input side of the converter unit.

Since current on the converter unit input side tends to be unbalanced, measurement of three phases is recommended.


Correct value cannot be obtained by measuring only one or two phases.

When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate. It is recommended to monitor values using the operation panel.

Examples of measured value differences produced by different measuring meters are shown below.

[Measurement conditions]

Indicated value of the moving-iron type ammeter is 100%.



Example of measuring converter unit input current

7.2.4 Use of CT and transducer

A CT may be used on the input side of the converter unit. Use the one with the largest possible VA ability.

When using a transducer, use the effective value calculation type which is immune to harmonics.

7.2.5 Example of measuring converter unit input power factor

Calculate using effective power and apparent power. A power-factor meter cannot indicate an exact value.

$$\begin{aligned} \text{Total power factor of the converter unit} &= \frac{\text{Effective power}}{\text{Apparent power}} \\ &= \frac{\text{Three-phase input power found by the 3-wattmeter method}}{\sqrt{3} \times V (\text{power supply voltage}) \times I (\text{input current effective value})} \end{aligned}$$

7.2.6 Measurement of converter output voltage (across terminals P and N)

The output voltage of the converter is output across terminals P and N and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 540 to 600 V is output when no load is connected. The voltage decreases when a load is applied.


When energy is regenerated from the motor during deceleration, for example, the converter output voltage rises to nearly 800 to 900 V maximum.

7.2.7 Insulation resistance test using megger

- For the converter unit, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500 VDC megger.)

NOTE

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the converter unit so that the test voltage is not applied to the converter unit.
- For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.



7.2.8 Pressure test

Do not conduct a pressure test. Deterioration may occur.

8 SPECIFICATIONS

This chapter explains the "SPECIFICATIONS" of this product.
Always read the instructions before using the equipment.

8.1 Converter unit rating	164
8.2 Common specifications	164
8.3 Outline dimension drawings.....	165

8.1 Converter unit rating

Model FR-CC2-H□		315K	355K	400K	450K	500K	560K	630K
Applicable motor capacity (kW)		315	355	400	450	500	560	630
Output	Overload current rating *1	200% 60 s, 250% 3 s				150% 60 s, 200% 3 s	120% 60 s, 150% 3 s	110% 60 s, 120% 3 s
	Rated voltage *2	430 to 780 VDC *4						
Power supply	Rated input AC voltage/frequency	Three-phase 380 to 500 V 50 Hz/60 Hz						
	Permissible AC voltage fluctuation	Three-phase 323 to 550 V 50 Hz/60 Hz						
	Permissible frequency fluctuation	±5%						
	Rated input current (A)	610	683	770	866	962	1094	1212
Power supply capacity (kVA) *3		465	521	587	660	733	833	924
Protective structure (IEC 60529)		Open type (IP00)						
Cooling system		Forced air cooling						
DC reactor		Built-in						
Approx. mass (kg)		210	213	282	285	288	293	294

- *1 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the converter unit and the inverter to return to or below the temperatures under 100% load.
- *2 The converter unit output voltage varies according to the input power supply voltage and the load. The maximum point of the voltage waveform at the converter unit output side is approximately the power supply voltage multiplied by $\sqrt{2}$.
- *3 The power supply capacity is the value when at the rated output current. It varies by the impedance at the power supply side (including those of the input reactor and cables).
- *4 The permissible voltage imbalance ratio is 3% or less. (Imbalance ratio = (highest voltage between lines - average voltage between three lines) / average voltage between three lines × 100)

8.2 Common specifications


Input signals (three terminals)		External thermal relay input, Converter reset The input signal can be changed using Pr.178, Pr.187, and Pr.189 (input terminal function selection) .
Operational functions		Thermal protection, DC injection brake, automatic restart after instantaneous power failure, retry function, RS-485 communication, life diagnosis, maintenance timer, 24 V power supply input for control circuit
Output signal		Inverter operation enable (positive logic, negative logic), Instantaneous power failure/undervoltage, Inverter reset, Fan fault output, Fault The output signal can be changed using Pr.190 to Pr.195 (output terminal function selection) .
Open collector output (five terminals)		
Relay output (one terminal)		
Operation panel (FR-DU08)*4	Operating status	Converter output voltage, Input current, Electric thermal relay function load factor The monitored item can be changed using Pr.774 to Pr.776 Operation panel monitor selection 1 to 3 .
	Fault record	Fault record is displayed when a fault occurs. Past 8 fault records and the conditions immediately before the fault (converter output voltage/input current/electronic thermal relay function load factor/cumulative energization time/year/month/date/time) are saved.
Protective/warning function	Protective function	Overvoltage trip, Converter overload trip (electronic thermal relay function), Heatsink overheat, Instantaneous power failure, Undervoltage, Input phase loss*3, External thermal relay operation, PU disconnection*3, Retry count excess*3, Parameter storage device fault, CPU fault, 24 VDC power fault, Inrush current limit circuit fault, Communication fault (inverter), Option fault, Operation panel power supply short circuit RS-485 terminals power supply short circuit, Internal circuit fault
	Warning function	Fan alarm, Electronic thermal relay function pre-alarm, Maintenance timer 1 to 3*3, Operation panel lock*3, Password locked*3, Parameter write error, Copy operation error, 24 V external power supply operation
Environment	Surrounding air temperature	FR-CC2-H315K to H560K: -10°C to +50°C (non-freezing) FR-CC2-H630K: -10°C to +40°C (non-freezing)
	Surrounding air humidity	With circuit board coating (conforming to IEC60721-3-3 3C2/3S2): 95% RH or less (non-condensing) Without circuit board coating: 90% RH or less (non-condensing)
	Storage temperature*1	-20°C to +65°C
	Atmosphere	Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt, etc.)
	Altitude/vibration	Maximum 1000 m above sea level, 2.9 m/s ² or less*2 at 10 to 55 Hz (directions of X, Y, Z axes)

- *1 Temperature applicable for a short time, e.g. in transit.
- *2 For the installation in an altitude above 1000 m (up to 2500 m), derate the rated current 3% per 500 m.
- *3 This protective function is not available in the initial status.
- *4 In the initial status, monitoring using the operation panel (FR-DU08) is not available. Remove the accessory cover and install the inverter operation panel (FR-DU08). (Refer to [page 15](#))


8.3 Outline dimension drawings

8.3.1 Converter unit outline dimension drawings

FR-CC2-H315K, H355K



FR-CC2-H400K, H450K, H500K, H560K, H630K



*1 Do not remove the cover on the side of the converter unit.

MEMO



APPENDIX

APPENDIX provides the reference information for use of this product.

Refer to **APPENDIX** as required.

Appendix1	Instruction code list.....	168
Appendix2	Instructions for compliance with the EU Directives.	170
Appendix3	Instructions for UL and cUL	172

Appendix 1 Instruction code list

- *1 Instruction codes are used to read and write parameters by using the Mitsubishi inverter protocol via RS-485 communication. (For the RS-485 communication, refer to [page 106](#).)
- *2 For "parameter copy", "parameter clear", and "all parameter clear", "O" indicates the function is available, and × indicates the function is not available.
- *3 Communication parameters that are not cleared by parameter clear (all clear) via the RS-485 communication. (For the RS-485 communication, refer to [page 106](#).)
- *4 Reading/writing is enabled only during communication via the PU connector.

Pr.	Name	Instruction code*1			PARAMETER		
		Read	Write	Extended	Copy*2	Clear*2	All clear*2
30	Reset selection during power supply to main circuit	1E	9E	0	○	○	○
57	Restart selection	39	B9	0	○	○	○
65	Retry selection	41	C1	0	○	○	○
67	Number of retries at fault occurrence	43	C3	0	○	○	○
68	Retry waiting time	44	C4	0	○	○	○
69	Retry count display erase	45	C5	0	○	○	○
75	Reset selection/disconnected PU detection/reset limit	4B	CB	0	○	×	×
77*4	Parameter write selection	4D	CD	0	○	○	○
117	PU communication station number	11	91	1	○	○*3	○*3
118	PU communication speed	12	92	1	○	○*3	○*3
119	PU communication stop bit length / data length	13	93	1	○	○*3	○*3
120	PU communication parity check	14	94	1	○	○*3	○*3
121	Number of PU communication retries	15	95	1	○	○*3	○*3
122	PU communication check time interval	16	96	1	○	○*3	○*3
123	PU communication waiting time setting	17	97	1	○	○*3	○*3
124	PU communication CR/LF selection	18	98	1	○	○*3	○*3
161	Key lock operation selection	01	81	2	○	×	○
168 169	Parameter for manufacturer setting.						
170	Watt-hour meter clear	0A	8A	2	○	×	○
178	RDI terminal function selection	12	92	2	○	×	○
187	OH terminal function selection	1B	9B	2	○	×	○
189	RES terminal function selection	1D	9D	2	○	×	○
190	RDB terminal function selection	1E	9E	2	○	×	○
191	RDA terminal function selection	1F	9F	2	○	×	○
192	IPF terminal function selection	20	A0	2	○	×	○
193	RSO terminal function selection	21	A1	2	○	×	○
194	FAN terminal function selection	22	A2	2	○	×	○
195	ABC1 terminal function selection	23	A3	2	○	×	○

Pr.	Name	Instruction code*1			PARAMETER		
		Read	Write	Extended	Copy*2	Clear*2	All clear*2
248	Self power management selection	38	B8	2	○	○	○
255	Life alarm status display	3F	BF	2	×	×	×
256	Inrush current limit circuit life display	40	C0	2	×	×	×
257	Control circuit capacitor life display	41	C1	2	×	×	×
261	Power failure stop selection	45	C5	2	○	○	○
268	Monitor decimal digits selection	4C	CC	2	○	○	○
269	Parameter for manufacturer setting. Do not set.						
290	Monitor negative output selection	62	E2	2	○	○	○
296	Password lock level	68	E8	2	○	×	○
297	Password lock/unlock	69	E9	2	○	○*4	○
331	RS-485 communication station number	1F	9F	3	○	○*3	○*3
332	RS-485 communication speed	20	A0	3	○	○*3	○*3
333	RS-485 communication stop bit length / data length	21	A1	3	○	○*3	○*3
334	RS-485 communication parity check selection	22	A2	3	○	○*3	○*3
335	RS-485 communication retry count	23	A3	3	○	○*3	○*3
336	RS-485 communication check time interval	24	A4	3	○	○*3	○*3
337	RS-485 communication waiting time setting	25	A5	3	○	○*3	○*3
341	RS-485 communication CR/LF selection	29	A9	3	○	○*3	○*3
342	Communication EEPROM write selection	2A	AA	3	○	○	○
343	Communication error count	2B	AB	3	×	×	×
503	Maintenance timer 1	03	83	5	×	×	×
504	Maintenance timer 1 warning output set time	04	84	5	○	×	○
539	Modbus-RTU communication check time interval	27	A7	5	○	○*3	○*3
549	Protocol selection	31	B1	5	○	○*3	○*3
563	Energization time carrying-over times	3F	BF	5	×	×	×
598	Undervoltage level	62	E2	5	○	○	○
663	Control circuit temperature signal output level	3F	BF	6	○	○	○
686	Maintenance timer 2	56	D6	6	×	×	×
687	Maintenance timer 2 warning output set time	57	D7	6	○	×	○
688	Maintenance timer 3	58	D8	6	×	×	×

Pr.	Name	Instruction code*1			PARAMETER		
		Read	Write	Extended	Copy *2	Clear *2	All clear *2
689	Maintenance timer 3 warning output set time	59	D9	6	○	×	○
774	Operation panel monitor selection 1	4A	CA	7	○	○	○
775	Operation panel monitor selection 2	4B	CB	7	○	○	○
776	Operation panel monitor selection 3	4C	CC	7	○	○	○
872	Input phase loss protection selection	48	C8	8	○	○	○
876	OH input selection	4C	CC	8	○	○	○
888	Free parameter 1	58	D8	8	○	×	×
889	Free parameter 2	59	D9	8	○	×	×
891	Cumulative power monitor digit shifted times	5B	DB	8	○	○	○
990	PU buzzer control	5A	DA	9	○	○	○
992	Operation panel setting dial push monitor selection	5C	DC	9	○	○	○
997	Fault initiation	61	E1	9	×	×	×
1006	Clock (year)	06	86	A	×	×	×
1007	Clock (month, day)	07	87	A	×	×	×
1008	Clock (hour, minute)	08	88	A	×	×	×
1048	Display-off waiting time	30	B0	A	○	○	○

Appendix2 Instructions for compliance with the EU Directives

The EU Directives are issued to standardize different national regulations of the EU Member States and to facilitate free movement of the equipment, whose safety is ensured, in the EU territory.

Since 1996, compliance with the EMC Directive that is one of the EU Directives has been legally required. Since 1997, compliance with the Low Voltage Directive, another EU Directive, has been also legally required. When a manufacturer confirms its equipment to be compliant with the EMC Directive and the Low Voltage Directive, the manufacturer must declare the conformity and affix the CE marking.

- The authorized representative in the EU

The authorized representative in the EU is shown below.

Company name: Mitsubishi Electric Europe B.V.

Address: Gothaer Strasse 8, 40880 Ratingen, Germany

- Note

We declare that this converter unit conforms with the EMC Directive in industrial environments and affix the CE marking on the converter unit. When using the converter unit in a residential area, take appropriate measures and ensure the conformity of the converter unit used in the residential area.

◆ EMC Directive

We declare that this converter unit conforms with the EMC Directive and affix the CE marking on the converter unit.

- EMC Directive: 2004/108/EC
- Standard(s): EN61800-3: 2004 (Second environment / PDS Category "C3")
- This converter unit is not intended to be used on a low-voltage public network which supplies domestic premises.
- Radio frequency interference is expected if used on such a network.
- The installer shall provide a guide for installation and use, including recommended mitigation devices.

Note:

First environment

Environment including residential buildings. Includes building directly connected without a transformer to the low voltage power supply network which supplies power to residential buildings.

Second environment

Environment including all buildings except buildings directly connected without a transformer to the lower voltage power supply network which supplies power to residential buildings.

◆ Note

Set the EMC filter valid and install the converter unit and perform wiring according to the following instructions.

- *1 The converter unit is equipped with an EMC filter. Enable the EMC filter. (For details, refer to [page 51](#).)
- *2 Connect the inverter and the converter unit to an earthed power supply.
- *3 Install a motor and a control cable written in the EMC Installation Manual (BCN-A21041-204) and Technical News (MF-S-113, 115) according to the instruction.
- *4 Confirm that the final integrated system with the inverter and the converter unit conforms with the EMC Directive.

◆ Low Voltage Directive

We have self-confirmed our converter units as products compliant to the Low Voltage Directive (Conforming standard EN 61800-5-1) and affix the CE marking on the converter units.

◆ Outline of instructions

- *1 Do not use an earth leakage current breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth (ground) securely.
- *2 Wire the earth (ground) terminal independently. (Do not connect two or more cables to one terminal.)
- *3 Use the earth (ground) cable and the cable sizes on [page 30](#) under the following conditions.
 - Surrounding air temperature: 40°C (104°F) maximum
 If conditions are different from above, select appropriate wire according to EN60204 Appendix C TABLE 5.
- *4 Use a tinned (plating should not include zinc) crimping terminal to connect the earth (ground) cable. When tightening the screw, be careful not to damage the threads.

For use as a product compliant with the Low Voltage Directive, use a PVC cable whose size is indicated on [page 30](#).
- *5 Use the molded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard.
- *6 DC current may flow from the converter unit to a protective earth (ground) conductor. When using a residual current device (RDC) or residual current monitor (RDM), connect a type B RCD or RCM to the power supply side.
- *7 Use the converter unit under the conditions of overvoltage category II (usable regardless of the earth (ground) condition of the power supply), overvoltage category III (usable with the earth-neutral system power supply, 400 V class only) and pollution degree 2 or lower specified in IEC60664.
 - To use the converter unit under the conditions of pollution degree 2, install it in the enclosure of IP2X or higher.
 - To use the converter unit under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher.
- *8 On the input and output of the inverter and the converter unit, use cables of the type and size set forth in EN60204 Appendix C.
- *9 The operating capacity of the relay outputs (terminal symbols A1, B1, C1, A2, B2, C2) should be 30 VDC, 0.3 A. (Relay output has basic isolation from the internal circuit of the inverter and the converter unit.)
- *10 Control circuit terminals on [page 25](#) are safely isolated from the main circuit.
- *11 Environment (For the detail, refer to [page 17](#).)

	During Operation	In Storage	During Transportation
Surrounding air temperature	-10 to +40°C	-20 to +65°C	-20 to +65°C
Ambient humidity	95% RH or less	95% RH or less	95% RH or less
Maximum altitude	2500 m	2500 m	10000 m

◆ Wiring protection

Class T, Class J, Class CC, or Class L fuse must be provided.

FR-CC2-□	H315K	H355K	H400K	H450K	H500K	H560K	H630K
Rated fuse voltage (V)	500 V or more						
Fuse maximum allowable rating (A) *1	1100	1200	1350	1500	1800	1800	1800

*1 Maximum allowable rating by US National Electrical Code. Exact size must be chosen for each installation.

◆ Short circuit ratings

Suitable For Use in A Circuit Capable of Delivering Not More Than 100 kA rms Symmetrical Amperes, 550 V or 600 V Maximum.

Appendix 3 Instructions for UL and cUL

(Standard to comply with: UL 508C, CSA C22.2 No.14)

◆ General Precaution

CAUTION - Risk of Electric Shock -

The bus capacitor discharge time is 10 minutes. Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for residual voltage between terminal P/+ and N/- with a meter etc., to avoid a hazard of electrical shock.

ATTENTION - Risque de choc électrique -

La durée de décharge du condensateur de bus est de 10 minutes. Avant de commencer le câblage ou l'inspection, mettez l'appareil hors tension et attendez plus de 10 minutes.

◆ Installation

The below types of converter unit have been approved as products for use in enclosure.

Design the enclosure so that the surrounding air temperature, humidity and ambience of the converter unit will satisfy the above specifications. (Refer to [page 17](#).)

◆ Wiring protection

For installation in the United States, Class T, Class J, Class CC, or Class L fuse must be provided, in accordance with the National Electrical Code and any applicable local codes.

For installation in Canada, Class T, Class J, Class CC, or Class L fuse must be provided, in accordance with the Canadian Electrical Code and any applicable local codes.

FR-CC2-□	H315K	H355K	H400K	H450K	H500K	H560K	H630K
Rated fuse voltage (V)	500 V or more						
Fuse maximum allowable rating (A) *1	1100	1200	1350	1500	1800	1800	1800

*1 Maximum allowable rating by US National Electrical Code. Exact size must be chosen for each installation.

◆ Wiring to the power supply and the motor

For wiring the input (R/L1, S/L2, T/L3) terminals of the converter unit and output (U, V, W) terminals of the inverter, use the UL listed copper, stranded wires (rated at 75°C) and round crimping terminals. Crimp the crimping terminals with the crimping tool recommended by the terminal maker.

◆ Short circuit ratings

Suitable For Use in A Circuit Capable of Delivering Not More Than 100 kA rms Symmetrical Amperes, 550 V or 600 V Maximum.

MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print date	*Manual number	Revision
Feb. 2014	IB(NA)-0600543ENG-A	First edition
Jul. 2014	IB(NA)-0600543ENG-B	Addition · FR-CC2-H560K, H630K



HEADQUARTERS		EUROPEAN REPRESENTATIVES		EUROPEAN REPRESENTATIVES		EURASIAN REPRESENTATIVES	
Mitsubishi Electric Europe B.V. Gothaer Straße 8 D-40880 Ratingen Phone: +49 (0)2102 / 486-0 Fax: +49 (0)2102 / 486-1120	EUROPE	GEVA Wiener Straße 89 A-2500 Baden Phone: +43 (0)2252 / 85 55 20 Fax: +43 (0)2252 / 488 60	AUSTRIA	Beijer Electronics UAB Goštautų g. 3 LT-48324 Kaunas Phone: +370 37 262707 Fax: +370 37 455605	LITHUANIA	TOO Kazpromavtomatika UL. ZHAMBYLA 28, KAZ-100017 Karaganda Phone: +7 7212 / 50 10 00 Fax: +7 7212 / 50 11 50	KAZAKHSTAN
Mitsubishi Electric Europe B.V. Radlická 751/113e Avenir Business Park CZ-158 00 Praha 5 Phone: +420 251 551 470 Fax: +420 251 551 471	CZECH REP.	000 TECHNIKON Prospect Nezavisimosti 177-9 BY-220125 Minsk Phone: +375 (0)17 / 393 1177 Fax: +375 (0)17 / 393 0081	BELARUS	ALFATRADE Ltd. 99, Paola Hill Malta-Paola PLA 1702 Phone: +356 (0)21 / 697 816 Fax: +356 (0)21 / 697 817	MALTA	MIDDLE EAST REPRESENTATIVE	
Mitsubishi Electric Europe B.V. 25, Boulevard des Bouvets F-92741 Nanterre Cedex Phone: +33 (0)1 / 55 68 55 68 Fax: +33 (0)1 / 55 68 57 57	FRANCE	ESCO DRIVES Culliganlaan 3 BE-1831 Diegem Phone: +32 (0)2 / 717 64 60 Fax: +32 (0)2 / 717 64 61	BELGIUM	INTEHSIS SRL bld. Traian 23/1 MD-2060 Kishinev Phone: +373 (0)22 / 66 4242 Fax: +373 (0)22 / 66 4280	MOLDOVA	I.C. SYSTEMS Ltd. 23 Al-Saad-Al-Alee St. EG-Sarayat, Maadi, Cairo Phone: +20 (0) 2 / 235 98 548 Fax: +20 (0) 2 / 235 96 625	EGYPT
Mitsubishi Electric Europe B.V. Westgate Business Park, Ballymount IRL-Dublin 24 Phone: +353 (0)1 4198800 Fax: +353 (0)1 4198890	IRELAND	KONING & HARTMAN B.V. Woluwelaan 31 BE-1800 Vilvoorde Phone: +32 (0)2 / 257 02 40 Fax: +32 (0)2 / 257 02 49	BELGIUM	HIFLEX AUTOM. B.V. Wolweverstraat 22 NL-2984 CD Ridderkerk Phone: +31 (0)180 / 46 60 04 Fax: +31 (0)180 / 44 23 55	NETHERLANDS	SHERF Motion Techn. Ltd. Rehov Hamerkava 19 IL-58851 Holon Phone: +972 (0)3 / 559 54 62 Fax: +972 (0)3 / 556 01 82	ISRAEL
Mitsubishi Electric Europe B.V. Viale Colleoni 7 Palazzo Sirio I-20864 Agrate Brianza (MB) Phone: +39 039 / 60 53 1 Fax: +39 039 / 60 53 312	ITALY	INEA RBT d.o.o. Stegne 11 SI-1000 Ljubljana Phone: +386 (0)1/513 8116 Fax: +386 (0)1/513 8170	BOSNIA AND HERZEGOVINA	IMTECH MARINE & OFFSHORE B.V. Sluisjesdijk 155 NL-3087 AG Rotterdam Phone: +31 (0)10 / 487 19 11 Fax: +31 (0)10 / 487 1692	NETHERLANDS	CEG LIBAN Cebaco Center/Block A Autostrade DORA Lebanon-Beirut Phone: +961 (0)1 / 240 445 Fax: +961 (0)1 / 240 193	LEBANON
Mitsubishi Electric Europe B.V. Nijverheidsweg 23a NL-3641RP Mijdrecht Phone: +31 (0) 297250350	NETHERLANDS	AKHNATON 4, Andrei Ljapchev Blvd., PO Box 21 BG-1756 Sofia Phone: +359 (0)2 / 817 6000 Fax: +359 (0)2 / 97 44 06 1	BULGARIA	KONING & HARTMAN B.V. Energieweg 1 NL-2627 AP Delft Phone: +31 (0)15 260 99 06 Fax: +31 (0)15 261 9194	NETHERLANDS	AFRICAN REPRESENTATIVE	
Mitsubishi Electric Europe B.V. ul. Krakowska 50 PL-32-083 Balice Phone: +48 (0) 12 347 65 00 Fax: +48 (0) 12 347 65 01	POLAND	INEA CR Losinjska 4 a HR-10000 Zagreb Phone: +385 (0)1 / 36 940 - 01/ -02/ -03 Fax: +385 (0)1 / 36 940 - 03	CROATIA	Beijer Electronics AS Postboks 487 NO-3002 Drammen Phone: +47 (0)32 / 24 30 00 Fax: +47 (0)32 / 84 85 77	NORWAY	ADROIT TECHNOLOGIES 20 Waterford Office Park 189 Witkoppen Road ZA-Fourways Phone: + 27 (0)11 / 658 8100 Fax: + 27 (0)11 / 658 8101	SOUTH AFRICA
Mitsubishi Electric Europe B.V. 52, bld. 1 Kosmodamianskaya emb. RU-115054 Moscow Phone: +7 495 / 721 2070 Fax: +7 495 / 721 2071	RUSSIA	AutoCont C. S. S.R.O. Kačkova 1853/3 CZ-702 00 Ostrava 2 Phone: +420 595 691 150 Fax: +420 595 691 199	CZECH REPUBLIC	Fonseca S.A. R. João Francisco do Casal 87/89 PT-3801-997 Aveiro, Esigueira Phone: +351 (0)234 / 303 900 Fax: +351 (0)234 / 303 910	PORTUGAL		
Mitsubishi Electric Europe B.V. Carretera de Rubi 76-80 Apdo. 420 E-08190 Sant Cugat del Vallés (Barcelona) Phone: +34 (0) 93 / 5653131 Fax: +34 (0) 93 / 5891579	SPAIN	Beijer Electronics A/S Lykkegardsvej 17 DK-4000 Roskilde Phone: +45 (0)46/75 76 66 Fax: +45 (0)46 / 75 56 26	DENMARK	SIRIUS TRADING & SERVICES SRL Aleea Lacul Morii Nr. 3 RO-060841 Bucuresti, Sector 6 Phone: +40 (0)21 / 430 40 06 Fax: +40 (0)21 / 430 40 02	ROMANIA		
Mitsubishi Electric Europe B.V. (Scandinavia) Fjellievägen 8 SE-22736 Lund Phone: +46 (0) 8 625 10 00 Fax: +46 (0) 46 39 70 18	SWEDEN	HANS FÖLPGAARD A/S Theilgaardstrø 1 DK-4600 Køge Phone: +45 4320 8600 Fax: +45 4396 8855	DENMARK	INEA SR d.o.o. Ul. Karadjordjeva 12/217 SER-11300 Smederevo Phone: +386 (026) 461 54 01	SERBIA		
Mitsubishi Electric Turkey Elektrik Ürünleri A.Ş. Fabrika Otomasyon Merkezi Şerifali Mahallesi Nutuk Sokak No.5 TR-34775 Ümraniye-İSTANBUL Phone: +90 (0)216 / 526 39 90 Fax: +90 (0)216 / 526 39 95	TURKEY	Beijer Electronics Eesti OÜ Pärnu mnt. 160i EE-11317 Tallinn Phone: +372 (0)6 / 51 81 40 Fax: +372 (0)6 / 51 81 49	ESTONIA	SIMAP SK (Západné Slovensko) Jána Derku 1671 SK-911 01 Trenčín Phone: +421 (0)32 743 04 72 Fax: +421 (0)32 743 75 20	SLOVAKIA		
Mitsubishi Electric Europe B.V. Travellers Lane UK-Hatfield, Herts. AL10 8XB Phone: +44 (0)1707 / 28 87 80 Fax: +44 (0)1707 / 27 86 95	UK	Beijer Electronics OY Vanha Nurmijärventie 62 FIN-01670 Vantaa Phone: +358 (0)207 / 463 500 Fax: +358 (0)207 / 463 501	FINLAND	INEA RBT d.o.o. Stegne 11 SI-1000 Ljubljana Phone: +386 (0)1 / 513 8116 Fax: +386 (0)1 / 513 8170	SLOVENIA		
Mitsubishi Electric Europe B.V. Dubai Silicon Oasis United Arab Emirates - Dubai Phone: +971 4 3724716 Fax: +971 4 3724721	UAE	PROVENDOR OY Teljänkatu 8 A3 FIN-28130 Pori Phone: +358 (0) 2 / 522 3300 Fax: +358 (0) 2 / 522 3322	FINLAND	Beijer Electronics Automation AB Box 426 SE-20124 Malmö Phone: +46 (0)40 / 35 86 00 Fax: +46 (0)40 / 93 23 01	SWEDEN		
Mitsubishi Electric Corporation Tokyo Building 2-7-3 Marunouchi, Chiyoda-ku Tokyo 100-8310 Phone: +81 (3) 3218-2111 Fax: +81 (3) 3218-2185	JAPAN	UTECO A.B.E.E. 5, Mavrogenous Str. GR-18542 Piraeus Phone: +30 (0)211 / 1206-900 Fax: +30 (0)211 / 1206-999	GREECE	OMNI RAY AG Im Schörl 5 CH-8600 Dübendorf Phone: +41 (0)44 / 802 28 80 Fax: +41 (0)44 / 802 28 28	SWITZERLAND		
Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Phone: +1 (847) 478-2100 Fax: +1 (847) 478-0328	USA	MELTRADE Kft. Fertő utca 14. HU-1107 Budapest Phone: +36 (0)1 / 431-9726 Fax: +36 (0)1 / 431-9727	HUNGARY	OOO "CSC-AUTOMATION" 4-B, M. Raskovoyi St. UA-02660 Kiev Phone: +380 (0)44 / 494 33 44 Fax: +380 (0)44 / 494-33-66	UKRAINE		
		Beijer Electronics SIA Rītausmas iela 23 LV-1058 Riga Phone: +371 (0)6 / 784 2280 Fax: +371 (0)6 / 784 2281	LATVIA				